



check if the mounting holles should be connected to ground or not.
 Generally a load module has mounting holes connected to the ground.
 Power source modules has mountig holes floating to avoid ground loops.

Title: GH4PIN01

PixHawk – MLAB interface

Alsa–Tucnak

Author: Mlab www.mlab.cz

Size: A4

Page: 1/1

Date: %d. %m. %Y

