



**check if the mounting holles should be connected to ground or not.**  
 Generally a load module has mounting holes connected to the ground.  
 Power source modules has mountig holes floating to avoid ground loops.

# **Title: GH4PIN01**

PixHawk – MLAB interface

Alsa-Tucnak

Author: Mlab [www.mlab.cz](http://www.mlab.cz)

Size: A4

Page: 1/1

Date: %d. %m. %Y

