



BearExtender

Instructions

Unplug the BearExtender USB cable first.

1. Run "Remove workaround" then restart
2. Run "Remove old files" then restart
3. Run "Install 5.4" **do not restart yet**
4. When "Install 5.4" finishes, **plug in the BearExtender USB cable.**
5. Now click restart.

After the third restart:

6. Look for the dot signal icon in your menu bar near the clock
7. When the BearExtender window opens click your network once, then click "Add to favorites"
8. Enter your Wi-Fi network password if required
9. Now you will be taken to the Favorites tab.
10. Select the network you just added and click "Activate".

From now on, BearExtender will automatically connect within 7-10 seconds the next time you unplug/plug in the USB cable or sleep/wake/shutdown/startup your Mac.

Additional notes

You can now unplug the USB cable at any time when finished using BearExtender. You do not need to shutdown first.

Please report issues to support@bearextender.com