

Step 1: Bring the cursor here and keeping “UseCases” press ENTER.

UseCase Selection		Production System	Customer Orders	Production Planning
-------------------	--	-------------------	-----------------	---------------------

Folder name:

UseCases

Use Cases:

Read

Case Info:

Step 2: Click the READ button for TBRM_Test instance.

UseCase Selection Production System Customer Orders Production Planning

Folder name: UseCases Use Cases: TBRM_Test ▼ Read

Case Info:

```
->/content/ProductionPlanning/UseCases
>>> file.CustomerOrders.csv
Customer Orders created: 116
>>> file.Resources.csv
Resources created: 49
>>> file.Operations.csv
Operations created: 816
>>> file.Precedences.csv
>>> file.ProductsOperations.csv
>>> file.Products.csv
Products created: 517
>>> file.ResourcesOperations.csv
ResourcesOperations: 816
```

Step 3: In “Production System” tab, the instance elements (resources, products, operations) can be seen.

The screenshot displays the 'Production System' tab, which is highlighted with a blue border and an arrow pointing to it from the text above. The tab is part of a larger interface with other tabs: 'UseCase Selection', 'Customer Orders', and 'Production Planning'. Below the tabs, there are three main sections: 'Resource List', 'Product List', and 'Operation List'. Each section contains a list of items with a scrollbar on the right side.

Resource List	Product List	Operation List
ZGN_02	bracket_[BD50-5075-011-E]	Material prep _ bracket_[BD50-5075-011-E]
FR3_01	ALU 7075 T79511 hoekprofiel 20x16x1.2_[5601-	Milling _ bracket_[BD50-5075-011-E]
BKW_01	bracket_[BD50-5075-013F]	BW - Benchwork _ bracket_[BD50-5075-011-E]
VERP_P	bracket_[BD50-5075-015F]	Packaging _ bracket_[BD50-5075-011-E]
Chromising		

Step 4: In “Customer Orders” tab, the list of customer orders can be seen.

The screenshot shows a software interface with four tabs: 'UseCase Selection', 'Production System', 'Customer Orders', and 'Production Planning'. The 'Customer Orders' tab is selected. Below the tabs are three lists: 'Resource List', 'Product List', and 'Operation List'.

Resource List	Product List	Operation List
ZGN_02	bracket_[BD50-5075-011-E]	Material prep _ bracket_[BD50-5075-011-E]
FR3_01	ALU 7075 T79511 hoekprofiel 20x16x1.2_[5601-	Milling _ bracket_[BD50-5075-011-E]
BKW_01	bracket_[BD50-5075-013F]	BW - Benchwork _ bracket_[BD50-5075-011-E]
VERP_P	bracket_[BD50-5075-015F]	Packaging _ bracket_[BD50-5075-011-E]
Chromising		

Step 5: Click “Make Plan” button to find a planning result for the customer orders.

UseCase Selection

Production System

Customer Orders

Production Planning

Make Plan

Summary

>Planning Horizon: 2025-03-15 <--> 2025-07-18 00:00:00
>> Deliveries
->S02548(M.P04743): deadline 2025-02-04 00:00:00, planned delivery: 2025-03-17 00:00:00
->S02461(4022.683.44771): deadline 2025-02-18 00:00:00, planned delivery: 2025-03-16 00:00:00
->S02461(4022.622.61941): deadline 2025-02-18 00:00:00, planned delivery: 2025-03-18 00:00:00
->S02461(4022.684.31741): deadline 2025-02-18 00:00:00, planned delivery: 2025-03-15 00:00:00
->S02461(4022.684.31572): deadline 2025-02-18 00:00:00, planned delivery: 2025-03-16 00:00:00
->S02461(4022.622.61761): deadline 2025-02-18 00:00:00, planned delivery: 2025-03-18 00:00:00
->S02715(7302598): deadline 2025-03-07 00:00:00, planned delivery: 2025-03-16 00:00:00
->S02713(7280337): deadline 2025-03-10 00:00:00, planned delivery: 2025-03-16 00:00:00


☒ Raw Material

☐ Resource Capacity


Raw Materi...

STAAL S235JRC+C blank plat 30
Customer supplied material - [M.]
ALU 7075 T79511 hoekprofiel 20
STAAL S235JRC+C blank plat 40
STAAL S355J2C+C ngl plat 50x2
Ensaf-SBS zelfsn draadbus M6x
ALU 6082 T6 vk 70_[5601-0000-]
STAAL S235JRC+C blank plat 20
Tensioner Plate cutout_[5990-00]
ALU 6082 T6 vk 30_[5601-0000-]
S235JRC+C blank plat 40x10 (c

Step 6: Click a raw material in the list to see the target levels within planning horizon.



Step 7: Check Resource Capacity to see the list of resources and their capacity use plan.



Step 8: Click the resource in the list to see Capacity Use Plan within the Planning horizon.

