

The background of the entire image is a repeating pattern of various outdoor furniture items, including tables, chairs, and lounge chairs, rendered in a light gray color. The pattern is dense and covers the entire area.

PRODUCT CARE

STAINLESS STEEL FURNITURE //
TEAK FURNITURE // SUNBRELLA FABRIC
FABRIC CUSHION // TEXTILENE FABRIC

FABRIC CUSHION CARE // TEXTILENE FABRIC CARE

FABRIC CUSHION CARE

CLEANING & MAINTENANCE

1. Do not take the fabric off the cushion and do not wash in a washing machine.
2. Simply wash with soap. Do not use detergent.
3. Leave the fabric dry under shade and do not use heat for drying.
4. Do not dry-clean the Sunbrella fabric or put it in a drying machine.



Sunbrella fabrics will not support the growth of mildew, but dirt on the fabric will

promote mildew growth. Therefore, regular cleaning is needed. Cleaning is required less frequently in a dry environment. Also, if stubborn stain persists, use detergent or soap with chlorine to bleach the dirty spot.

HOW TO PREPARE FOR SUNBRELLA'S SPECIAL CLEANER

1. Mix 114 g (4 Oz) of detergent with chlorine mixture.
2. With 56 g (2 Oz) of soap.
3. And 4.5 L (1 Gallon) of water.
4. Brush with a non-abrasive brush.

5. Leave it in the cleaner for 20 minutes thus the fabric is soaked with the special cleaner.
6. Rinse thoroughly with clean water.
7. Leave it dry under shade. If the stain still persists, repeat the previous steps.
8. Dry-cleaning is not recommended for Sunbrella fabric.


TEXTILENE FABRIC CARE

CLEANING & MAINTENANCE

Stains on Textilene or Batyline fabric mostly come from dust and dirt, carried by winds or rains, or other common stains such as spilling of food and drink.

CLEANING TIPS


1. Regularly clean with a vacuum cleaner or a non-abrasive brush and never use a metal brush.
 2. Scrub with a soft brush or sponge and wash away with soap.
 3. Rinse thoroughly with clean water.
 4. Leave it dry completely outdoor.
- * DO NOT use strong detergent or sand paper for cleaning



RENEW TEAK FURNITURE WITH TEAK OIL




1. Put a sticky tape around the areas where do not require the teak oil, for example, stainless steel part. Then, sand brush wooden parts thoroughly with a sand paper.



2. Apply teak oil on a cloth or a soft brush, then wipe all over the furniture to create the full, rich surface sheen.



3. Wipe off the left over teak oil with a cloth.



4. Repeat No.2 and No.3 twice and sand brush the wooden surface again with a sand paper.



5. Apply teak oil for last time. Wipe off with a dry and clean cloth. Leave it dry for 15-20 mins.

STAINLESS STEEL FURNITURE CARE

CLEANING & MAINTENANCE

Stainless Steel is suitable for outdoor usage due to its resistant to extreme conditions. However, regular care is required to assure that stainless steel furniture is last longer in a good condition.

DO NOT leave stainless steel furniture where it could be contacted with sea or salt water directly such as on the beach or salt water pool.

Stainless Steel is easy to be cleaned. Wash off all stains with soap and rinse with clean water thoroughly. Dry the furniture completely then apply INOX CARE* to protect and keep the furniture shiny and resist fingerprint stains. Stainless Steel furniture needs to be cleaned at least once a month to help reducing dirt collection. Furniture placed by the seaside needs to be cleaned regularly (at least twice a month) to avoid collection of salt causing the stainless steel dull and corrosive, thus hard to maintain and clean in the long run.



STAINLESS STEEL CLEANING & MAINTENANCE TIPS

1. Wash the stainless steel parts with soap and water then dry it off with a cloth.
2. Spray INOX CARE* on a dry cloth and wipe over stainless steel surfaces.

Recommendation : Follow this instruction once a month for a normal condition and once a week for furniture placed by the seaside to keep the stainless steel shiny.

CLEANING TIPS FOR BROWN STAINS (CAUSED BY SALT FROM THE SEA) AND PERVERSIVE STAINS.

In case of stains which are hard to be removed by soap, it is recommended to:

1. Apply INOX CLEAN* or WENOL*, stainless steel scrubbing wash, with abrasive sponge (such as 3M scotch bright) and scrub the stains until disappeared.
2. Wash out with soap and water and dry with a cloth . By following these, you will renew your stainless steel furniture and make it shiny once again.

Caution :

- * **DO NOT** use any acid, chloride-based cleaners or Sodiumhydroxide with stainless steel furniture, for example, the bathroom cleaner.
- * **DO NOT** use metal brushes with stainless steel furniture. Only use a nylon material such as 3M scotch bright.
- * Ask kenkoon agent for the supply of INOX Care and Wenol.

TEAK FURNITURE CARE // SUNBRELLA FABRIC CARE

TEAK FURNITURE CARE

CLEANING & MAINTENANCE



Teak is regarded as one of the world's most precious woods these days. It could effectively resist in extreme environment and climate. With the combination of top-graded materials and sophisticated techniques from experienced carpenters, Teak is transformed to furniture which is very durable especially for outdoor.

STAINS REMOVAL

Normally, all stains that appear on teak wood will gradually disappear by themselves.

For immediate removal, please follow these

INSTRUCTIONS :

1. Simply wash the stains off with soap.
2. Scrub repeatedly with a non-abrasive brush or sponge.
3. Rinse the entire piece of furniture with clean water and leave it dry naturally.

CHANGE DUE TO WEATHERING TENDENCY (OUTDOOR USAGE)

Teak Outdoor Furniture will attain a gorgeous silvery-gray patina by approximately 3 months to 1 year depending on the amount of sunlight and rain exposure.

During weathering, a slight lifting of the grain may appear on the tops of furniture arms and legs which is normal for outdoor wood furniture to have expanding and contracting conditions and will not effect or minimize the durability / quality of the furniture.

Regular cleaning should be done by washing with soft brush or sponge. Another care option is to use teak oil which keeps a color of the woods last longer.

SUNBRELLA FABRIC CARE

CLEANING & MAINTENANCE

One of the best ways to keep Sunbrella Fabric (cushion or parasol fabric) beautiful and long-lasting is to spray and wash them with clean water once a month. This tip helps avoiding dirt penetrated deeply, thus easier to be cleaned in the future. Importantly, Sunbrella is a type of fabric that needs to be cleaned regularly for its durability and beauty.



CLEANING TIPS

1. Brush off dust and dirt.
2. Wash afterwards with clean water.
3. Prepare a cleaning mixture of water and mild soap (do not use detergent).
4. Apply the cleaning mixture on a non-abrasive brush and wipe it all over the fabric.
5. Leave it for a while until the fabrics fully soaked with soap.
6. Rinse thoroughly with clean water.
7. Leave the fabric dry under shade and never apply heat to dry Sunbrella fabrics.