


SW2 is shared by pin43 and pin0.  
Hold SW2 and push Reset on M5Capsule to enter StampS3 into boot loader mode.

Released under the Creative Commons  
Attribution Share-Alike 4.0 License  
<https://creativecommons.org/licenses/by-sa/4.0/>

TITLE: M5capsule 2btn_ALLwire		REV: 2
	Company:	Sheet: 1/1
	Date: 2023-11-14	Drawn By: NANANA (@nananauno)