

# Installation Instructions

## Insulation Pack

1. Open and lay out the single window insulation pack. The Velcro edge of the window flap is the top, the stitched edge of the window flap is the bottom.
2. Install single window insulation pack in the back and next repeat in the front:
  - a. Remove fabric bungees from the back side of the lifting arms by sliding the loops sideways off of the steel hooks.
  - b. Attach the center of the single window insulation pack to the top and bottom velcro.
  - c. Attach and smooth out the top & bottom velcro from the center to the left and right. During this process ensure that the window flap is aligned & centered on the exterior window.
    - Check alignment by opening the fold down insulation pack window flap and inspecting for alignment of the insulation pack on the exterior window. Then close the insulation pack window flap.
    - Further check alignment by ensuring that the fabric bungees are aligned with the buttonhole style slots
    - If it is not aligned, remove the insulation pack and recenter.
  - d. Slide the ends of the insulation pack behind the lifting arms and complete full velcro attachment along the top and bottom of the entire single window insulation pack.
  - e. Pass fabric bungees through buttonhole style slots & reattach them to the steel hooks on the back side of the lifting arms
3. Install double window insulation packs on both sides after the front and back single window insulation packs have been completely installed.
  - a. Find the center of the double window insulation pack and attach the top & bottom velcro between the exterior windows.
  - b. Attach and smooth out the top & bottom velcro from the center to the left and right. Go past the exterior windows.
    - Check for alignment by opening the fold down insulation pack window flap and inspecting for alignment of the insulation pack on the exterior window. Then close the insulation pack window flap.
    - Further check alignment by ensuring that the fabric bungees pass through the buttonhole style slots and are able to be hooked on the external fabric loops.
    - If it is not aligned, remove the insulation pack and recenter.
  - c. Complete velcro attachment at the top and bottom and along the edges.
4. Test close & open: If your camper has trouble closing with the insulation pack fully attached you may have to remove the upper velcro of the insulation pack along the sides during roof closure.
5. Complete: You are ready to enjoy some warmer camping in the winter and improved heat control in the summer.

# Trimming

The insulation pack is designed to fit with multiple camper sizes. Therefore it may be a little long in your specific circumstance. If you would like to cut your insulation pack down to size a bit for better fitment and less material overlap you can. It is designed to be cut along the vertical velcro strips.

1. You will need some sharp scissors.
2. First install the Insulation Pack and get everything lined up perfectly.
3. Find where the velcro attaches the panels together.
  - a. Any velcro that is past the overlap and not engaged can be trimmed off.
  - b. Double check you marked in the correct spot. Do not trim off the velcro strips that are in contact and mating together at the seam.
  - c. Mark that point and peel the insulation back.
4. Cut along the velcro about ¼ inch from the edge of the velcro on the gray insulating fabric.
5. There may be a bit of fraying near that edge after prolonged use, but the cut will be hidden behind the panel and the stitch line on the velcro will keep any frays from propagating.
6. Tuck everything back together and enjoy.