

Bluetooth USB Adapter

Quick Start Guide

Version 4.2

© All rights reserved.

All trade names are registered trademarks of respective manufacturers listed.

The Bluetooth name and the Bluetooth trademarks are owned by Bluetooth SIG, Inc.

This manual may not be copied in any media or form without the written consent of original
maker.

TABLE OF CONTENTS

WELCOME	3
Features	3
System Requirements	3
Before You Start	3
Install Driver in Windows Vista 7 / 8	4

WELCOME

Thank you for your purchase of the Bluetooth USB Adapter. Featuring Bluetooth wireless technology, Bluetooth USB Adapter creates cable-free connections between your PCs and other Bluetooth devices. Bluetooth USB Adapter supports Bluetooth 4.0 standard and is compatible with all Bluetooth certified devices.

Features

Compliant with Bluetooth standard version 4.0.

Support for Microsoft Windows Vista 7 / 8.

Easy operation and setting up.

System requirements

Processor: Intel Celeron / Pentium III, IV; AMD Duron / Athlon

Operating System: Microsoft Windows 7 and 8.

System memory: 64MB at least

Hard Drive Free Space: 250MB

Before you start

Please remove any previous version of Bluetooth software existing in your system.

The remove procedures are as follows:

Step 1: Click Start/Settings, then select Control Panel.

Step 2: In the Control Panel window, double click Add/Remove

programs icon. Step 3: Find out the WIDCOMM or other Bluetooth Software then remove it.

Install Driver in Windows 7 / 8

The following steps tell you how to install the WIDCOMM Bluetooth driver in Windows Vista 7 / 8. Other Windows OS is similar procedures as Windows Vista 7 / 8 installations below.

Step 1:

Put WIDCOMM Driver CD into CD drive of your PC, an auto-installation program will start to guide you to complete the installation step by step.




Step 2:

Please click Yes to continue installation.



Step 2:

Installation program will remind you to plug in the Bluetooth USB Adapter if you don't put it into your PC.



This dialog box will not pop up if you already have Bluetooth USB Adapter in your PC.

Step 3:

Click **Agree and Install Bluetooth Software** to continue.



Step 4:

Please plug your Bluetooth adapter and then it will install.



Step 5:

Welcome to install Bluetooth stack.



Step 6:

Installation Completed.

