

← USB A-B cable  
to USB port  
on host computer

Acroname  
USB-to-Serial  
Connector

Serial  
extension  
cable

PXA-AVR  
UART  
jumper

5V power adapter  
to power outlet →

MMC  
Card

basix + robostix

Bluetooth antenna

