








# Magicc\_3 Solenoid control box electrical. 2017-07-03



Note: Pin 3 on the XLR connector is connected to ground so external manual switches can be used where needed.



# Magicc\_3 Solenoid control box electrical. 2017-07-03

