


Max input voltage is 28V!

Power input has a protection
for reverse polarity

Attention!
Logic level for RS232 is 3.3V



SJ1: Z = VDD MT6701CT
Z = GND AS5600

For programming ESP-12 use a short cut
between GND and PRG and switch power on

(C) Norbert Walter



TITLE: Wind Sensor Yachta V2.1		REV: 2.1
	Company: Open Boat Projects	Sheet: 1/1
	Date: 2023-05-10	Drawn By: norbert-walter