



RD-800

Sound List

Contents

Tone List	3
CONCERT	3
STUDIO	3
VINTAGE	3
MODERN	4
CLAV	4
ORGAN	5
STRINGS	6
PAD/CHOIR	7
BASS	8
OTHER	10

Live Set List	15
A	15
B	15
C	15
D	15
E	16
F	16
G	16
H	16
I	17
J	17

Rhythm Pattern List	18
----------------------------------	-----------

Rhythm Set List	20
------------------------------	-----------

Tone List

CONCERT

No.	Name	Category	MSB	LSB	PC
0001	Concert Grand (*1)	CONCERT PIANO	84	0	1
0002	Bright Concert (*1)	CONCERT PIANO	84	0	2
0003	Mellow Concert (*1)	CONCERT PIANO	84	0	3
0004	Rock Concert Grd (*1)	CONCERT PIANO	84	0	4
0005	Comp ConcertGrd (*1)	CONCERT PIANO	84	0	5
0006	Concert Grd Mono (*1)	CONCERT PIANO	84	0	6
0007	NX Concert Grand (*1)	CONCERT PIANO	84	0	7
0008	Bright NX Concrtr (*1)	CONCERT PIANO	84	0	8
0009	Mellow NX Concrtr (*1)	CONCERT PIANO	84	0	9
0010	Rock NX Concert (*1)	CONCERT PIANO	84	0	10
0011	Comp NX Concert (*1)	CONCERT PIANO	84	0	11
0012	NX Concert Mono (*1)	CONCERT PIANO	84	0	12
0013	Brilliant Grand (*1)	CONCERT PIANO	84	0	13
0014	Hard Brill Grand (*1)	CONCERT PIANO	84	0	14
0015	Soft Brill Grand (*1)	CONCERT PIANO	84	0	15
0016	Rock Brill Grand (*1)	CONCERT PIANO	84	0	16
0017	Comp Brill Grand (*1)	CONCERT PIANO	84	0	17
0018	Brill Grand Mono (*1)	CONCERT PIANO	84	0	18
0019	St.Piano 1	CONCERT PIANO	84	0	19
0020	St.Piano 2	CONCERT PIANO	84	0	20
0021	St.Piano 3	CONCERT PIANO	84	0	21
0022	St.Piano 4	CONCERT PIANO	84	0	22
0023	St.Piano 5	CONCERT PIANO	84	0	23
0024	Piano 1	CONCERT PIANO	84	0	24
0025	Piano 1 w	CONCERT PIANO	84	0	25
0026	European Pf	CONCERT PIANO	84	0	26
0027	Stage Piano	CONCERT PIANO	84	0	27

*1 Piano Designer, Individual Note Voicing, and Sympathetic Resonance parameters can be edited for these tones.

STUDIO

No.	Name	Category	MSB	LSB	PC
0028	Upright Piano (*1)	STUDIO PIANO	84	0	28
0029	Bright Upright (*1)	STUDIO PIANO	84	0	29
0030	Mellow Upright (*1)	STUDIO PIANO	84	0	30
0031	Rock Upright Pno (*1)	STUDIO PIANO	84	0	31
0032	Comp Upright Pno (*1)	STUDIO PIANO	84	0	32
0033	UprightPianoMono (*1)	STUDIO PIANO	84	0	33
0034	Studio Grand (*1)	STUDIO PIANO	84	0	34
0035	Bright Studio (*1)	STUDIO PIANO	84	0	35
0036	Mellow Studio (*1)	STUDIO PIANO	84	0	36
0037	Rock StudioGrand (*1)	STUDIO PIANO	84	0	37
0038	Comp Studio Grd (*1)	STUDIO PIANO	84	0	38
0039	StudioGrand Mono (*1)	STUDIO PIANO	84	0	39
0040	Piano 2	STUDIO PIANO	84	0	40
0041	Piano 2 w	STUDIO PIANO	84	0	41
0042	Honky-tonk Pno 1 (*1)	HONKY-TONK	84	0	42
0043	Honky-tonk Pno 2 (*1)	HONKY-TONK	84	0	43

No.	Name	Category	MSB	LSB	PC
0044	Honky-tonk Pno 3 (*1)	HONKY-TONK	84	0	44
0045	Honky-tonk Pno 4 (*1)	HONKY-TONK	84	0	45
0046	Honky Tonk	HONKY-TONK	84	0	46
0047	Honky-tonk	HONKY-TONK	84	0	47
0048	Honky-tonk w	HONKY-TONK	84	0	48
0049	SA Piano (*3)	SA PIANO	84	0	49
0050	Modulated SA Pno (*3)	SA PIANO	84	0	50
0051	Bright SA Piano (*3)	SA PIANO	84	0	51
0052	Comp SA Piano (*3)	SA PIANO	84	0	52
0053	Phaser SA Piano (*3)	SA PIANO	84	0	53
0054	Lo-Fi SA Piano (*3)	SA PIANO	84	0	54
0055	JD Piano	SYNTH PIANO	84	0	55
0056	Bright JD Piano	SYNTH PIANO	84	0	56
0057	Rock JD Piano	SYNTH PIANO	84	0	57
0058	Comp JD Piano	SYNTH PIANO	84	0	58
0059	Comp JD Piano2	SYNTH PIANO	84	0	59
0060	Detuned JD Piano	SYNTH PIANO	84	0	60
0061	Chorus JD Piano	SYNTH PIANO	84	0	61
0062	Phaser JD Piano	SYNTH PIANO	84	0	62
0063	Lo-Fi JD Piano	SYNTH PIANO	84	0	63
0064	Brite Piano	SYNTH PIANO	84	0	64
0065	Pop Piano 1	SYNTH PIANO	84	0	65
0066	Pop Piano 2	SYNTH PIANO	84	0	66
0067	Pop Piano 3	SYNTH PIANO	84	0	67
0068	LoFi Piano	SYNTH PIANO	84	0	68

*1 Piano Designer, Individual Note Voicing, and Sympathetic Resonance parameters can be edited for these tones.

*3 Some parameters of "Detailed settings for E. Piano tones (Owner's Manual p. 33)" are shown in the Tone Designer screen.

VINTAGE

No.	Name	Category	MSB	LSB	PC
0069	Tine E.Piano (*2)	TINE E.PIANO	84	0	69
0070	Silver Top EP (*2)	TINE E.PIANO	84	0	70
0071	Tine EP Mkl (*2)	TINE E.PIANO	84	0	71
0072	Tine EP MkII (*2)	TINE E.PIANO	84	0	72
0073	Dyno E.Piano (*2)	TINE E.PIANO	84	0	73
0074	Small Case Tine (*2)	TINE E.PIANO	84	0	74
0075	Soft Tine EP (*2)	TINE E.PIANO	84	0	75
0076	Chorus Tine EP (*2)	TINE E.PIANO	84	0	76
0077	Chorus Tine EP2 (*2)	TINE E.PIANO	84	0	77
0078	Chorus Dyno EP (*2)	TINE E.PIANO	84	0	78
0079	Tremolo Cho Tine (*2)	TINE E.PIANO	84	0	79
0080	Phaser Tine EP (*2)	TINE E.PIANO	84	0	80
0081	Phaser Dyno EP (*2)	TINE E.PIANO	84	0	81
0082	Trem Phaser Tine (*2)	TINE E.PIANO	84	0	82
0083	Trem Phaser Dyno (*2)	TINE E.PIANO	84	0	83
0084	Rotary Tine EP (*2)	TINE E.PIANO	84	0	84
0085	TouchWah TineEP (*2)	TINE E.PIANO	84	0	85
0086	Auto Wah Tine EP (*2)	TINE E.PIANO	84	0	86
0087	Echo Tine EP (*2)	TINE E.PIANO	84	0	87

Tone List

No.	Name	Category	MSB	LSB	PC
0088	Echo->Trem Tine (*2)	TINE E.PIANO	84	0	88
0089	Echo->RotaryTine (*2)	TINE E.PIANO	84	0	89
0090	Comp Tine EP (*2)	TINE E.PIANO	84	0	90
0091	Comp Tine EP2 (*2)	TINE E.PIANO	84	0	91
0092	Comp Silver Top (*2)	TINE E.PIANO	84	0	92
0093	Driven Tine EP (*2)	TINE E.PIANO	84	0	93
0094	Driven SilverTop (*2)	TINE E.PIANO	84	0	94
0095	Stage EP 1	TINE E.PIANO	84	0	95
0096	Stage EP 2	TINE E.PIANO	84	0	96
0097	Stage EP Trm	TINE E.PIANO	84	0	97
0098	Tremolo EP 1	TINE E.PIANO	84	0	98
0099	E.Piano 3	TINE E.PIANO	84	0	99
0100	E.Piano 4	TINE E.PIANO	84	0	100
0101	E.Piano 5	TINE E.PIANO	84	0	101
0102	E.Piano 6	TINE E.PIANO	84	0	102
0103	E.Piano 7	TINE E.PIANO	84	0	103
0104	E.Piano 8	TINE E.PIANO	84	0	104
0105	Dyno EP	TINE E.PIANO	84	0	105
0106	Dyno EP Trm	TINE E.PIANO	84	0	106
0107	Tremolo EP 2	TINE E.PIANO	84	0	107
0108	Back2the60s	TINE E.PIANO	84	0	108
0109	Tine EP	TINE E.PIANO	84	0	109
0110	E.Piano 1	TINE E.PIANO	84	0	110
0111	St.Soft EP	TINE E.PIANO	84	0	111
0112	Reed E.Piano (*2)	REED E.PIANO	84	0	112
0113	Round Reed EP (*2)	REED E.PIANO	84	0	113
0114	Driven Reed EP (*2)	REED E.PIANO	84	0	114
0115	Driven Reed EP2 (*2)	REED E.PIANO	84	0	115
0116	Comp Reed EP (*2)	REED E.PIANO	84	0	116
0117	Comp Reed EP2 (*2)	REED E.PIANO	84	0	117
0118	Rotary Reed EP (*2)	REED E.PIANO	84	0	118
0119	Tremolo Reed EP (*2)	REED E.PIANO	84	0	119
0120	Chorus Reed EP (*2)	REED E.PIANO	84	0	120
0121	Phaser Reed EP (*2)	REED E.PIANO	84	0	121
0122	Echo Reed EP (*2)	REED E.PIANO	84	0	122
0123	Echo->Trem Reed (*2)	REED E.PIANO	84	0	123
0124	TouchWah ReedEP (*2)	REED E.PIANO	84	0	124
0125	AutoWah Reed EP (*2)	REED E.PIANO	84	0	125
0126	Pnet Tee	REED E.PIANO	84	0	126
0127	R&B Pnet	REED E.PIANO	84	0	127
0128	Wurly EP	REED E.PIANO	84	0	128
0129	Wurly EP Trm	REED E.PIANO	84	1	1
0130	Curly Wurly	REED E.PIANO	84	1	2
0131	Super Wurly	REED E.PIANO	84	1	3
0132	Wurly	REED E.PIANO	84	1	4
0133	E.Grand 1	E.GRAND	84	1	5
0134	E.Grand 2	E.GRAND	84	1	6
0135	E.Grand 3	E.GRAND	84	1	7
0136	Piano 3	E.GRAND	84	1	8
0137	Piano 3 w	E.GRAND	84	1	9

*2 The parameters of "Detailed settings for E. Piano tone (Owner's Manual p. 33)" are shown in the Tone Designer screen.

MODERN

No.	Name	Category	MSB	LSB	PC
0138	SA E.Piano (*3)	SA E.PIANO	84	1	10
0139	SA E.Piano2 (*3)	SA E.PIANO	84	1	11
0140	SA E.Piano3 (*3)	SA E.PIANO	84	1	12
0141	SA E.Piano4 (*3)	SA E.PIANO	84	1	13
0142	SA E.Piano5 (*3)	SA E.PIANO	84	1	14
0143	SA EP 1	SA E.PIANO	84	1	15
0144	SA EP 2	SA E.PIANO	84	1	16
0145	Psy EP	SA E.PIANO	84	1	17
0146	FM E.Piano (*3)	FM E.PIANO	84	1	18
0147	Woody FM E.Piano (*3)	FM E.PIANO	84	1	19
0148	Bright FM EP (*3)	FM E.PIANO	84	1	20
0149	Detuned FM EP (*3)	FM E.PIANO	84	1	21
0150	Tremolo FM EP (*3)	FM E.PIANO	84	1	22
0151	EP Legend 3	FM E.PIANO	84	1	23
0152	80's EP	FM E.PIANO	84	1	24
0153	FM EP 1	FM E.PIANO	84	1	25
0154	FM EP 2	FM E.PIANO	84	1	26
0155	Hit EP	MODERN E.PIANO	84	1	27
0156	EP Legend 1	MODERN E.PIANO	84	1	28
0157	EP Belle	MODERN E.PIANO	84	1	29
0158	Sinus EP	MODERN E.PIANO	84	1	30
0159	Spirit Tines	MODERN E.PIANO	84	1	31
0160	E.Piano 2	MODERN E.PIANO	84	1	32
0161	Detuned EP	MODERN E.PIANO	84	1	33
0162	St.FM EP	MODERN E.PIANO	84	1	34
0163	EP Legend 2	MODERN E.PIANO	84	1	35
0164	EP Phase	MODERN E.PIANO	84	1	36
0165	Rox Piano 1	MODERN E.PIANO	84	1	37
0166	Rox Piano 2	MODERN E.PIANO	84	1	38
0167	Crummy Piano	MODERN E.PIANO	84	1	39
0168	Rox Lute	MODERN E.PIANO	84	1	40

*3 Some parameters of "Detailed settings for E. Piano tones (Owner's Manual p. 33)" are shown in the Tone Designer screen.

CLAV

No.	Name	Category	MSB	LSB	PC
0169	Clav CB (*4)	CLAV	84	1	41
0170	Clav CA (*4)	CLAV	84	1	42
0171	Phaser Clav (*4)	CLAV	84	1	43
0172	Phaser Clav2 (*4)	CLAV	84	1	44
0173	Touch Wah Clav (*4)	CLAV	84	1	45
0174	Auto Wah Clav (*4)	CLAV	84	1	46
0175	Auto Wah Clav2 (*4)	CLAV	84	1	47
0176	Comp Clav (*4)	CLAV	84	1	48
0177	Comp Clav2 (*4)	CLAV	84	1	49
0178	Chorus Clav (*4)	CLAV	84	1	50
0179	Chorus Clav2 (*4)	CLAV	84	1	51
0180	Chorus Clav3 (*4)	CLAV	84	1	52

No.	Name	Category	MSB	LSB	PC
0181	Driven Clav (*4)	CLAV	84	1	53
0182	Driven Clav2 (*4)	CLAV	84	1	54
0183	Clav CB Medium (*4)	CLAV	84	1	55
0184	Clav CA Medium (*4)	CLAV	84	1	56
0185	Clav CB Brillia (*4)	CLAV	84	1	57
0186	Clav CA Brillia (*4)	CLAV	84	1	58
0187	Clav CB Combo (*4)	CLAV	84	1	59
0188	Clav CA Combo (*4)	CLAV	84	1	60
0189	Clav	CLAV	84	1	61
0190	Clav 2	CLAV	84	1	62
0191	Pulse Clav	CLAV	84	1	63
0192	Pulse Clav 2	CLAV	84	1	64
0193	Sweepin Clav	CLAV	84	1	65
0194	Analog Clav	CLAV	84	1	66
0195	Biting Clav	CLAV	84	1	67
0196	Pulse Clv St	CLAV	84	1	68
0197	Natural Hps.	HARPSICHORD	84	1	69
0198	Harpsichord	HARPSICHORD	84	1	70
0199	Harpsichord2	HARPSICHORD	84	1	71
0200	Coupled Hps	HARPSICHORD	84	1	72
0201	Harpsi w	HARPSICHORD	84	1	73
0202	Harpsi o	HARPSICHORD	84	1	74
0203	Rox Harpsi	HARPSICHORD	84	1	75
0204	VX Harpsi	HARPSICHORD	84	1	76
0205	Celesta	CELESTA	84	1	77
0206	Farf Celeste	CELESTA	84	1	78
0207	Music Box	BELL	84	1	79
0208	Music Box 2	BELL	84	1	80
0209	Kalimbells	BELL	84	1	81
0210	D50 Fantasy	BELL	84	1	82
0211	D50 Bell	BELL	84	1	83
0212	Fantasia	BELL	84	1	84
0213	Org Bell	BELL	84	1	85
0214	Dreambell	BELL	84	1	86
0215	FM Sparkles	BELL	84	1	87
0216	FM Syn Bell	BELL	84	1	88
0217	FM Heaven	BELL	84	1	89
0218	Dreaming Bel	BELL	84	1	90
0219	Analog Bell	BELL	84	1	91
0220	Music Bells	BELL	84	1	92
0221	Bell 1	BELL	84	1	93
0222	Bell 2	BELL	84	1	94
0223	Crystal	BELL	84	1	95
0224	Tinkle Bell	BELL	84	1	96
0225	Icy Keys	BELL	84	1	97
0226	TubularBells	BELL	84	1	98
0227	TubularBell2	BELL	84	1	99
0228	Church Bell	BELL	84	1	100
0229	Carillon	BELL	84	1	101
0230	Carillon 2	BELL	84	1	102
0231	Tower Bell	BELL	84	1	103
0232	Bell Ring	BELL	84	1	104
0233	Vibraphone	MALLET	84	1	105

No.	Name	Category	MSB	LSB	PC
0234	Vibraphone 2	MALLET	84	1	106
0235	VibraphoneTr	MALLET	84	1	107
0236	Vibraphone w	MALLET	84	1	108
0237	Tremolo Vib	MALLET	84	1	109
0238	Jazz Vib	MALLET	84	1	110
0239	Marimba	MALLET	84	1	111
0240	Marimba 2	MALLET	84	1	112
0241	Marimba 3	MALLET	84	1	113
0242	Marimba w	MALLET	84	1	114
0243	BsMarimba 1	MALLET	84	1	115
0244	BsMarimba 2	MALLET	84	1	116
0245	Xylophone	MALLET	84	1	117
0246	Xylophone 2	MALLET	84	1	118
0247	Xylophone 3	MALLET	84	1	119
0248	Ethno Keys	MALLET	84	1	120
0249	Glockenspiel	MALLET	84	1	121
0250	Steel Drums	MALLET	84	1	122
0251	Steel Drums2	MALLET	84	1	123
0252	Soft StIDrm	MALLET	84	1	124
0253	Toy Box	MALLET	84	1	125
0254	Sine Mallet	MALLET	84	1	126

*4 The parameters of "Detailed settings for Clav sounds (owner's manual p. 33)" are shown in the Tone Designer screen.

ORGAN

No.	Name	Category	MSB	LSB	PC
0255	TW-Organ 1	E.ORGAN	84	1	127
0256	TW-Organ 2	E.ORGAN	84	1	128
0257	TW-Organ 3	E.ORGAN	84	2	1
0258	TW-Organ 4	E.ORGAN	84	2	2
0259	TW-Organ 5	E.ORGAN	84	2	3
0260	TW-Organ 6	E.ORGAN	84	2	4
0261	TW-Organ 7	E.ORGAN	84	2	5
0262	TW-Organ 8	E.ORGAN	84	2	6
0263	TW-Organ 9	E.ORGAN	84	2	7
0264	TW-Organ 10	E.ORGAN	84	2	8
0265	Rock Organ 1	E.ORGAN	84	2	9
0266	Rock Organ 2	E.ORGAN	84	2	10
0267	Rock Organ 3	E.ORGAN	84	2	11
0268	Rock Organ 4	E.ORGAN	84	2	12
0269	Rock Organ 5	E.ORGAN	84	2	13
0270	RotaryOrgan1	E.ORGAN	84	2	14
0271	RotaryOrgan2	E.ORGAN	84	2	15
0272	Perc. Organ	E.ORGAN	84	2	16
0273	Perc.Organ 2	E.ORGAN	84	2	17
0274	Perc.Organ 3	E.ORGAN	84	2	18
0275	Perc.Organ 4	E.ORGAN	84	2	19
0276	Organ 1	E.ORGAN	84	2	20
0277	Trem. Organ	E.ORGAN	84	2	21
0278	Organ 2	E.ORGAN	84	2	22
0279	Chorus Organ	E.ORGAN	84	2	23

Tone List

No.	Name	Category	MSB	LSB	PC
0280	Organ 3	E.ORGAN	84	2	24
0281	Animal Mod	E.ORGAN	84	2	25
0282	Rising Sun	E.ORGAN	84	2	26
0283	Surf Monkeys	E.ORGAN	84	2	27
0284	Palisades	E.ORGAN	84	2	28
0285	Kitchen Soul	E.ORGAN	84	2	29
0286	BreakOnThru	E.ORGAN	84	2	30
0287	Calif.Sun	E.ORGAN	84	2	31
0288	Steppin' VX	E.ORGAN	84	2	32
0289	Costello+Mod	E.ORGAN	84	2	33
0290	Archie's Mod	E.ORGAN	84	2	34
0291	Telstar VX	E.ORGAN	84	2	35
0292	The Sham	E.ORGAN	84	2	36
0293	Crummy Organ	E.ORGAN	84	2	37
0294	VX Religion	E.ORGAN	84	2	38
0295	Farfi Combo	E.ORGAN	84	2	39
0296	Iron Farf	E.ORGAN	84	2	40
0297	Dancin' Queen	E.ORGAN	84	2	41
0298	Farf Lite	E.ORGAN	84	2	42
0299	Wooly Farfy	E.ORGAN	84	2	43
0300	Clark Farf	E.ORGAN	84	2	44
0301	Pacemaker	E.ORGAN	84	2	45
0302	Rox Organ P	E.ORGAN	84	2	46
0303	Rox Organ Ph	E.ORGAN	84	2	47
0304	Rox Organ PH	E.ORGAN	84	2	48
0305	Rox Organ L	E.ORGAN	84	2	49
0306	60's Organ	E.ORGAN	84	2	50
0307	70's E.Org 1	E.ORGAN	84	2	51
0308	70's E.Org 2	E.ORGAN	84	2	52
0309	70's E.Organ	E.ORGAN	84	2	53
0310	E.Organ 1	E.ORGAN	84	2	54
0311	E.Organ 2	E.ORGAN	84	2	55
0312	E.Organ 3	E.ORGAN	84	2	56
0313	E.Organ 4	E.ORGAN	84	2	57
0314	E.Organ 5	E.ORGAN	84	2	58
0315	E.Organ 6	E.ORGAN	84	2	59
0316	E.Organ 7	E.ORGAN	84	2	60
0317	Theater Org	E.ORGAN	84	2	61
0318	Ana Organ 1	E.ORGAN	84	2	62
0319	Ana Organ 2	E.ORGAN	84	2	63
0320	Ana Organ 3	E.ORGAN	84	2	64
0321	Ana Organ 4	E.ORGAN	84	2	65
0322	Ana Organ 5	E.ORGAN	84	2	66
0323	Puff Organ	PIPE ORGAN	84	2	67
0324	Nason Flute	PIPE ORGAN	84	2	68
0325	Massive Pipe	PIPE ORGAN	84	2	69
0326	Mid Pipe Org	PIPE ORGAN	84	2	70
0327	Grand Pipes	PIPE ORGAN	84	2	71
0328	Church Org 1	PIPE ORGAN	84	2	72
0329	Church Org 2	PIPE ORGAN	84	2	73
0330	Church Org 3	PIPE ORGAN	84	2	74
0331	Reed Organ	PIPE ORGAN	84	2	75
0332	Accordion Fr	ACCORDION	84	2	76

No.	Name	Category	MSB	LSB	PC
0333	Accordion It	ACCORDION	84	2	77
0334	AccordionIt2	ACCORDION	84	2	78
0335	Musette	ACCORDION	84	2	79
0336	Vodkakordion	ACCORDION	84	2	80
0337	Bandoneon	ACCORDION	84	2	81
0338	Harmonica	HARMONICA	84	2	82
0339	Harmonica 2	HARMONICA	84	2	83

STRINGS

No.	Name	Category	MSB	LSB	PC
0340	Slow FullStrings	ENSEMBLE STRINGS	84	2	84
0341	Full Strings	ENSEMBLE STRINGS	84	2	85
0342	GX Strings	ENSEMBLE STRINGS	84	2	86
0343	Mood Strings	ENSEMBLE STRINGS	84	2	87
0344	Slow Strings	ENSEMBLE STRINGS	84	2	88
0345	DecayStrings	ENSEMBLE STRINGS	84	2	89
0346	Strings	ENSEMBLE STRINGS	84	2	90
0347	Strings 2	ENSEMBLE STRINGS	84	2	91
0348	Strings 3	ENSEMBLE STRINGS	84	2	92
0349	Strings 4	ENSEMBLE STRINGS	84	2	93
0350	Strings 5	ENSEMBLE STRINGS	84	2	94
0351	Strings 6	ENSEMBLE STRINGS	84	2	95
0352	Stage Str 1	ENSEMBLE STRINGS	84	2	96
0353	Stage Str 2	ENSEMBLE STRINGS	84	2	97
0354	Pop Str	ENSEMBLE STRINGS	84	2	98
0355	Hall Strings	ENSEMBLE STRINGS	84	2	99
0356	Marc.Str	ENSEMBLE STRINGS	84	2	100
0357	StringsStacc	ENSEMBLE STRINGS	84	2	101
0358	Oct Strings	ENSEMBLE STRINGS	84	2	102
0359	Tremolo Str	ENSEMBLE STRINGS	84	2	103
0360	Tron Strings	ENSEMBLE STRINGS	84	2	104
0361	Tron Strings2	ENSEMBLE STRINGS	84	2	105
0362	Symphonic Tron	ENSEMBLE STRINGS	84	2	106
0363	Moody Tron	ENSEMBLE STRINGS	84	2	107
0364	TapeStrings1	ENSEMBLE STRINGS	84	2	108
0365	TapeStrings2	ENSEMBLE STRINGS	84	2	109
0366	Hybrid Str	ENSEMBLE STRINGS	84	2	110
0367	PizzicatoStr	ENSEMBLE STRINGS	84	2	111
0368	Pizz 1	ENSEMBLE STRINGS	84	2	112
0369	Pizz 2	ENSEMBLE STRINGS	84	2	113
0370	Violin	SOLO STRINGS	84	2	114
0371	Violin 2	SOLO STRINGS	84	2	115
0372	Slow Violin	SOLO STRINGS	84	2	116
0373	Bright Vln	SOLO STRINGS	84	2	117
0374	Viola	SOLO STRINGS	84	2	118
0375	Cello	SOLO STRINGS	84	2	119
0376	Bright Vc	SOLO STRINGS	84	2	120
0377	Contrabass	SOLO STRINGS	84	2	121
0378	Fiddle	SOLO STRINGS	84	2	122
0379	Tron Violins	SOLO STRINGS	84	2	123

No.	Name	Category	MSB	LSB	PC
0380	Tron Cello	SOLO STRINGS	84	2	124
0381	Orchestra	ORCHESTRAL	84	2	125
0382	Orc.Unison 1	ORCHESTRAL	84	2	126
0383	Orc.Unison 2	ORCHESTRAL	84	2	127
0384	Full Orc	ORCHESTRAL	84	2	128

PAD/CHOIR

No.	Name	Category	MSB	LSB	PC
0385	Wide Soft Pad	SYNTH PAD/STR	84	3	1
0386	Silky Way	SYNTH PAD/STR	84	3	2
0387	CalmChoirPad	SYNTH PAD/STR	84	3	3
0388	Decay Choir Pad	SYNTH PAD/STR	84	3	4
0389	Soft Pad 1	SYNTH PAD/STR	84	3	5
0390	Soft Pad 2	SYNTH PAD/STR	84	3	6
0391	Soft Pad 3	SYNTH PAD/STR	84	3	7
0392	Soft Pad 4	SYNTH PAD/STR	84	3	8
0393	Soft Pad 5	SYNTH PAD/STR	84	3	9
0394	Soft Pad 6	SYNTH PAD/STR	84	3	10
0395	Soft Pad 7	SYNTH PAD/STR	84	3	11
0396	Soft Pad 8	SYNTH PAD/STR	84	3	12
0397	Soft Pad 9	SYNTH PAD/STR	84	3	13
0398	Soft Pad 10	SYNTH PAD/STR	84	3	14
0399	Dreamheaven	SYNTH PAD/STR	84	3	15
0400	Oct Heaven	SYNTH PAD/STR	84	3	16
0401	VintageStr 1	SYNTH PAD/STR	84	3	17
0402	VintageStr 2	SYNTH PAD/STR	84	3	18
0403	VintageStr 3	SYNTH PAD/STR	84	3	19
0404	VintageStr 4	SYNTH PAD/STR	84	3	20
0405	VintageStr 5	SYNTH PAD/STR	84	3	21
0406	VintageStr 6	SYNTH PAD/STR	84	3	22
0407	VintageStr 7	SYNTH PAD/STR	84	3	23
0408	JX Strings	SYNTH PAD/STR	84	3	24
0409	JP Strings 1	SYNTH PAD/STR	84	3	25
0410	JP Strings 2	SYNTH PAD/STR	84	3	26
0411	106 Strings	SYNTH PAD/STR	84	3	27
0412	Sol Strings	SYNTH PAD/STR	84	3	28
0413	Rhapsody STR	SYNTH PAD/STR	84	3	29
0414	PWM Str 1	SYNTH PAD/STR	84	3	30
0415	PWM Str 2	SYNTH PAD/STR	84	3	31
0416	PWM Str 3	SYNTH PAD/STR	84	3	32
0417	Fading Str	SYNTH PAD/STR	84	3	33
0418	ParadisePad	SYNTH PAD/STR	84	3	34
0419	80s Strings	SYNTH PAD/STR	84	3	35
0420	Stringship	SYNTH PAD/STR	84	3	36
0421	Airy Pad	SYNTH PAD/STR	84	3	37
0422	Neo RS-202	SYNTH PAD/STR	84	3	38
0423	Sawtooth Str	SYNTH PAD/STR	84	3	39
0424	Syn.Strings1	SYNTH PAD/STR	84	3	40
0425	Syn.Strings2	SYNTH PAD/STR	84	3	41
0426	Syn.Strings3	SYNTH PAD/STR	84	3	42

No.	Name	Category	MSB	LSB	PC
0427	Pulse Pad	SYNTH PAD/STR	84	3	43
0428	Hollow Pad 1	SYNTH PAD/STR	84	3	44
0429	WarmHeaven 1	SYNTH PAD/STR	84	3	45
0430	WarmHeaven 2	SYNTH PAD/STR	84	3	46
0431	Heaven Pad 1	SYNTH PAD/STR	84	3	47
0432	Heaven Pad 2	SYNTH PAD/STR	84	3	48
0433	Heaven Pad 3	SYNTH PAD/STR	84	3	49
0434	Heaven Pad 4	SYNTH PAD/STR	84	3	50
0435	FineWinePad1	SYNTH PAD/STR	84	3	51
0436	FineWinePad2	SYNTH PAD/STR	84	3	52
0437	5th Pad 1	SYNTH PAD/STR	84	3	53
0438	5th Pad 2	SYNTH PAD/STR	84	3	54
0439	Nu Epic Pad	SYNTH PAD/STR	84	3	55
0440	Angelis Pad	SYNTH PAD/STR	84	3	56
0441	TrnsSweepPad	SYNTH PAD/STR	84	3	57
0442	Giant Sweep	SYNTH PAD/STR	84	3	58
0443	Voyager	SYNTH PAD/STR	84	3	59
0444	Digital Pad	SYNTH PAD/STR	84	3	60
0445	NuSoundtrack	SYNTH PAD/STR	84	3	61
0446	Xadecimal	SYNTH PAD/STR	84	3	62
0447	Strobe Pad	SYNTH PAD/STR	84	3	63
0448	BUBBLE 2	SYNTH PAD/STR	84	3	64
0449	BUBBLE 3	SYNTH PAD/STR	84	3	65
0450	Soft PWM Pad	SYNTH PAD/STR	84	3	66
0451	Org Pad	SYNTH PAD/STR	84	3	67
0452	Hollow Pad 2	SYNTH PAD/STR	84	3	68
0453	SavannaPad 1	SYNTH PAD/STR	84	3	69
0454	SavannaPad 2	SYNTH PAD/STR	84	3	70
0455	SavannaPad 3	SYNTH PAD/STR	84	3	71
0456	PWM Pad 2	SYNTH PAD/STR	84	3	72
0457	Str Machine	SYNTH PAD/STR	84	3	73
0458	Reso Pad	SYNTH PAD/STR	84	3	74
0459	BPF Pad	SYNTH PAD/STR	84	3	75
0460	Sweep Pad	SYNTH PAD/STR	84	3	76
0461	Sweep Pad 2	SYNTH PAD/STR	84	3	77
0462	Sweep Pad 3	SYNTH PAD/STR	84	3	78
0463	Sweep Pad 4	SYNTH PAD/STR	84	3	79
0464	Scoop Pad 1	SYNTH PAD/STR	84	3	80
0465	Scoop Pad 2	SYNTH PAD/STR	84	3	81
0466	Brite Wine	SYNTH PAD/STR	84	3	82
0467	Wine Pad	SYNTH PAD/STR	84	3	83
0468	Warm Pad	SYNTH PAD/STR	84	3	84
0469	Sine Pad	SYNTH PAD/STR	84	3	85
0470	Bowed Glass	SYNTH PAD/STR	84	3	86
0471	Metal Pad	SYNTH PAD/STR	84	3	87
0472	Halo Pad	SYNTH PAD/STR	84	3	88
0473	Soundtrack	SYNTH PAD/STR	84	3	89
0474	Star Theme	SYNTH PAD/STR	84	3	90
0475	Air Key 1	SYNTH BELLPAD	84	3	91
0476	Air Key 2	SYNTH BELLPAD	84	3	92
0477	Sweet Keys	SYNTH BELLPAD	84	3	93
0478	Soft Bell	SYNTH BELLPAD	84	3	94
0479	Stacc Heaven	SYNTH BELLPAD	84	3	95

Tone List

No.	Name	Category	MSB	LSB	PC
0480	DigitalDream	SYNTH BELLPAD	84	3	96
0481	Analog Dream	SYNTH BELLPAD	84	3	97
0482	Harp Pad	SYNTH BELLPAD	84	3	98
0483	Ice Rain	SYNTH BELLPAD	84	3	99
0484	Atmosphere	SYNTH BELLPAD	84	3	100
0485	Brightness	SYNTH BELLPAD	84	3	101
0486	Dreaming Box	SYNTH BELLPAD	84	3	102
0487	Large Choir	VOX CHOIR	84	3	103
0488	GX Choir	VOX CHOIR	84	3	104
0489	Choir Aahs	VOX CHOIR	84	3	105
0490	Chorus Aahs	VOX CHOIR	84	3	106
0491	Choir Pad	VOX CHOIR	84	3	107
0492	Angels Choir	VOX CHOIR	84	3	108
0493	Aerial Choir	VOX CHOIR	84	3	109
0494	Voice Oohs	VOX CHOIR	84	3	110
0495	Doo Pad	VOX CHOIR	84	3	111
0496	Humming	VOX CHOIR	84	3	112
0497	Humming 2	VOX CHOIR	84	3	113
0498	Humming 3	VOX CHOIR	84	3	114
0499	Gospel Hum	VOX CHOIR	84	3	115
0500	Decay Choir	VOX CHOIR	84	3	116
0501	Vox Pad 1	VOX CHOIR	84	3	117
0502	Vox Pad 2	VOX CHOIR	84	3	118
0503	Dreamvox 1	VOX CHOIR	84	3	119
0504	Dreamvox 2	VOX CHOIR	84	3	120
0505	80s Vox	VOX CHOIR	84	3	121
0506	SynVox	VOX CHOIR	84	3	122
0507	SynVox 2	VOX CHOIR	84	3	123
0508	SynVox 3	VOX CHOIR	84	3	124
0509	Mini Vox	VOX CHOIR	84	3	125
0510	Chipmunk	VOX CHOIR	84	3	126
0511	Sample Opera	VOX CHOIR	84	3	127
0512	Sad Ceremony	VOX CHOIR	84	3	128
0513	5th Voice	VOX CHOIR	84	4	1
0514	Sop Vox	VOX CHOIR	84	4	2
0515	Analog Voice	VOX CHOIR	84	4	3
0516	Space Voice	VOX CHOIR	84	4	4
0517	Itopia	VOX CHOIR	84	4	5
0518	Tron Choir	VOX CHOIR	84	4	6
0519	Tron Vox	VOX CHOIR	84	4	7
0520	Jazz Scat 1	SCAT	84	4	8
0521	Jazz Scat 2	SCAT	84	4	9

No.	Name	Category	MSB	LSB	PC
0527	Fingered Bs2	E.BASS	84	4	15
0528	Fingered Bs3	E.BASS	84	4	16
0529	Fingered Bs4	E.BASS	84	4	17
0530	Pick Bass	E.BASS	84	4	18
0531	Picked Bass	E.BASS	84	4	19
0532	Fretless Bs	E.BASS	84	4	20
0533	FretlessBs 2	E.BASS	84	4	21
0534	FretlessBs 3	E.BASS	84	4	22
0535	Finger Slap	E.BASS	84	4	23
0536	Finger Slap2	E.BASS	84	4	24
0537	Slap Bass 1	E.BASS	84	4	25
0538	Slap Bass 2	E.BASS	84	4	26
0539	Return2Base!	E.BASS	84	4	27
0540	MG Bass 1	SYNTH BASS	84	4	28
0541	MG Bass 2	SYNTH BASS	84	4	29
0542	MG Bass 3	SYNTH BASS	84	4	30
0543	Modular Bs 1	SYNTH BASS	84	4	31
0544	Modular Bs 2	SYNTH BASS	84	4	32
0545	PWM Bass 1	SYNTH BASS	84	4	33
0546	PWM Bass 2	SYNTH BASS	84	4	34
0547	Big Mini	SYNTH BASS	84	4	35
0548	Fat Analog	SYNTH BASS	84	4	36
0549	Spike Bass	SYNTH BASS	84	4	37
0550	SH Bass	SYNTH BASS	84	4	38
0551	Intrusive Bs	SYNTH BASS	84	4	39
0552	Synth Bass 1	SYNTH BASS	84	4	40
0553	Synth Bass 2	SYNTH BASS	84	4	41
0554	Synth Bass 3	SYNTH BASS	84	4	42
0555	Synth Bass 4	SYNTH BASS	84	4	43
0556	Synth Bass 5	SYNTH BASS	84	4	44
0557	Synth Bass 6	SYNTH BASS	84	4	45
0558	Synth Bass 7	SYNTH BASS	84	4	46
0559	Synth Bass 8	SYNTH BASS	84	4	47
0560	Synth Bass 9	SYNTH BASS	84	4	48
0561	Synth Bass10	SYNTH BASS	84	4	49
0562	Synth Bass11	SYNTH BASS	84	4	50
0563	Synth Bass12	SYNTH BASS	84	4	51
0564	Synth Bass13	SYNTH BASS	84	4	52
0565	Synth Bass14	SYNTH BASS	84	4	53
0566	Reso Bass 1	SYNTH BASS	84	4	54
0567	Reso Bass 2	SYNTH BASS	84	4	55
0568	Reso Bass 3	SYNTH BASS	84	4	56
0569	Reso Bass 4	SYNTH BASS	84	4	57
0570	Reso Bass 5	SYNTH BASS	84	4	58
0571	Reso Bass 6	SYNTH BASS	84	4	59
0572	Reso Bass 7	SYNTH BASS	84	4	60
0573	Reso Bass 8	SYNTH BASS	84	4	61
0574	Reso Bass 9	SYNTH BASS	84	4	62
0575	Reso Bass 10	SYNTH BASS	84	4	63
0576	Acid Bass	SYNTH BASS	84	4	64
0577	Acid Bass 2	SYNTH BASS	84	4	65
0578	Acid Bass 3	SYNTH BASS	84	4	66
0579	Acid Bass 4	SYNTH BASS	84	4	67

BASS

No.	Name	Category	MSB	LSB	PC
0522	Acoustic Bs	AC.BASS	84	4	10
0523	Acoustic Bs2	AC.BASS	84	4	11
0524	Acoustic Bs3	AC.BASS	84	4	12
0525	String Slap	AC.BASS	84	4	13
0526	Fingered Bs	E.BASS	84	4	14

No.	Name	Category	MSB	LSB	PC
0580	Acid Bass 5	SYNTH BASS	84	4	68
0581	Acid Bass 6	SYNTH BASS	84	4	69
0582	Acid Bass 7	SYNTH BASS	84	4	70
0583	TB Bass 1	SYNTH BASS	84	4	71
0584	TB Bass 2	SYNTH BASS	84	4	72
0585	TB Bass 3	SYNTH BASS	84	4	73
0586	TB Bass 4	SYNTH BASS	84	4	74
0587	Alpha Bass 1	SYNTH BASS	84	4	75
0588	Alpha Bass 2	SYNTH BASS	84	4	76
0589	Alpha ResoBs	SYNTH BASS	84	4	77
0590	Nu Saw Bass	SYNTH BASS	84	4	78
0591	Nu RnB SawBs	SYNTH BASS	84	4	79
0592	Storm Bass	SYNTH BASS	84	4	80
0593	Detune Bass	SYNTH BASS	84	4	81
0594	Gashed Bass	SYNTH BASS	84	4	82
0595	Hi-Energy Bs	SYNTH BASS	84	4	83
0596	Pedal Bass 1	SYNTH BASS	84	4	84
0597	Pedal Bass 2	SYNTH BASS	84	4	85
0598	Monster Bass	SYNTH BASS	84	4	86
0599	JunoSqr Bs 1	SYNTH BASS	84	4	87
0600	JunoSqr Bs 2	SYNTH BASS	84	4	88
0601	101 Bass	SYNTH BASS	84	4	89
0602	106 Bass 1	SYNTH BASS	84	4	90
0603	106 Bass 2	SYNTH BASS	84	4	91
0604	Compu Bass 1	SYNTH BASS	84	4	92
0605	Compu Bass 2	SYNTH BASS	84	4	93
0606	Triangle Bs	SYNTH BASS	84	4	94
0607	Muffled Bass	SYNTH BASS	84	4	95
0608	Garage Bass	SYNTH BASS	84	4	96
0609	TransistorBs	SYNTH BASS	84	4	97
0610	Fazee Bass	SYNTH BASS	84	4	98
0611	Brite Bass	SYNTH BASS	84	4	99
0612	Saw Bass	SYNTH BASS	84	4	100
0613	Sub Bass	SYNTH BASS	84	4	101
0614	Ramp Bass	SYNTH BASS	84	4	102
0615	Fat Bass 1	SYNTH BASS	84	4	103
0616	Fat Bass 2	SYNTH BASS	84	4	104
0617	Fat Bass 3	SYNTH BASS	84	4	105
0618	Flat Bass	SYNTH BASS	84	4	106
0619	Electro Rubb	SYNTH BASS	84	4	107
0620	80s Bass	SYNTH BASS	84	4	108
0621	SynthBass101	SYNTH BASS	84	4	109
0622	Clav Bass	SYNTH BASS	84	4	110
0623	Hammer Bass	SYNTH BASS	84	4	111
0624	SynSlap Bass	SYNTH BASS	84	4	112
0625	Rubber Bass	SYNTH BASS	84	4	113
0626	Attack Pulse	SYNTH BASS	84	4	114
0627	Nylon Gtr 1	AC.GUITAR	84	4	115
0628	Nylon Gtr 2	AC.GUITAR	84	4	116
0629	Nylon Gtr 3	AC.GUITAR	84	4	117
0630	Nylon Gtr 4	AC.GUITAR	84	4	118
0631	Nylon Gtr 5	AC.GUITAR	84	4	119
0632	Nylon Gtr 6	AC.GUITAR	84	4	120

No.	Name	Category	MSB	LSB	PC
0633	Wet NylN Gtr	AC.GUITAR	84	4	121
0634	Folk Gtr 1	AC.GUITAR	84	4	122
0635	Folk Gtr 2	AC.GUITAR	84	4	123
0636	Folk Gtr 3	AC.GUITAR	84	4	124
0637	Latin Gtr	AC.GUITAR	84	4	125
0638	Ukulele	AC.GUITAR	84	4	126
0639	Ukulele 2	AC.GUITAR	84	4	127
0640	Nylon Gtr 1o	AC.GUITAR	84	4	128
0641	Steel-str.Gt	AC.GUITAR	84	5	1
0642	12-str. Gtr	AC.GUITAR	84	5	2
0643	Steel + Body	AC.GUITAR	84	5	3
0644	Gt FretNoise	AC.GUITAR	84	5	4
0645	Clean Gtr 1	E.GUITAR	84	5	5
0646	Clean Gtr 2	E.GUITAR	84	5	6
0647	Clean Gtr 3	E.GUITAR	84	5	7
0648	Jazz Guitar	E.GUITAR	84	5	8
0649	Jazz Guitar2	E.GUITAR	84	5	9
0650	Pick E.Gtr	E.GUITAR	84	5	10
0651	Funk Guitar	E.GUITAR	84	5	11
0652	Funk Guitar2	E.GUITAR	84	5	12
0653	Wet E.Gtr	E.GUITAR	84	5	13
0654	Pedal Steel	E.GUITAR	84	5	14
0655	Pedal Steel2	E.GUITAR	84	5	15
0656	Clean Guitar	E.GUITAR	84	5	16
0657	Chorus Gtr	E.GUITAR	84	5	17
0658	Mid Tone Gtr	E.GUITAR	84	5	18
0659	Muted Guitar	E.GUITAR	84	5	19
0660	Funk Pop	E.GUITAR	84	5	20
0661	Jazz Man	E.GUITAR	84	5	21
0662	Gt Cut Noise	E.GUITAR	84	5	22
0663	Overdrive Gt	DIST GUITAR	84	5	23
0664	OverdriveGt2	DIST GUITAR	84	5	24
0665	Guitar Pinch	DIST GUITAR	84	5	25
0666	Dist Gtr 1	DIST GUITAR	84	5	26
0667	Dist Gtr 2	DIST GUITAR	84	5	27
0668	Dist Gtr 3	DIST GUITAR	84	5	28
0669	DistortionGt	DIST GUITAR	84	5	29
0670	Gt Feedback1	DIST GUITAR	84	5	30
0671	Dist Rtm Gtr	DIST GUITAR	84	5	31
0672	Gt Harmonics	DIST GUITAR	84	5	32
0673	Gt Feedback2	DIST GUITAR	84	5	33
0674	Kalimba	PLUCKED STROKE	84	5	34
0675	Harp	PLUCKED STROKE	84	5	35
0676	Yang Qin	PLUCKED STROKE	84	5	36
0677	Sitar Pad	PLUCKED STROKE	84	5	37
0678	Mandolin	PLUCKED STROKE	84	5	38
0679	Sitar 1	PLUCKED STROKE	84	5	39
0680	Sitar 2	PLUCKED STROKE	84	5	40
0681	Sitar 3	PLUCKED STROKE	84	5	41
0682	Banjo	PLUCKED STROKE	84	5	42
0683	Shamisen	PLUCKED STROKE	84	5	43
0684	Koto	PLUCKED STROKE	84	5	44
0685	Taisho Koto	PLUCKED STROKE	84	5	45

Tone List

No.	Name	Category	MSB	LSB	PC
0686	Aerial Harp	PLUCKED STROKE	84	5	46
0687	LostParadise	PLUCKED STROKE	84	5	47
0688	Indian Frtls	PLUCKED STROKE	84	5	48
0689	Santur	PLUCKED STROKE	84	5	49
0690	Santur 2	PLUCKED STROKE	84	5	50
0691	Santur 3	PLUCKED STROKE	84	5	51

OTHER

No.	Name	Category	MSB	LSB	PC
0692	Brass 1	ENSEMBLE BRASS	84	5	52
0693	Brass 2	ENSEMBLE BRASS	84	5	53
0694	Brass 3	ENSEMBLE BRASS	84	5	54
0695	Brass 4	ENSEMBLE BRASS	84	5	55
0696	Brass 5	ENSEMBLE BRASS	84	5	56
0697	Brass 6	ENSEMBLE BRASS	84	5	57
0698	F.Horn Sect	ENSEMBLE BRASS	84	5	58
0699	Trumpet	SOLO BRASS	84	5	59
0700	Trumpet 2	SOLO BRASS	84	5	60
0701	Dark Trumpet	SOLO BRASS	84	5	61
0702	MuteTrumpet1	SOLO BRASS	84	5	62
0703	MuteTrumpet2	SOLO BRASS	84	5	63
0704	Trombone 1	SOLO BRASS	84	5	64
0705	Trombone 2	SOLO BRASS	84	5	65
0706	Bright Tb	SOLO BRASS	84	5	66
0707	Tuba	SOLO BRASS	84	5	67
0708	Fr.Horn	SOLO BRASS	84	5	68
0709	French Horn	SOLO BRASS	84	5	69
0710	Oboe	WOODWINDS	84	5	70
0711	English Horn	WOODWINDS	84	5	71
0712	Bassoon	WOODWINDS	84	5	72
0713	Bassoon 2	WOODWINDS	84	5	73
0714	Clarinet	WOODWINDS	84	5	74
0715	Bagpipe	WOODWINDS	84	5	75
0716	Shanai	WOODWINDS	84	5	76
0717	Piccolo	FLUTE	84	5	77
0718	Flute	FLUTE	84	5	78
0719	Flute 2	FLUTE	84	5	79
0720	Strawberry Flute	FLUTE	84	5	80
0721	Pan Flute	FLUTE	84	5	81
0722	Pan Flute 2	FLUTE	84	5	82
0723	Pan Pipes 1	FLUTE	84	5	83
0724	Pan Pipes 2	FLUTE	84	5	84
0725	Bottle Blow	FLUTE	84	5	85
0726	Shakuhachi	FLUTE	84	5	86
0727	Shakuhachi 2	FLUTE	84	5	87
0728	Breath Noise	FLUTE	84	5	88
0729	Fl.Key Click	FLUTE	84	5	89
0730	Soprano Sax	SAX	84	5	90
0731	Soprano Sax2	SAX	84	5	91
0732	Alto Sax	SAX	84	5	92

No.	Name	Category	MSB	LSB	PC
0733	Tenor Sax	SAX	84	5	93
0734	Tenor Sax 2	SAX	84	5	94
0735	BreathyTenor	SAX	84	5	95
0736	Baritone Sax	SAX	84	5	96
0737	Recorder	RECORDER	84	5	97
0738	Whistle	RECORDER	84	5	98
0739	Ocarina	RECORDER	84	5	99
0740	Ocarina 2	RECORDER	84	5	100
0741	Juno SQR	SYNTH LEAD	84	5	101
0742	Saw Lead 1	SYNTH LEAD	84	5	102
0743	Saw Lead 2	SYNTH LEAD	84	5	103
0744	Saw Lead 3	SYNTH LEAD	84	5	104
0745	Saw Lead 4	SYNTH LEAD	84	5	105
0746	Saw Lead 5	SYNTH LEAD	84	5	106
0747	Saw Lead 6	SYNTH LEAD	84	5	107
0748	Saw Lead 7	SYNTH LEAD	84	5	108
0749	Saw Lead 8	SYNTH LEAD	84	5	109
0750	Saw Lead 9	SYNTH LEAD	84	5	110
0751	Saw Lead 10	SYNTH LEAD	84	5	111
0752	GR300 Lead 1	SYNTH LEAD	84	5	112
0753	GR300 Lead 2	SYNTH LEAD	84	5	113
0754	Classic GR	SYNTH LEAD	84	5	114
0755	Bright GR	SYNTH LEAD	84	5	115
0756	Fat GR Lead	SYNTH LEAD	84	5	116
0757	MODified Ld	SYNTH LEAD	84	5	117
0758	Syn Lead 1	SYNTH LEAD	84	5	118
0759	Syn Lead 2	SYNTH LEAD	84	5	119
0760	Syn Lead 3	SYNTH LEAD	84	5	120
0761	Syn Lead 4	SYNTH LEAD	84	5	121
0762	Syn Lead 5	SYNTH LEAD	84	5	122
0763	Syn Lead 6	SYNTH LEAD	84	5	123
0764	Syn Lead 7	SYNTH LEAD	84	5	124
0765	Pro Fat Ld 1	SYNTH LEAD	84	5	125
0766	Pro Fat Ld 2	SYNTH LEAD	84	5	126
0767	JupiterLead1	SYNTH LEAD	84	5	127
0768	JupiterLead2	SYNTH LEAD	84	5	128
0769	Porta Lead	SYNTH LEAD	84	6	1
0770	Classic Lead	SYNTH LEAD	84	6	2
0771	On Air	SYNTH LEAD	84	6	3
0772	Wormy Lead	SYNTH LEAD	84	6	4
0773	Waspy Lead	SYNTH LEAD	84	6	5
0774	Brite ResoLd	SYNTH LEAD	84	6	6
0775	Brass Lead	SYNTH LEAD	84	6	7
0776	Legato Tkno	SYNTH LEAD	84	6	8
0777	Follow Me	SYNTH LEAD	84	6	9
0778	Octa Juice	SYNTH LEAD	84	6	10
0779	Juicy Jupe	SYNTH LEAD	84	6	11
0780	Octa Saw	SYNTH LEAD	84	6	12
0781	Vintager 1	SYNTH LEAD	84	6	13
0782	Vintager 2	SYNTH LEAD	84	6	14
0783	Sync Lead	SYNTH LEAD	84	6	15
0784	Octa Sync	SYNTH LEAD	84	6	16
0785	Leading Sync	SYNTH LEAD	84	6	17

No.	Name	Category	MSB	LSB	PC
0786	A Leader	SYNTH LEAD	84	6	18
0787	Hot Coffee	SYNTH LEAD	84	6	19
0788	Hot Sync	SYNTH LEAD	84	6	20
0789	Synchro Lead	SYNTH LEAD	84	6	21
0790	Space Solo	SYNTH LEAD	84	6	22
0791	Squareheads	SYNTH LEAD	84	6	23
0792	Mod Lead	SYNTH LEAD	84	6	24
0793	Alpha Spit	SYNTH LEAD	84	6	25
0794	Air Lead	SYNTH LEAD	84	6	26
0795	Pulstar Lead	SYNTH LEAD	84	6	27
0796	Therasaw	SYNTH LEAD	84	6	28
0797	Warmy Lead	SYNTH LEAD	84	6	29
0798	ResoSawLead	SYNTH LEAD	84	6	30
0799	Soft Reso Ld	SYNTH LEAD	84	6	31
0800	Reso Lead 1	SYNTH LEAD	84	6	32
0801	Reso Lead 2	SYNTH LEAD	84	6	33
0802	Reso Lead 3	SYNTH LEAD	84	6	34
0803	Reso Lead 4	SYNTH LEAD	84	6	35
0804	Reso Lead 5	SYNTH LEAD	84	6	36
0805	Juicy Lead	SYNTH LEAD	84	6	37
0806	DC Triangle	SYNTH LEAD	84	6	38
0807	Soft Lead 1	SYNTH LEAD	84	6	39
0808	Soft Lead 2	SYNTH LEAD	84	6	40
0809	Soft Lead 3	SYNTH LEAD	84	6	41
0810	Soft Lead 4	SYNTH LEAD	84	6	42
0811	Soft Lead 5	SYNTH LEAD	84	6	43
0812	Soft Lead 6	SYNTH LEAD	84	6	44
0813	Soft Lead 7	SYNTH LEAD	84	6	45
0814	Soft Lead 8	SYNTH LEAD	84	6	46
0815	Soft Lead 9	SYNTH LEAD	84	6	47
0816	Soft Lead 10	SYNTH LEAD	84	6	48
0817	Tri Lead	SYNTH LEAD	84	6	49
0818	Pulse Lead 1	SYNTH LEAD	84	6	50
0819	Pulse Lead 2	SYNTH LEAD	84	6	51
0820	Pulse Lead 3	SYNTH LEAD	84	6	52
0821	Pulse Lead 4	SYNTH LEAD	84	6	53
0822	Simple Tri	SYNTH LEAD	84	6	54
0823	Simple Sine	SYNTH LEAD	84	6	55
0824	Whistle Ld 1	SYNTH LEAD	84	6	56
0825	Whistle Ld 2	SYNTH LEAD	84	6	57
0826	Square Pipe	SYNTH LEAD	84	6	58
0827	CosmicDrops1	SYNTH LEAD	84	6	59
0828	Spooky Lead	SYNTH LEAD	84	6	60
0829	Pure Lead	SYNTH LEAD	84	6	61
0830	303 NRG	SYNTH LEAD	84	6	62
0831	Round SQR	SYNTH LEAD	84	6	63
0832	Brite SQR	SYNTH LEAD	84	6	64
0833	Square SAW	SYNTH LEAD	84	6	65
0834	Simple SQR	SYNTH LEAD	84	6	66
0835	Sqr Lead	SYNTH LEAD	84	6	67
0836	Atk Lead	SYNTH LEAD	84	6	68
0837	Octa Square	SYNTH LEAD	84	6	69
0838	CS Lead	SYNTH LEAD	84	6	70

No.	Name	Category	MSB	LSB	PC
0839	Mini Growl	SYNTH LEAD	84	6	71
0840	Hoover Again	SYNTH LEAD	84	6	72
0841	Tranceformer	SYNTH LEAD	84	6	73
0842	Ramp Lead 1	SYNTH LEAD	84	6	74
0843	Ramp Lead 2	SYNTH LEAD	84	6	75
0844	Sine Lead 1	SYNTH LEAD	84	6	76
0845	Sine Lead 2	SYNTH LEAD	84	6	77
0846	Dance Saws1	SYNTH LEAD	84	6	78
0847	Resoform	SYNTH LEAD	84	6	79
0848	Dance Saws 2	SYNTH LEAD	84	6	80
0849	Square Wave	SYNTH LEAD	84	6	81
0850	MG Square	SYNTH LEAD	84	6	82
0851	2600 Sine	SYNTH LEAD	84	6	83
0852	Saw Wave	SYNTH LEAD	84	6	84
0853	OB2 Saw	SYNTH LEAD	84	6	85
0854	Doctor Solo	SYNTH LEAD	84	6	86
0855	Natural Lead	SYNTH LEAD	84	6	87
0856	Syn.Calliope	SYNTH LEAD	84	6	88
0857	Chiffer Lead	SYNTH LEAD	84	6	89
0858	Charang	SYNTH LEAD	84	6	90
0859	Wire Lead	SYNTH LEAD	84	6	91
0860	Solo Vox	SYNTH LEAD	84	6	92
0861	5th Saw Wave	SYNTH LEAD	84	6	93
0862	Bass & Lead	SYNTH LEAD	84	6	94
0863	Delayed Lead	SYNTH LEAD	84	6	95
0864	80s Brass 1	SYNTH BRASS	84	6	96
0865	80s Brass 2	SYNTH BRASS	84	6	97
0866	80s Brass 3	SYNTH BRASS	84	6	98
0867	80s Brass 4	SYNTH BRASS	84	6	99
0868	80s Brass 5	SYNTH BRASS	84	6	100
0869	80s Brass 6	SYNTH BRASS	84	6	101
0870	80s Brass 7	SYNTH BRASS	84	6	102
0871	80s Brass 8	SYNTH BRASS	84	6	103
0872	Soft SynBrs1	SYNTH BRASS	84	6	104
0873	Soft SynBrs2	SYNTH BRASS	84	6	105
0874	Warm SynBrs	SYNTH BRASS	84	6	106
0875	Brite SynBrs	SYNTH BRASS	84	6	107
0876	Express Brs	SYNTH BRASS	84	6	108
0877	EuroExpress1	SYNTH BRASS	84	6	109
0878	JP Brass 1	SYNTH BRASS	84	6	110
0879	JP Brass 2	SYNTH BRASS	84	6	111
0880	Juno Brass	SYNTH BRASS	84	6	112
0881	Ox Brass	SYNTH BRASS	84	6	113
0882	Reso Brass	SYNTH BRASS	84	6	114
0883	Wide SynBrs	SYNTH BRASS	84	6	115
0884	106 Brass	SYNTH BRASS	84	6	116
0885	Octa Brass	SYNTH BRASS	84	6	117
0886	Poly Brass 1	SYNTH BRASS	84	6	118
0887	Poly Brass 2	SYNTH BRASS	84	6	119
0888	Dual Saw Brs	SYNTH BRASS	84	6	120
0889	Jump Poly	SYNTH BRASS	84	6	121
0890	Reso Key 1	SYNTH BRASS	84	6	122
0891	EuroExpress2	SYNTH BRASS	84	6	123

Tone List

No.	Name	Category	MSB	LSB	PC
0892	Ox Synth	SYNTH BRASS	84	6	124
0893	VintageBrs 1	SYNTH BRASS	84	6	125
0894	VintageBrs 2	SYNTH BRASS	84	6	126
0895	VintageBrs 3	SYNTH BRASS	84	6	127
0896	VintageBrs 4	SYNTH BRASS	84	6	128
0897	JP Brass	SYNTH BRASS	84	7	1
0898	Oct SynBrass	SYNTH BRASS	84	7	2
0899	Jump Brass	SYNTH BRASS	84	7	3
0900	Synth Brass1	SYNTH BRASS	84	7	4
0901	Synth Brass2	SYNTH BRASS	84	7	5
0902	SynBrass sfz	SYNTH BRASS	84	7	6
0903	Velo Brass	SYNTH BRASS	84	7	7
0904	Syn Mallet	SYNTH POLY KEY	84	7	8
0905	Heaven Key	SYNTH POLY KEY	84	7	9
0906	PWM Pad 1	SYNTH POLY KEY	84	7	10
0907	Poly Synth	SYNTH POLY KEY	84	7	11
0908	Dream Trance	SYNTH POLY KEY	84	7	12
0909	Dream Saws	SYNTH POLY KEY	84	7	13
0910	Dream Pulse	SYNTH POLY KEY	84	7	14
0911	Trance Synth	SYNTH POLY KEY	84	7	15
0912	Trancy	SYNTH POLY KEY	84	7	16
0913	Trance Keys	SYNTH POLY KEY	84	7	17
0914	Trance Saws	SYNTH POLY KEY	84	7	18
0915	Auto Trance1	SYNTH POLY KEY	84	7	19
0916	Super Saws 1	SYNTH POLY KEY	84	7	20
0917	Analog Saws	SYNTH POLY KEY	84	7	21
0918	Uni-G	SYNTH POLY KEY	84	7	22
0919	Digitaleess	SYNTH POLY KEY	84	7	23
0920	Bustranza	SYNTH POLY KEY	84	7	24
0921	Super Saws 2	SYNTH POLY KEY	84	7	25
0922	Poly Synth 2	SYNTH POLY KEY	84	7	26
0923	Poly Synth 3	SYNTH POLY KEY	84	7	27
0924	Poly Synth 4	SYNTH POLY KEY	84	7	28
0925	Poly Synth 5	SYNTH POLY KEY	84	7	29
0926	Poly Synth 6	SYNTH POLY KEY	84	7	30
0927	Poly Synth 7	SYNTH POLY KEY	84	7	31
0928	Juno Saw Key	SYNTH POLY KEY	84	7	32
0929	Saw Key 1	SYNTH POLY KEY	84	7	33
0930	Saw Key 2	SYNTH POLY KEY	84	7	34
0931	Waspy Synth	SYNTH POLY KEY	84	7	35
0932	Vintage Key	SYNTH POLY KEY	84	7	36
0933	Ju-D Fifths	SYNTH POLY KEY	84	7	37
0934	Reso Key 2	SYNTH POLY KEY	84	7	38
0935	Fat Synth	SYNTH POLY KEY	84	7	39
0936	DOC Stack	SYNTH POLY KEY	84	7	40
0937	2 Saws	SYNTH POLY KEY	84	7	41
0938	Hi Saw Band	SYNTH POLY KEY	84	7	42
0939	Brite Synth	SYNTH POLY KEY	84	7	43
0940	RAVtune	SYNTH POLY KEY	84	7	44
0941	Pipe Key	SYNTH POLY KEY	84	7	45
0942	Shroomy	SYNTH POLY KEY	84	7	46
0943	AnalogDays 1	SYNTH POLY KEY	84	7	47
0944	Sync Key	SYNTH POLY KEY	84	7	48

No.	Name	Category	MSB	LSB	PC
0945	Detune Ramp	SYNTH POLY KEY	84	7	49
0946	Reso Saw	SYNTH POLY KEY	84	7	50
0947	EuroExpress3	SYNTH POLY KEY	84	7	51
0948	Sweep Saw	SYNTH POLY KEY	84	7	52
0949	Shimmer Pad	SYNTH FX	84	7	53
0950	BUBBLE 1	SYNTH FX	84	7	54
0951	CosmicDrops2	SYNTH FX	84	7	55
0952	Enigmatic	SYNTH FX	84	7	56
0953	Planetz	SYNTH FX	84	7	57
0954	Sci-Fi	SYNTH FX	84	7	58
0955	ResoSweep Dn	SYNTH FX	84	7	59
0956	Jet Noise	SYNTH FX	84	7	60
0957	Brandish	SYNTH FX	84	7	61
0958	909 Fx	SYNTH FX	84	7	62
0959	Zap	SYNTH FX	84	7	63
0960	PolySweep Nz	SYNTH FX	84	7	64
0961	Passing By	SYNTH FX	84	7	65
0962	Lazer Points	SYNTH FX	84	7	66
0963	Crystal Fx	SYNTH FX	84	7	67
0964	Crystal Ice	SYNTH FX	84	7	68
0965	Mad Noise	SYNTH FX	84	7	69
0966	Robot Sci-Fi	SYNTH FX	84	7	70
0967	Computer 1	SYNTH FX	84	7	71
0968	Computer 2	SYNTH FX	84	7	72
0969	S&H Noise	SYNTH FX	84	7	73
0970	S&H Ramp	SYNTH FX	84	7	74
0971	S&H PWM	SYNTH FX	84	7	75
0972	S&H Saw 1	SYNTH FX	84	7	76
0973	S&H Saw 2	SYNTH FX	84	7	77
0974	Electrostar	SYNTH FX	84	7	78
0975	Alpha Said	SYNTH FX	84	7	79
0976	FX Ramp	SYNTH FX	84	7	80
0977	Goblin	SYNTH FX	84	7	81
0978	Echo Drops	SYNTH FX	84	7	82
0979	Echo Bell	SYNTH FX	84	7	83
0980	Analog Seq	SYNTH SEQ PAD	84	7	84
0981	Seq Pop	SYNTH SEQ PAD	84	7	85
0982	Periscope	SYNTH SEQ PAD	84	7	86
0983	Major 7	SYNTH SEQ PAD	84	7	87
0984	Juno-D Maj7	SYNTH SEQ PAD	84	7	88
0985	Sweet House	SYNTH SEQ PAD	84	7	89
0986	Detune Saws	SYNTH SEQ PAD	84	7	90
0987	Melodic Drum	SYNTH SEQ PAD	84	7	91
0988	Detune Seq	SYNTH SEQ PAD	84	7	92
0989	SequencedSaw	SYNTH SEQ PAD	84	7	93
0990	Echo Pan	SYNTH SEQ PAD	84	7	94
0991	PanninFormnt	PULSATING	84	7	95
0992	Fairy's Song	PULSATING	84	7	96
0993	Atmospherics	PULSATING	84	7	97
0994	StrobeBell 1	PULSATING	84	7	98
0995	StrobeBell 2	PULSATING	84	7	99
0996	Flying Pad 1	PULSATING	84	7	100
0997	Flying Pad 2	PULSATING	84	7	101

Tone List

No.	Name	Category	MSB	LSB	PC
0998	Flying Pad 3	PULSATING	84	7	102
0999	Flying Pad 4	PULSATING	84	7	103
1000	Flying Pad 5	PULSATING	84	7	104
1001	Sine Magic	PULSATING	84	7	105
1002	Pulsatron	PULSATING	84	7	106
1003	Motion Bass	PULSATING	84	7	107
1004	Trance Splt	PULSATING	84	7	108
1005	Rhythmic 5th	PULSATING	84	7	109
1006	Rhythmic 1	PULSATING	84	7	110
1007	Rhythmic 2	PULSATING	84	7	111
1008	Mega Sync 1	PULSATING	84	7	112
1009	StrobeBell 3	PULSATING	84	7	113
1010	Strobe 1	PULSATING	84	7	114
1011	Strobe 2	PULSATING	84	7	115
1012	Strobe 3	PULSATING	84	7	116
1013	Strobe 4	PULSATING	84	7	117
1014	LFO Saw	PULSATING	84	7	118
1015	Keep Going	PULSATING	84	7	119
1016	Keep Running	PULSATING	84	7	120
1017	Electrons	PULSATING	84	7	121
1018	BriskVortex	PULSATING	84	7	122
1019	LFO Vox	PULSATING	84	7	123
1020	Pulsasaw	PULSATING	84	7	124
1021	Arposphere	PULSATING	84	7	125
1022	Mega Sync 2	PULSATING	84	7	126
1023	Compusonic 1	BEAT GROOVE	84	7	127
1024	Compusonic 2	BEAT GROOVE	84	7	128
1025	Compusonic 3	BEAT GROOVE	84	8	1
1026	Compusonic 4	BEAT GROOVE	84	8	2
1027	Compusonic 5	BEAT GROOVE	84	8	3
1028	AnalogDays 2	BEAT GROOVE	84	8	4
1029	Groove 007	BEAT GROOVE	84	8	5
1030	Juno Pop	BEAT GROOVE	84	8	6
1031	Auto Trance2	BEAT GROOVE	84	8	7
1032	In Da Groove	BEAT GROOVE	84	8	8
1033	80s Beat	BEAT GROOVE	84	8	9
1034	Cheezy Movie	HIT	84	8	10
1035	Mod Chord	HIT	84	8	11
1036	Housechord	HIT	84	8	12
1037	OrchestraHit	HIT	84	8	13
1038	Bass Hit	HIT	84	8	14
1039	6th Hit	HIT	84	8	15
1040	Euro Hit	HIT	84	8	16
1041	Seashore	SOUND FX	84	8	17
1042	Rain	SOUND FX	84	8	18
1043	Thunder	SOUND FX	84	8	19
1044	Wind	SOUND FX	84	8	20
1045	Stream	SOUND FX	84	8	21
1046	Bubble	SOUND FX	84	8	22
1047	Bird 1	SOUND FX	84	8	23
1048	Dog	SOUND FX	84	8	24
1049	Horse Gallop	SOUND FX	84	8	25
1050	Bird 2	SOUND FX	84	8	26

No.	Name	Category	MSB	LSB	PC
1051	Telephone 1	SOUND FX	84	8	27
1052	Telephone 2	SOUND FX	84	8	28
1053	DoorCreaking	SOUND FX	84	8	29
1054	Door	SOUND FX	84	8	30
1055	Scratch	SOUND FX	84	8	31
1056	Scratch 2	SOUND FX	84	8	32
1057	Wind Chimes	SOUND FX	84	8	33
1058	Helicopter	SOUND FX	84	8	34
1059	Car Engine	SOUND FX	84	8	35
1060	Car Stop	SOUND FX	84	8	36
1061	Car Pass	SOUND FX	84	8	37
1062	Car Crash	SOUND FX	84	8	38
1063	Siren	SOUND FX	84	8	39
1064	Train	SOUND FX	84	8	40
1065	Jetplane	SOUND FX	84	8	41
1066	Starship	SOUND FX	84	8	42
1067	Burst Noise	SOUND FX	84	8	43
1068	Applause	SOUND FX	84	8	44
1069	Laughing	SOUND FX	84	8	45
1070	Screaming	SOUND FX	84	8	46
1071	Punch	SOUND FX	84	8	47
1072	Heart Beat	SOUND FX	84	8	48
1073	Footsteps	SOUND FX	84	8	49
1074	Gun Shot	SOUND FX	84	8	50
1075	Machine Gun	SOUND FX	84	8	51
1076	Laser Gun	SOUND FX	84	8	52
1077	Explosion	SOUND FX	84	8	53
1078	GM2 SFX	SOUND FX	84	8	54
1079	Timpani	PERCUSSION	84	8	55
1080	Ride Cymbal	PERCUSSION	84	8	56
1081	Castanets	PERCUSSION	84	8	57
1082	Taiko	PERCUSSION	84	8	58
1083	Concert BD	PERCUSSION	84	8	59
1084	Melo. Tom 1	PERCUSSION	84	8	60
1085	Melo. Tom 2	PERCUSSION	84	8	61
1086	Synth Drum	PERCUSSION	84	8	62
1087	808 Tom	PERCUSSION	84	8	63
1088	Elec Perc	PERCUSSION	84	8	64
1089	Reverse Cymb	PERCUSSION	84	8	65
1090	Agogo	PERCUSSION	84	8	66
1091	Woodblock	PERCUSSION	84	8	67
1092	Standard 1	DRUMS	84	8	68
1093	Standard 2	DRUMS	84	8	69
1094	Standard 3	DRUMS	84	8	70
1095	Rock Kit	DRUMS	84	8	71
1096	Jazz Kit	DRUMS	84	8	72
1097	Brush Kit	DRUMS	84	8	73
1098	Machine Kit	DRUMS	84	8	74
1099	R&B T-Analog	DRUMS	84	8	75
1100	R&B Mini Kit	DRUMS	84	8	76
1101	HipHop Kit	DRUMS	84	8	77
1102	R&B Kit	DRUMS	84	8	78
1103	Dance Kit 1	DRUMS	84	8	79

Tone List

No.	Name	Category	MSB	LSB	PC
1104	Dance Kit 2	DRUMS	84	8	80
1105	Dance Kit 3	DRUMS	84	8	81
1106	GM2 STANDARD	DRUMS	84	8	82
1107	GM2 ROOM	DRUMS	84	8	83
1108	GM2 POWER	DRUMS	84	8	84
1109	GM2 ELECTRIC	DRUMS	84	8	85
1110	GM2 ANALOG	DRUMS	84	8	86
1111	GM2 JAZZ	DRUMS	84	8	87
1112	GM2 BRUSH	DRUMS	84	8	88
1113	GM2 ORCHSTRA	DRUMS	84	8	89

Live Set List

A

No.	Name	MSB	LSB	PC
A-01	Piano + Strings	84	64	1
A-02	MFXTine EP Menu	84	64	2
A-03	Funky Keys Split	84	64	3
A-04	Nice SA E.Piano	84	64	4
A-05	an old Friend...	84	64	5
A-06	Piano + FM EP	84	64	6
A-07	R&B Tine EP Set	84	64	7
A-08	Bs+Ride / Grand	84	64	8
A-09	INITIAL LIVE SET	84	64	9
A-10	INITIAL LIVE SET	84	64	10
A-11	INITIAL LIVE SET	84	64	11
A-12	INITIAL LIVE SET	84	64	12
A-13	INITIAL LIVE SET	84	64	13
A-14	INITIAL LIVE SET	84	64	14
A-15	INITIAL LIVE SET	84	64	15
A-16	INITIAL LIVE SET	84	64	16
A-17	INITIAL LIVE SET	84	64	17
A-18	INITIAL LIVE SET	84	64	18
A-19	INITIAL LIVE SET	84	64	19
A-20	INITIAL LIVE SET	84	64	20

B

No.	Name	MSB	LSB	PC
B-01	Isn't she ...?	84	64	21
B-02	SlapBs/TWahClav	84	64	22
B-03	Maze of Love	84	64	23
B-04	Silver Top Menu	84	64	24
B-05	1978 ElectricPNO	84	64	25
B-06	StarDust Fantasy	84	64	26
B-07	RvrsPno & Pad	84	64	27
B-08	Telephone Piano	84	64	28
B-09	INITIAL LIVE SET	84	64	29
B-10	INITIAL LIVE SET	84	64	30
B-11	INITIAL LIVE SET	84	64	31
B-12	INITIAL LIVE SET	84	64	32
B-13	INITIAL LIVE SET	84	64	33
B-14	INITIAL LIVE SET	84	64	34
B-15	INITIAL LIVE SET	84	64	35
B-16	INITIAL LIVE SET	84	64	36
B-17	INITIAL LIVE SET	84	64	37
B-18	INITIAL LIVE SET	84	64	38
B-19	INITIAL LIVE SET	84	64	39
B-20	INITIAL LIVE SET	84	64	40

C

No.	Name	MSB	LSB	PC
C-01	Small Jazz Club	84	64	41
C-02	Rock Organ	84	64	42
C-03	R&B Ballad	84	64	43
C-04	Dyno EP Menu	84	64	44
C-05	Healing Piano	84	64	45
C-06	E.Bass /OrganFst	84	64	46
C-07	CmpPno/AnalogStr	84	64	47
C-08	DEMO Concert Grd	84	64	48
C-09	INITIAL LIVE SET	84	64	49
C-10	INITIAL LIVE SET	84	64	50
C-11	INITIAL LIVE SET	84	64	51
C-12	INITIAL LIVE SET	84	64	52
C-13	INITIAL LIVE SET	84	64	53
C-14	INITIAL LIVE SET	84	64	54
C-15	INITIAL LIVE SET	84	64	55
C-16	INITIAL LIVE SET	84	64	56
C-17	INITIAL LIVE SET	84	64	57
C-18	INITIAL LIVE SET	84	64	58
C-19	INITIAL LIVE SET	84	64	59
C-20	INITIAL LIVE SET	84	64	60

D

No.	Name	MSB	LSB	PC
D-01	Dist L-Org	84	64	61
D-02	Rox Collection	84	64	62
D-03	Wafting Piano	84	64	63
D-04	Garbage EP	84	64	64
D-05	Dream Keys	84	64	65
D-06	E.Bass /OrganSlw	84	64	66
D-07	SuperLight Piano	84	64	67
D-08	DEMO Tine EP	84	64	68
D-09	INITIAL LIVE SET	84	64	69
D-10	INITIAL LIVE SET	84	64	70
D-11	INITIAL LIVE SET	84	64	71
D-12	INITIAL LIVE SET	84	64	72
D-13	INITIAL LIVE SET	84	64	73
D-14	INITIAL LIVE SET	84	64	74
D-15	INITIAL LIVE SET	84	64	75
D-16	INITIAL LIVE SET	84	64	76
D-17	INITIAL LIVE SET	84	64	77
D-18	INITIAL LIVE SET	84	64	78
D-19	INITIAL LIVE SET	84	64	79
D-20	INITIAL LIVE SET	84	64	80

Live Set List

E

No.	Name	MSB	LSB	PC
E-01	FC1 PedalWahClav	84	64	81
E-02	TransistorOrgans	84	64	82
E-03	BrightRainyWaltz	84	64	83
E-04	E.Bass/RockPiano	84	64	84
E-05	WaterRing Piano	84	64	85
E-06	DynoEP /SoloLead	84	64	86
E-07	DEMO ToneColor 1	84	64	87
E-08	DEMO ToneColor 2	84	64	88
E-09	INITIAL LIVE SET	84	64	89
E-10	INITIAL LIVE SET	84	64	90
E-11	INITIAL LIVE SET	84	64	91
E-12	INITIAL LIVE SET	84	64	92
E-13	INITIAL LIVE SET	84	64	93
E-14	INITIAL LIVE SET	84	64	94
E-15	INITIAL LIVE SET	84	64	95
E-16	INITIAL LIVE SET	84	64	96
E-17	INITIAL LIVE SET	84	64	97
E-18	INITIAL LIVE SET	84	64	98
E-19	INITIAL LIVE SET	84	64	99
E-20	INITIAL LIVE SET	84	64	100

F

No.	Name	MSB	LSB	PC
F-01	Reed EP Menu	84	64	101
F-02	History of Tine	84	64	102
F-03	Symphonic Grand	84	64	103
F-04	LA Brass Rock	84	64	104
F-05	E.Bass/RockOrgan	84	64	105
F-06	Re:Milian ScPno	84	64	106
F-07	DEMO Upright Pno	84	64	107
F-08	DEMO SA Piano	84	64	108
F-09	INITIAL LIVE SET	84	64	109
F-10	INITIAL LIVE SET	84	64	110
F-11	INITIAL LIVE SET	84	64	111
F-12	INITIAL LIVE SET	84	64	112
F-13	INITIAL LIVE SET	84	64	113
F-14	INITIAL LIVE SET	84	64	114
F-15	INITIAL LIVE SET	84	64	115
F-16	INITIAL LIVE SET	84	64	116
F-17	INITIAL LIVE SET	84	64	117
F-18	INITIAL LIVE SET	84	64	118
F-19	INITIAL LIVE SET	84	64	119
F-20	INITIAL LIVE SET	84	64	120

G

No.	Name	MSB	LSB	PC
G-01	Bright FM EP	84	64	121
G-02	Piano + SA EP	84	64	122
G-03	Piano + Choir	84	64	123
G-04	TW-Org w/ LHBass	84	64	124
G-05	+StrgsVelo>High1	84	64	125
G-06	FranDoll ScPiano	84	64	126
G-07	DEMO JD Piano	84	64	127
G-08	DEMO Reed EP	84	64	128
G-09	INITIAL LIVE SET	84	65	1
G-10	INITIAL LIVE SET	84	65	2
G-11	INITIAL LIVE SET	84	65	3
G-12	INITIAL LIVE SET	84	65	4
G-13	INITIAL LIVE SET	84	65	5
G-14	INITIAL LIVE SET	84	65	6
G-15	INITIAL LIVE SET	84	65	7
G-16	INITIAL LIVE SET	84	65	8
G-17	INITIAL LIVE SET	84	65	9
G-18	INITIAL LIVE SET	84	65	10
G-19	INITIAL LIVE SET	84	65	11
G-20	INITIAL LIVE SET	84	65	12

H

No.	Name	MSB	LSB	PC
H-01	Tron Split	84	65	13
H-02	Piano + Pad	84	65	14
H-03	Misty as Last.Bs	84	65	15
H-04	SA Piano Menu	84	65	16
H-05	E.Bass / Tine EP	84	65	17
H-06	Grand Piano Menu	84	65	18
H-07	DEMO Tremolo EP	84	65	19
H-08	DEMO SA E.Piano	84	65	20
H-09	INITIAL LIVE SET	84	65	21
H-10	INITIAL LIVE SET	84	65	22
H-11	INITIAL LIVE SET	84	65	23
H-12	INITIAL LIVE SET	84	65	24
H-13	INITIAL LIVE SET	84	65	25
H-14	INITIAL LIVE SET	84	65	26
H-15	INITIAL LIVE SET	84	65	27
H-16	INITIAL LIVE SET	84	65	28
H-17	INITIAL LIVE SET	84	65	29
H-18	INITIAL LIVE SET	84	65	30
H-19	INITIAL LIVE SET	84	65	31
H-20	INITIAL LIVE SET	84	65	32

I

No.	Name	MSB	LSB	PC
I-01	Too Deep Delay!	84	65	33
I-02	JD Piano Menu	84	65	34
I-03	SA Piano Layer	84	65	35
I-04	WitchOfMilkyWay	84	65	36
I-05	+StrgsVelo>High2	84	65	37
I-06	Wedding	84	65	38
I-07	SynPad/TwinBrass	84	65	39
I-08	DEMO FM E.Piano	84	65	40
I-09	INITIAL LIVE SET	84	65	41
I-10	INITIAL LIVE SET	84	65	42
I-11	INITIAL LIVE SET	84	65	43
I-12	INITIAL LIVE SET	84	65	44
I-13	INITIAL LIVE SET	84	65	45
I-14	INITIAL LIVE SET	84	65	46
I-15	INITIAL LIVE SET	84	65	47
I-16	INITIAL LIVE SET	84	65	48
I-17	INITIAL LIVE SET	84	65	49
I-18	INITIAL LIVE SET	84	65	50
I-19	INITIAL LIVE SET	84	65	51
I-20	INITIAL LIVE SET	84	65	52

J

No.	Name	MSB	LSB	PC
J-01	SynthBrass Ens	84	65	53
J-02	Sweet House Set	84	65	54
J-03	Electro Split	84	65	55
J-04	4-Space Ballad	84	65	56
J-05	DaNCe	84	65	57
J-06	Dream Slice Pad	84	65	58
J-07	Pontyfy	84	65	59
J-08	Trance Synth	84	65	60
J-09	INITIAL LIVE SET	84	65	61
J-10	INITIAL LIVE SET	84	65	62
J-11	INITIAL LIVE SET	84	65	63
J-12	INITIAL LIVE SET	84	65	64
J-13	INITIAL LIVE SET	84	65	65
J-14	INITIAL LIVE SET	84	65	66
J-15	INITIAL LIVE SET	84	65	67
J-16	INITIAL LIVE SET	84	65	68
J-17	INITIAL LIVE SET	84	65	69
J-18	INITIAL LIVE SET	84	65	70
J-19	INITIAL LIVE SET	84	65	71
J-20	INITIAL LIVE SET	84	65	72

Rhythm Pattern List

No	Pattern name	Drum set
000	Metronome	Standard 1
001	8-Beat Pop1	Standard 1
002	8-Beat Pop2	Jazz Kit
003	8-Beat Pop3	Standard 1
004	8-Beat Pop4	Standard 1
005	8-Beat Pop5	Standard 1
006	16-Beat Pop1	Standard 2
007	16-Beat Pop2	Standard 2
008	16-Beat Pop3	Standard 2
009	16-Beat Funk	Standard 2
010	16-Bt Fusion1	Standard 2
011	16-Bt Fusion2	Standard 2
012	8-Beat Rock1	Standard 2
013	8-Beat Rock2	Standard 2
014	16Beat Rock1	Standard 2
015	16Beat Rock2	Standard 2
016	Pop Ballad	Standard 2
017	Ballad 1	Machine Kit
018	Ballad 2	Machine Kit
019	Ballad 3	Machine Kit
020	Piano R&B 1	Jazz Kit
021	Piano R&B 2	Standard 3
022	Pop 1-1	Standard 1
023	Pop 1-2	Standard 1
024	Pop 1-3	Standard 1
025	Pop 1-4	Standard 1
026	Pop 2-1	Standard 1
027	Pop 2-2	Standard 1
028	Pop 2-3	Standard 1
029	Pop 2-4	Standard 1
030	Pop 2-5	Standard 1
031	Pop 3-1	Standard 1
032	Pop 3-2	Standard 1
033	Pop 3-3	Standard 1
034	Pop 3-4	Standard 1
035	Pop 4-1	Standard 1
036	Pop 4-2	Standard 1
037	Pop 5-1	Standard 1
038	Pop 5-2	Standard 1
039	Pop 5-3	Standard 1
040	Pop 5-4	Standard 1
041	Pop 5-5	Standard 1
042	Pop 6-1	Standard 1
043	Pop 6-2	Standard 1
044	Pop 7-1	Standard 1
045	Pop 7-2	Standard 1
046	Pop 7-3	Standard 1
047	Pop 7-4	Standard 1
048	West Coast	Standard 2
049	Big Beat 1	Standard 2
050	Big Beat 2	Standard 2
051	Big Beat 3	Standard 2
052	Funk 1	Standard 3

No	Pattern name	Drum set
053	Funk 2	Standard 3
054	Funk 3	Standard 3
055	Pop Funk 1	Standard 3
056	Pop Funk 2	Standard 3
057	Pop Funk 3	Standard 3
058	R&B 1	R&B Mini Kit
059	R&B 2	R&B Mini Kit
060	R&B 3	R&B Mini Kit
061	R&B 4	R&B Mini Kit
062	R&B 5	R&B Mini Kit
063	R&B 6	R&B Mini Kit
064	R&B 7	R&B Mini Kit
065	R&B 8	R&B Mini Kit
066	R&B 9	R&B Mini Kit
067	R&B 10	R&B Mini Kit
068	R&B 11	R&B Mini Kit
069	R&B 12	R&B Mini Kit
070	R&B 13	R&B Mini Kit
071	R&B 14	R&B Mini Kit
072	R&B 15	R&B Mini Kit
073	R&B 16	R&B Mini Kit
074	R&B 17	R&B Mini Kit
075	R&B 18	R&B Mini Kit
076	R&B Pop 1	Standard 2
077	R&B Pop 2	Standard 2
078	R&B Pop 3	Standard 2
079	R&B Pop 4	Standard 2
080	R&B Pop 5	Standard 2
081	R&B Pop 6	Standard 2
082	Rockaballad	Standard 3
083	Shuffle 1	Standard 3
084	Shuffle 2	Standard 3
085	ShufflePop1	Standard 2
086	ShufflePop2	Standard 2
087	ShufflePop3	Standard 2
088	ShufflePop4	Standard 2
089	ShufflePop5	Standard 2
090	Slow Beat	Standard 2
091	StraightRock	Standard 1
092	Back Beat 1	Jazz Kit
093	Back Beat 2	R&B Mini Kit
094	Back Beat 3	R&B Mini Kit
095	Back Beat 4	R&B Mini Kit
096	Back Beat 5	R&B Mini Kit
097	Back Beat 6	R&B Mini Kit
098	Back Beat 7	R&B Mini Kit
099	Back Beat 8	R&B Mini Kit
100	Back Beat 9	R&B Mini Kit
101	Back Beat10	R&B Mini Kit
102	Jazz 1	Jazz Kit
103	Jazz 2	Jazz Kit
104	Jazz 3	Jazz Kit
105	Jazz 4	Jazz Kit

No	Pattern name	Drum set
106	Jazz 5	Jazz Kit
107	Swing 1	Jazz Kit
108	Swing 2	Jazz Kit
109	Swing 3	Jazz Kit
110	Swing 4	Jazz Kit
111	Combo	Jazz Kit
112	Free Jazz	Jazz Kit
113	Acid Jazz	R&B Kit
114	Motown	Standard 3
115	Gospel 1	Standard 3
116	Gospel 2	Standard 3
117	Blues 1	Standard 1
118	Blues 2	Standard 1
119	Power Fusion	Standard 1
120	PowerfulRock	Standard 1
121	Progressive	Standard 1
122	Rock 1	Standard 1
123	Rock 2	Standard 1
124	Rock 3	Standard 1
125	Rock 4	Standard 1
126	Rock 5	Standard 1
127	Rock 6	Standard 1
128	Rock 7	Standard 1
129	Rock 8	Standard 1
130	Rock 9	Standard 1
131	Rock 10	Standard 1
132	Rock 11	Standard 1
133	Rock 12	Standard 1
134	Rock 13	Standard 1
135	Rock 14	Standard 1
136	Rock 15	Standard 1
137	Rock 16	Standard 1
138	Rock 17	Standard 1
139	Rock 18	Standard 1
140	Rock 19	Standard 1
141	Rock 20	Standard 1
142	Rock 21	Standard 1
143	Rock 22	Standard 1
144	Rock 23	Standard 1
145	Rock 24	Standard 1
146	Rock 25	Standard 1
147	Rock 26	Standard 1
148	Rock 27	Standard 1
149	Rock 28	Standard 1
150	Rock 29	Standard 1
151	Latin Dance	Standard 1
152	Latin Pop 1	Standard 3
153	Latin Pop 2	Standard 3
154	Latin Pop 3	Standard 3
155	Latin Pop 4	Standard 3
156	Latin Pop 5	Standard 3
157	Latin Pop 6	Standard 3
158	Salsa 1	Standard 3

No	Pattern name	Drum set
159	Salsa 2	Standard 3
160	Samba	Standard 3
161	Reggae	Standard 2
162	Fast Bossa	Standard 3
163	BossaNova 1	Standard 2
164	BossaNova 2	Standard 2
165	Mambo	Standard 3
166	ElecDance 1	Machine Kit
167	ElecDance 2	Machine Kit
168	ElecDance 3	Dance Kit 1
169	ElecDance 4	Dance Kit 1
170	ElecDance 5	Machine Kit
171	ElecDance 6	Machine Kit
172	ElecDance 7	Machine Kit
173	ElecDance 8	Machine Kit
174	Dance	HipHop Kit
175	Rap 1	Dance Kit 3
176	Rap 2	Dance Kit 3
177	Hip Hop 1	Machine Kit
178	Hip Hop 2	Machine Kit
179	Hip Hop 3	Machine Kit
180	Hip Hop 4	Machine Kit
181	Hip Hop 5	Machine Kit
182	Techno	Machine Kit
183	Polka 1	Standard 3
184	Polka 2	Standard 3
185	Simple Waltz	Jazz Kit
186	Pop Waltz 1	Jazz Kit
187	Pop Waltz 2	Jazz Kit
188	Pop Waltz 3	Jazz Kit
189	Pop Waltz 4	Jazz Kit
190	Metro (2/4)	Standard 1
191	Metro (3/4)	Standard 1
192	Metro (4/4)	Standard 1
193	Metro (5/4)	Standard 1
194	Metro (6/4)	Standard 1
195	Metro (7/4)	Standard 1
196	Metro (5/8)	Standard 1
197	Metro (6/8)	Standard 1
198	Metro (7/8)	Standard 1
199	Metro (9/8)	Standard 1
200	Metro (12/8)	Standard 1

Rhythm Set List

* [EXC] : Percussion sound of the same number will not be heard at the same time.

	Standard 1 MSB: 84/LSB: 8/PC: 68	Standard 2 MSB: 84/LSB: 8/PC: 69	Standard 3 MSB: 84/LSB: 8/PC: 70	Rock Kit MSB: 84/LSB: 8/PC: 71	Jazz Kit MSB: 84/LSB: 8/PC: 72
C1	22 MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1
	23 MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2
	24 Concert SD	Concert SD	Concert SD	Concert SD	Concert SD
	25 Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
	26 Snap	Snap	Snap	Snap	Snap
	27 High Q	High Q	High Q	High Q	High Q
	28 Slap	Slap	Slap	Slap	Slap
	29 Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]
	30 Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]
	31 Sticks	Sticks	Sticks	Sticks	Sticks
C2	32 Square Click	Square Click	Square Click	Square Click	Square Click
	33 Metron Click	Metron Click	Metron Click	Metron Click	Metron Click
	34 Metron Bell	Metron Bell	Metron Bell	Metron Bell	Metron Bell
	35 Kick Drum 2	Kick Drum 2	Kick Drum 2	Power Kick2	Jazz Kick 2
	36 Kick Drum 1	Kick Drum 1	Kick Drum 1	Power Kick1	Jazz Kick 1
	37 Side Stick	Side Stick	Side Stick	Side Stick	Side Stick
	38 Reg.Snr 2	Snare 1	Snare 1	Power Snare1	Jazz Snare1
	39 Hand Clap	Hand Clap	Hand Clap	Hand Clap	Hand Clap
	40 Reg.Snr 1	Snare 2	Snare 2	Power Snare2	Jazz Snare2
	41 Reg.F.Tom	Low Tom 2	Low Tom 2	Low Tom 1	Low Tom 2
C3	42 ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]
	43 Reg.L.Tom	Low Tom 1	Low Tom 1	Low Tom 2	Low Tom 1
	44 Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]
	45 Reg.M.Tom	Mid Tom 2	Mid Tom 2	Mid Tom 1	Mid Tom 2
	46 Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]
	47 Reg.M.Tom	Mid Tom 1	Mid Tom 1	Mid Tom 2	Mid Tom 1
	48 Reg.H.Tom	High Tom 2	High Tom 2	High Tom 1	High Tom 2
	49 CrashCymbal1	CrashCymbal1	CrashCymbal1	CrashCymbal1	CrashCymbal1
	50 Reg.H.Tom	High Tom 1	High Tom 1	High Tom 2	High Tom 1
	51 Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1
C4	52 China Cymbal	China Cymbal	China Cymbal	China Cymbal	China Cymbal
	53 Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell
	54 Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
	55 SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal
	56 Cowbell	Cowbell	Cowbell	Cowbell	Cowbell
	57 CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2
	58 Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap
	59 Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2
	60 High Bongo	High Bongo	High Bongo	High Bongo	High Bongo
	61 Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo
C5	62 MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga
	63 OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga
	64 Low Conga	Low Conga	Low Conga	Low Conga	Low Conga
	65 High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
	66 Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
	67 High Agogo	High Agogo	High Agogo	High Agogo	High Agogo
	68 Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo
	69 Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
	70 Maracas	Maracas	Maracas	Maracas	Maracas
	71 ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
C6	72 Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
	73 Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
	74 Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
	75 Claves	Claves	Claves	Claves	Claves
	76 Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
	77 LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
	78 Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
	79 Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
	80 MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
	81 OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
C7	82 Shaker	Shaker	Shaker	Shaker	Shaker
	83 Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
	84 Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
	85 Castanets	Castanets	Castanets	Castanets	Castanets
	86 Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
	87 Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
	88 Applause	Applause	Applause	Applause	Applause
	89 SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1
	90 SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2
	91 Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1
C8	92 Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2
	93 Scratch1	Scratch1	Scratch1	Scratch1	Scratch1
	94 Scratch2	Scratch2	Scratch2	Scratch2	Scratch2
	95 Scratch3	Scratch3	Scratch3	Scratch3	Scratch3
	96 Hit1	Hit1	Hit1	Hit1	Hit1
	97 Hit2	Hit2	Hit2	Hit2	Hit2
	98 Hit3	Hit3	Hit3	Hit3	Hit3
	99 Hit4	Hit4	Hit4	Hit4	Hit4
	100 Hit5	Hit5	Hit5	Hit5	Hit5
	101 Low Tom1	Low Tom 1	Low Tom 1	Low Tom 1	Low Tom 1
102 Low Tom2	Low Tom 2	Low Tom 2	Low Tom 2	Low Tom 2	
103 Cajon1	Cajon1	Cajon1	Cajon1	Cajon1	
104 Cajon2	Cajon2	Cajon2	Cajon2	Cajon2	
105 Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	
106 Sweep Down	Sweep Down	Sweep Down	Sweep Down	Sweep Down	
107 Laser	Laser	Laser	Laser	Laser	
108 Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz	

* [EXC] : Percussion sound of the same number will not be heard at the same time.

	Brush Kit MSB: 84/LSB: 8/PC: 73	Machine Kit MSB: 84/LSB: 8/PC: 74	R&B T-Analog MSB: 84/LSB: 8/PC: 75	R&B Mini Kit MSB: 84/LSB: 8/PC: 76	HipHop Kit MSB: 84/LSB: 8/PC: 77
C1	22 MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1
	23 MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2
	Concert SD	Concert SD	Concert SD	Concert SD	Concert SD
	24 Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
	25 Snap	Snap	Snap	Snap	Snap
	26 High Q	High Q	High Q	High Q	High Q
	27 Slap	Slap	Slap	Slap	Mix Kick1
	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Analog Kick1
	29 Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Mix Snare4
	30 Sticks	Sticks	Sticks	Sticks	Analog Kick2
	31 Square Click	Square Click	Square Click	Square Click	Mix Snare3
	32 Metron Click	Metron Click	Metron Click	Metron Click	Mix Kick2
	33 Metron Bell	Metron Bell	Metron Bell	Metron Bell	HH Shaker [EXC 1]
C2	35 Jazz Kick 2	Ana.Kick 1	Ana.Kick 1	Kick 2	Mix Kick4
	Jazz Kick 1	Ana.Kick 2	Ana.Kick 2	Kick 1	Mix Kick3
	36 Side Stick	Ana.Rim Shot	Ana.Rim Shot	Side Stick	TR808 Rim
	37 Brush Tap	Ana.Snare	Ana.Snare	Snare 1	Mix Snare1
	38 Brush Slap	Hand Clap	Hand Clap	Hand Clap	TR808 Clap
	39 Brush Swirl	Elec.Snare	Elec.Snare	Snare 2	Mix Snare2
	40 Low Tom 2	Ana.Low Tom2	Ana.Low Tom2	Reg.F.Tom	Tom 1
	41 ClosedHi-hat [EXC 1]	Ana.CI HH 1 [EXC 1]	Ana.CI HH 1 [EXC 1]	ClosedHi-hat [EXC 1]	TR808 CIHH [EXC 1]
	42 Low Tom 1	Ana.Low Tom 1	Ana.Low Tom 1	Reg.L.Tom	Tom 2
	43 Pedal Hi-hat [EXC 1]	Ana.CI HH 2 [EXC 1]	Ana.CI HH 2 [EXC 1]	Pedal Hi-hat [EXC 1]	Noise CIHH [EXC 1]
	44 Mid Tom 2	Ana.Mid Tom2	Ana.Mid Tom2	Reg.M.Tom	Tom 3
	45 Open Hi-hat [EXC 1]	Ana.Open HH [EXC 1]	Ana.Open HH [EXC 1]	Open Hi-hat [EXC 1]	TR808 OpHH [EXC 1]
	46 Mid Tom 1	Ana.Mid Tom 1	Ana.Mid Tom 1	Reg.M.Tom	Tom 4
C3	47 High Tom 2	Ana.Hi Tom2	Ana.Hi Tom2	Reg.H.Tom	Tom 5
	48 CrashCymbal1	Ride Cymbal1	Ride Cymbal1	CrashCymbal 1	TR909 Cym
	49 High Tom 1	Ana.Hi Tom 1	Ana.Hi Tom 1	Reg.H.Tom	Tom 6
	50 Ride Cymbal1	Ana.Cymbal	Ana.Cymbal	Ride Cymbal1	TR808 Cym
	51 China Cymbal	China Cymbal	China Cymbal	China Cymbal	China Cymbal
	52 Ride Bell	Ride Bell	Ride Bell	Ride Bell	Rock Rd Edge
	53 Tambourine	Tambourine	Tambourine	Tambourine	Mix Perc
	54 SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal	Mix Crash 1
	55 Cowbell	Ana.Cowbell	Ana.Cowbell	Cowbell	Ana.Cowbell
	56 CrashCymbal2	CrashCymbal	CrashCymbal	CrashCymbal2	Mix Crash2
	57 Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Roll FX
	58 Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cym
C4	59 High Bongo	High Bongo	High Bongo	High Bongo	High Bongo
	60 Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo
	61 MuteHi Conga	Ana.Hi Conga	Ana.Hi Conga	MuteHi Conga	MuteHi Conga
	62 OpenHi Conga	Ana.MidConga	Ana.MidConga	OpenHi Conga	OpenHi Conga
	63 Low Conga	Ana.LowConga	Ana.LowConga	Low Conga	Low Conga
	64 High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
	65 Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
	66 High Agogo	High Agogo	High Agogo	High Agogo	High Agogo
	67 Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo
	68 Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
	69 Maracas	Ana.Maracas	Ana.Maracas	Maracas	Maracas
C5	70 ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
	71 Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
	72 Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
	73 Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
	74 Claves	Ana.Claves	Ana.Claves	Claves	Claves
	75 Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
	76 LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
	77 Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
	78 Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
	79 MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
	80 OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
	81 Shaker	Shaker	Shaker	Shaker	Shaker
C6	82 Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
	83 Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
	84 Castanets	Castanets	Castanets	Castanets	Castanets
	85 Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
	86 Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
	87 Applause	Applause	Applause	Applause	Applause
	88 SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1
	89 SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2
	90 Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1
	91 Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2
	92 Scratch1	Scratch1	Scratch1	Scratch1	Scratch1
	93 Scratch2	Scratch2	Scratch2	Scratch2	Scratch2
	94 Scratch3	Scratch3	Scratch3	Scratch3	Scratch3
C7	95 Hit1	Hit1	Hit1	Hit1	Hit1
	96 Hit2	Hit2	Hit2	Hit2	Hit2
	97 Hit3	Hit3	Hit3	Hit3	Hit3
	98 Hit4	Hit4	Hit4	Hit4	Hit4
	99 Hit5	Hit5	Hit5	Hit5	Hit5
	100 Low Tom 1	Low Tom 1	Low Tom 1	Low Tom 1	Low Tom 1
	101 Low Tom 2	Low Tom 2	Low Tom 2	Low Tom 2	Low Tom 2
	102 Cajon1	Cajon1	Cajon1	Cajon1	Cajon1
	103 Cajon2	Cajon2	Cajon2	Cajon2	Cajon2
	104 Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz
	105 Sweep Down	Sweep Down	Sweep Down	Sweep Down	Sweep Down
	106 Laser	Laser	Laser	Laser	Laser
C8	107 Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz
	108				

Rhythm Set List

* [EXC] : Percussion sound of the same number will not be heard at the same time.

	R&B Kit MSB: 84/LSB: 8/PC: 78	Dance Kit 1 MSB: 84/LSB: 8/PC: 79	Dance Kit 2 MSB: 84/LSB: 8/PC: 80	Dance Kit 3 MSB: 84/LSB: 8/PC: 81
	22	MC500 Beep1	MC500 Beep1	MC500 Beep1
		MC500 Beep2	MC500 Beep2	MC500 Beep2
		Concert SD	Concert SD	Concert SD
C1	24	25 Snare Roll	Snare Roll	Snare Roll
		Snap	Snap	Snap
		27 High Q	High Q	High Q
		TR808 Kick	TR909 Kick	SH32 Kick1
		HH Kick	SH32 Kick1	TR909 Kick1
		29 Mix Snare2	AnalogSnare	AnalogSnare1
		Mix Kick4	Analog Kick	Analog Kick1
		32 Short Snare2	TR808 Snare	TR808 Snare
		Mix Kick3	SH32 Kick2	SH32 Kick2
		34 TR808 Cl HH [EXC 1]	Syn ClHH1 [EXC 1]	Pedal Hihat [EXC 1]
		Mix Kick1	Mix Kick2	TR909 Kick2
		Mix Kick2	Mix Kick1	Analog Kick2
C2	36	37 Soft Stick	Mix Rim	Synth Rim
		Short Snare1	Mix Snare1	DistNz Snare
		39 Hand Clap	TR808 Clap	TR808 Clap
		Mix Snare1	Mix Snare2	DistNz Snare
		TR808 Tom1	Mix Tom1	Deep Tom1
		42 Cl Hihat1 [EXC 1]	Mix ClHH1 [EXC 1]	Syn ClHH1 [EXC 1]
		TR808 Tom2	Mix Tom2	Deep Tom2
		44 Cl Hihat2 [EXC 1]	Mix ClHH2 [EXC 1]	Syn ClHH2 [EXC 1]
		TR808 Tom3	Mix Tom3	Deep Tom3
		46 Op Hihat [EXC 1]	Op Hihat [EXC 1]	Syn OpHH [EXC 1]
		TR808 Tom4	Mix Tom4	Deep Tom4
		TR808 Tom5	Mix Tom5	Deep Tom5
C3	48	49 TR909 Cym	Mix Crash	TR808 OpHH
		TR808 Tom6	Mix Tom6	Deep Tom6
		51 TR808 Cym	Rock Rd Edge	Wide Syn Cym
		China Cymbal	China Cymbal	TR808 Cym1
		Rock Rd Edge	Ride Cymbal	Ride Cym1
		53 Mix Hat	Tambourine	Castanet
		54 Mix Crash1	Syn Splash	TR808 Cym2
		56 Ana.Cowbell	Cowbell	TR808Cowbell
		57 Mix Crash2	Concert Cym	Ride Cym2
		58 Vibra-slap	Vibraslap	Syn Cowbell
		Ride Cym	TR808 Cym	Ride Cym3
C4	60	High Bongo	High Bongo	High Bongo
		61 Low Bongo	Low Bongo	Low Bongo
		MuteHi Conga	MuteHi Conga	MuteHi Conga
		63 OpenHi Conga	OpenHi Conga	OpenHi Conga
		Low Conga	Low Conga	Low Conga
		High Timbale	High Timbale	High Timbale
		66 Low Timbale	Low Timbale	Low Timbale
		High Agogo	High Agogo	High Agogo
		68 Low Agogo	Low Agogo	Low Agogo
		69 Cabasa	Cabasa	Cabasa
		70 Maracas	Maracas	Maracas
		ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
		Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
C5	72	73 Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
		Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
		75 Claves	Claves	Claves
		Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
		LowWoodBlock	LowWoodBlock	LowWoodBlock
		78 Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
		Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
		80 MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
		OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
		82 Shaker	Shaker	Shaker
		Jingle Bell	Jingle Bell	Jingle Bell
		Bell Tree	Bell Tree	Bell Tree
C6	84	85 Castanets	Castanets	Castanets
		Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
		87 Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
		Applause	Applause	Applause
		SnareGhost1	SnareGhost1	SnareGhost1
		90 SnareGhost2	SnareGhost2	SnareGhost2
		Hand Clap1	Hand Clap1	Hand Clap1
		92 Hand Clap2	Hand Clap2	Hand Clap2
		Scratch1	Scratch1	Scratch1
		94 Scratch2	Scratch2	Scratch2
		Scratch3	Scratch3	Scratch3
C7	96	Hit1	Hit1	Hit1
		97 Hit2	Hit2	Hit2
		Hit3	Hit3	Hit3
		99 Hit4	Hit4	Hit4
		Hit5	Hit5	Hit5
		Low Tom1	Low Tom1	Low Tom1
		102 Low Tom2	Low Tom2	Low Tom2
		103 Cajon1	Cajon1	Cajon1
		104 Cajon2	Cajon2	Cajon2
		105 Syn Burst Nz	Syn Burst Nz	Syn Burst Nz
		106 Sweep Down	Sweep Down	Sweep Down
		107 Laser	Laser	Laser
C8	108	Syn Back Nz	Syn Back Nz	Syn Back Nz

* [EXC] : Percussion sound of the same number will not be heard at the same time.

	GM2 STANDARD MSB: 84/LSB: 8/PC: 82	GM2 ROOM MSB: 84/LSB: 8/PC: 83	GM2 POWER MSB: 84/LSB: 8/PC: 84	GM2 ELECTRIC MSB: 84/LSB: 8/PC: 85	GM2 ANALOG MSB: 84/LSB: 8/PC: 86
27	High Q	High Q	High Q	High Q	High Q
28	Slap	Slap	Slap	Slap	Slap
29	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]
30	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]
31	Sticks	Sticks	Sticks	Sticks	Sticks
32	Square Click	Square Click	Square Click	Square Click	Square Click
33	Metron Click	Metron Click	Metron Click	Metron Click	Metron Click
34	Metron Bell	Metron Bell	Metron Bell	Metron Bell	Metron Bell
35	Kick Drum 2	Kick Drum 2	Kick Drum 2	Kick Drum 2	Kick Drum 2
36	Kick Drum 1	Kick Drum 1	Power Kick	Elec.Kick	Ana.Kick
37	Side Stick	Side Stick	Side Stick	Side Stick	Ana.Rim Sho
38	Aco.Snare	Aco.Snare	PowerSnare	E.SnareDrum1	Ana.Snare
39	Hand Clap	Hand Clap	Hand Clap	Hand Clap	Hand Clap
40	Elec.Snare	Elec.Snare	Elec.Snare	E.SnareDrum2	Elec.Snare
41	Low Tom 2	Room LowTom2	PowerLowTom2	E.Low Tom 2	Ana.Low Tom2
42	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	Ana.ClosedHH [EXC 1]
43	Low Tom 1	Room LowTom1	PowerLowTom1	E.Low Tom 1	Ana.Low Tom1
44	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Ana.ClosedHH [EXC 1]
45	Mid Tom 2	Room MidTom2	PowerMidTom2	E.Mid Tom 2	Ana.Mid Tom2
46	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Ana.Open HH [EXC 1]
47	Mid Tom 1	Room MidTom1	PowerMidTom1	E.Mid Tom 1	Ana.Mid Tom1
48	High Tom 2	Room Hi Tom2	PowerHiTom2	E.Hi Tom 2	Ana.Hi Tom2
49	CrashCymbal1	CrashCymbal1	CrashCymbal1	CrashCymbal1	Ana.Cymbal
50	High Tom 1	Room Hi Tom1	PowerHiTom1	E.Hi Tom 1	Ana.Hi Tom1
51	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1
52	China Cymbal	China Cymbal	China Cymbal	Reverse Cym.	China Cymbal
53	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell
54	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
55	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal
56	Cowbell	Cowbell	Cowbell	Cowbell	Ana.Cowbell
57	CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2
58	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap
59	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2
60	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo
61	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo
62	MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga	Ana.Hi Conga
63	OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga	Ana.MidConga
64	Low Conga	Low Conga	Low Conga	Low Conga	Ana.LowConga
65	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
66	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
67	High Agogo	High Agogo	High Agogo	High Agogo	High Agogo
68	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo
69	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
70	Maracas	Maracas	Maracas	Maracas	Ana.Maracas
71	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
72	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
73	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
74	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
75	Claves	Claves	Claves	Claves	Ana.Claves
76	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
77	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
78	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
79	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
80	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
81	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
82	Shaker	Shaker	Shaker	Shaker	Shaker
83	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
84	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
85	Castanets	Castanets	Castanets	Castanets	Castanets
86	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
87	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
88	-	-	-	-	-

Rhythm Set List

* [EXC] : Percussion sound of the same number will not be heard at the same time.

	GM2 JAZZ MSB: 84/LSB: 8/PC: 87	GM2 BRUSH MSB: 84/LSB: 8/PC: 88	GM2 ORCHSTRA MSB: 84/LSB: 8/PC: 89	GM2 SFX MSB: 84/LSB: 8/PC: 54		
	27	High Q	High Q	ClosedHi-hat [EXC 1]	-	
		Slap	Slap	Pedal Hi-hat [EXC 1]	-	
		Scratch Push [EXC 7]	Scratch Push [EXC 7]	Open Hi-hat [EXC 1]	-	
	29	30	Scratch Pull [EXC 7]	Ride Cymbal1	-	
		Sticks	Sticks	Sticks	-	
		32	Square Click	Square Click	-	
		Metron Click	Metron Click	Metron Click	-	
		34	Metron Bell	Metron Bell	-	
		Jazz Kick 2	Jazz Kick 2	Concert BD 2	-	
		Jazz Kick 1	Jazz Kick 1	Concert BD 1	-	
C2		37	Side Stick	Side Stick	-	
		Aco.Snare	Brush Tap	Concert SD	-	
		39	Hand Clap	Brush Slap	Castanets	High Q
		Elec.Snare	Brush Swirl	Concert SD	Slap	
		Low Tom 2	Low Tom 2	Timpani F	Scratch Push [EXC 7]	
		42	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	Timpani F#	Scratch Pull [EXC 7]
		Low Tom 1	Low Tom 1	Timpani G	Sticks	
		44	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Timpani G#	Square Click
		45	Mid Tom 2	Mid Tom 2	Timpani A	Metron Click
		46	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Timpani A#	Metron Bell
		Mid Tom 1	Mid Tom 1	Timpani B	GtFret Noise	
		High Tom 2	High Tom 2	Timpani c	Cut Noise Up	
C3		49	CrashCymbal1	CrashCymbal1	Timpani c#	Cut Noise Dw
		High Tom 1	High Tom 1	Timpani d	Slap St.Bass	
		51	Ride Cymbal1	Ride Cymbal1	Timpani d#	Fl.Key Click
		China Cymbal	China Cymbal	Timpani e	Laughing	
		Ride Bell	Ride Bell	Timpani f	Scream	
		54	Tambourine	Tambourine	Tambourine	Punch
		SplashCymbal	SplashCymbal	SplashCymbal	Heart Beat	
		56	Cowbell	Cowbell	Cowbell	Footsteps 1
		CrashCymbal2	CrashCymbal2	Concert Cym2	Footsteps 2	
		58	Vibra-slap	Vibra-slap	Vibra-slap	Applause
		Ride Cymbal2	Ride Cymbal2	Concert Cym1	Door Creak	
		High Bongo	High Bongo	High Bongo	Door	
C4		61	Low Bongo	Low Bongo	Low Bongo	Scratch
		MuteHi Conga	MuteHi Conga	MuteHi Conga	Wind Chimes	
		63	OpenHi Conga	OpenHi Conga	OpenHi Conga	Car Engine
		Low Conga	Low Conga	Low Conga	Car Stop	
		High Timbale	High Timbale	High Timbale	Car Pass	
		66	Low Timbale	Low Timbale	Low Timbale	Car Crash
		High Agogo	High Agogo	High Agogo	Siren	
		68	Low Agogo	Low Agogo	Low Agogo	Train
		Cabasa	Cabasa	Cabasa	Jetplane	
		70	Maracas	Maracas	Maracas	Helicopter
		ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	Starship	
		Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Gun Shot	
C5		73	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Machine Gun
		Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Lasergun
		75	Claves	Claves	Claves	Explosion
		Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Dog	
		LowWoodBlock	LowWoodBlock	LowWoodBlock	Horse Gallop	
		78	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Birds
		Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Rain
		80	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	Thunder
		OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	Wind
		82	Shaker	Shaker	Shaker	Seashore
		Jingle Bell	Jingle Bell	Jingle Bell	Stream	
		Bell Tree	Bell Tree	Bell Tree	Bubble	
C6		85	Castanets	Castanets	Castanets	-
		Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	-
		87	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	-
		88	-	-	Applause	-