



# Sip & Puff setup for MacOS

## Adding switch actions to the mouthpieces

The Sip & Puff device works with switch-control in MacOS. A few actions use regular key-strokes, and for a few we need to set-up specific switch controls to make browsing faster and easier.

1. Go to system preferences and choose Accessibility
2. Now turn on “**Switch Control**”
3. The Switch control modal will appear on screen
4. Now connect the sip & puff device to an USB port of your Macbook
5. Scroll down in the “**Switch control**” modal, and find “**Switches**”
6. If no “**Space Input**” switch is listed add a new Switch by clicking +
7. When a switch is requested, puff on the most left mouthpiece
8. Then select “**Select item**” as action
9. Click + again to add a new switch
10. Puff on the second mouthpiece from the left when a switch is requested
11. Select “**Move To Next Item**” as action
12. Click + again to add a new switch
13. When a switch is requested, sip on the most left mouthpiece
14. Select “**Restart from top**” as action
15. Click + again to add a new switch
16. When a switch is requested, sip on the 3rd mouthpiece from the left
17. Select “**Open application...**” as action
18. in the Finder popup select **Google Chrome** in your application folder
19. The switch actions should now contain 4 items



# Sip and Puff


1	2	3	4
0	0	0	0

1. **Sip:**  return to top

**Puff:**  select item

2. **Sip:** Press return

**Puff:**  Next item


3. **Sip:**  Open Google Chrome

**Puff:** Press delete

4. **Sip:** Press shift tab

**Puff:** Press tab

 : Switch control

 : Google Chrome browser

When the red light is on the Sip & Puff device is calibrating and no Sip or Puff actions are recorded