


USER MANUAL

The menu is a choice of three options:

- 1) static light
- 2) continuous change
- 3) flashing
- 4) exit



The Main Menu

To change a zoom of the text of the program, click the BLUE button in the Main Menu.


STATIC LIGHT:

is a menu for selecting the color of the lamp 1 and lamp 2, setting the lamps at the same time, and also provides the ability to copy the current state of the lamp to another.


To adjust the lamp colors, press RED button and scroll through the parameters you need. To apply the changes, click BLUE button.

To make a copy, simply press RED button of the desired menu item.

To exit to the main menu, press GREEN button.



STATIC LIGHT Menu



CONTINUOUS CHANGE Menu

CONTINUOUS CHANGE:

is a menu to select two colors for which the change will be made within a certain time.

To select the first and second color, press RED button and scroll to the color you want.

To set the time for the color change, select Time and set the time for the color change.

To turn on the change of the first lamp, press RED button on LED1 in the menu. For the second lamp is LED2.

To light both lamps together, press LED1&LED2.

To turn on lamps in antiphase, click ANTI-PHASE.

To stop all the effects click STOP ALL.

FLASHING:

is a menu to create a glint static light, long glow, as well as the glow with a time shift.

If you chose the time of constant glow, press RED to set TIME "ON", scroll and adjust the glow time.

To set the off time, click TIME "OFF" and set the off time.

To set the time shift time, select SHIFT TIME in the menu and adjust the shift time.



FLASHING Menu

To start the first lamp, press RED button on LED1 in the menu. To start the second lamp is LED2.

To light both lamps together, press LED1&LED2.

To turn on lamps with the time offset, click LEDs+OFFSET.

To stop all the effects click STOP ALL.