


The circuit diagram shows the output section of a tone generator. It includes a CD4093 U2C Schmitt trigger, which is configured as a monostable multivibrator. The output of the CD4093 (pin 10) is connected to a network of resistors (R10, R11) and capacitors (C5, C6) that controls the timing of the output pulse. The output is then connected to a speaker (J9) through a volume control potentiometer (VOLUME1) and a coupling capacitor (C7). The circuit is powered by a 5V supply and ground.



Sheet: /		
File: Bebe.sch		
Title: Bebe		
Size: A4	Date: 2019-09-17	Rev: 0.0
KiCad E.D.A. kicad 4.0.7		Id: 1/1