

Instructions for the SeeBox

Powering on:

1. Press and hold the lowest button between four on the side of the box to turn it on. You will hear an indication sound.
2. Right after the sound (not later than around 30 seconds after you pressed the power button) insert the headphone jack key to the plug on the top edge of the box. Leave it there for as long as you are using the device.
3. A greeting message will play.
(Sometime the message doesn't play, the device should work fine even without that. Mostly pay attention to the on and off melodic indications.)

Connecting:

1. Make sure your phone's bluetooth is on. Open the "SeeBox" app.
2. In the app, click the "Connect" button.
3. If it could connect successfully, a message will tell you "Successfully connected to the SeeBox". Press Ok.
4. If it could not connect, no message will pop up. Try clicking the button again or close the app and power off and on the box.

Note: Unfortunately at the moment, there is no indication on the system of whether you are outside of the bluetooth range. Therefore, if you are too far away from the device and you could not connect to it, move closer and try again.

Using:

1. Use the buttons labeled "Volume up" and "Volume down" on the app to adjust the volume. You will hear an indication of the chosen volume after every press on the button.
2. For changing the volume directly from the device, use the two middle buttons between the four on the side of the box (above the power button).

(Please note that the volume change from the app and the device are not directly related to each other, but they are accumulative. So if you want to get the highest possible volume, you should turn up the volume to the maximum on BOTH the app and the device).

3. Use "Find my SeeBox" button on the app to start making the sound.
4. For muting the sound, you can use the "Mute" button on the phone and wait for the end of the current playing melody for it to stop.
5. If you want to mute the sound directly from the device, use the top button between the four buttons on the side and it will mute the speaker. However, you should use the "mute" button on the app to completely stop the device from making sound. Otherwise,

the sound will continue playing after you unmute the speaker by pressing the button one more time on the box.

6. Use “change track” on the app to alternate between two tracks on the Seebox. The selected track will playing once after clicking that button.

Powering off:

1. Press and hold the power button. There will be a sound indication.
2. Take the headphone jack key out and the device will shut off completely.

Charging:

Use the micro-usb cable and connect it to the plug on the top edge of the box. There is no auditory indication of a fully charged device, but it should not take more than 3-4 hours of charging for the device to become full battery. Try to charge it every two/three days.