

RC SERIES

PARTS LIST

VERSION 1.0

JUNE, 1992

PARTS LIST I

INDEX..... II


[ATTENTION]

- ★ If you want to order spare parts, please make sure of what is the spare parts you want referring to Parts List, and never fail to inform us the number, name and quantity of the spare parts you want referring to Index.
- ★ It should be agreed that some parts will be modified or added without prior information.
- ★ The parts composing of an unit are marked ' * ' before their names and arranged just below the name of the unit.
In case the parts marked with ' * ' is also an assembly, its components are marked ' * * ' before their names.
- ★ As the not-numbered parts in Part List can't be ordered, please order the unit including the not-numbered parts if you want them.
- ★ The actual parts to be shipped may differ in parts number in the last three digits from those on this parts list , but they are compatible.

I. PARTS LIST

Fig. 1.	MAIN BODY AREA: (RC4000, RC4500, RC5600/D)	2
Fig. 2	MAIN BODY AREA: (RC5800)	4
Fig. 3	MAIN BODY AREA: (RC6300)	6
Fig. 4	ELEVATOR-SCRAPER AREA	8
Fig. 5	PAPER-FEED TRAY	10
Fig. 6	DRIVE MECHANISM AREA	12
Fig. 7	ROLLER SYSTEM AREA: (RC4000, RC4500, RC5600/D, RC5800)	16
Fig. 8	ROLLER SYSTEM AREA: (RC6300)	18
Fig. 9	SQUEEGEE-INK PUMP UNIT AREA	20
Fig. 10	DRUM-SCREEN AREA	24
Fig. 11	LOCK LEVER AREA: (RC4000, RC4500, RC5600/D, RC5800)	26
Fig. 12	LOCK LEVER AREA: (RC6300)	28
Fig. 13	CLAMP-PRESSURE CONTROL AREA	30
Fig. 14	SEPARATOR AREA	32
Fig. 15	SUCTION UNIT: (RC4000, RC4500, RC5600/D, RC5800)	34
Fig. 16	SUCTION UNIT: (RC6300)	36
Fig. 17	PAPER RECEIVING TRAY	38
Fig. 18	SCANNER AREA (1): (RC4000)	40
Fig. 19	SCANNER AREA (2): (RC4000)	42
Fig. 20	SCANNER AREA (1): (RC4500, RC5600/D)	44
Fig. 21	SCANNER AREA (2): (RC4500, RC5600/D)	46
Fig. 22	SCANNER AREA (3): (RC4500, RC5600/D)	48
Fig. 23	SCANNER AREA (1): (RC5800, RC6300)	50
Fig. 24	SCANNER AREA (2): (RC5800)	54
Fig. 25	SCANNER AREA (2): (RC6300)	56
Fig. 26	ADF AREA (1): (RC5800, RC6300)	58
Fig. 27	ADF AREA (2): (RC5800, RC6300)	60
Fig. 28	MASTER-MAKING AREA (1): RC4000, RC4500, RC5600/D, RC5800)	64
Fig. 29	MASTER-MAKING AREA (2): (RC4000)	66
Fig. 30	MASTER-MAKING AREA (2): (RC4500, RC5600/D, RC5800)	68
Fig. 31	MASTER-MAKING AREA (1): (RC6300)	70
Fig. 32	MASTER-MAKING AREA (2): (RC6300)	72
Fig. 33	CUTTER UNIT: (RC4000, RC4500, RC5600/D, RC5800)	74
Fig. 34	CUTTER UNIT: (RC6300)	76
Fig. 35	MASTER REMOVAL UNIT: (RC4000, RC4500, RC5600/D, RC5800)	78
Fig. 36	MASTER REMOVAL UNIT: (RC6300)	80
Fig. 37	MASTER DISPOSAL BOX	82
Fig. 38	ELECTRICAL COMPONENT AREA (1): (RC4000)	84
Fig. 39	ELECTRICAL COMPONENT AREA (1): (RC4500, RC5600/D)	86
Fig. 40	ELECTRICAL COMPONENT AREA (1): (RC5800)	88
Fig. 41	ELECTRICAL COMPONENT AREA (1): (RC6300)	90
Fig. 42	ELECTRICAL COMPONENT AREA (2): (RC4000, RC4500, RC5600/D)	92
Fig. 43	ELECTRICAL COMPONENT AREA (2): (RC5800, RC6300)	94
Fig. 44	EXTERIOR COVER AREA: (RC 4000, RC4500, RC5600/D)	96
Fig. 45	EXTERIOR COVER AREA: (RC5800, RC6300)	98
Fig. 46	EXTERIOR COVER AREA (ADF): (RC5800, RC6300)	100
Fig. 47	DIGITIZER: (RC5800, RC6300)	102

Fig. 1 MAIN BODY AREA (RC4000, RC4500, RC5600/D)




No.	Part No.	Part Name	Q'ty	Remark
1		Main Side Frame	1	
	011-93110-009	Magnet Catch Ass'y; P.-Rcv.-T.		
2	011-13122-001	* Bracket; Magnet Catch; P.-Rcv.-T.	1	
3	660-05000-018	* Magnet Catch SM50P	2	
4	011-16101-102	Rail (Left)	1	
5	011-16109-006	Rail Edge (Left)	1	
6	011-16102-109	Rail (Right)	1	
7	011-16110-004	Rail Edge L (Right)	1	
8	011-16111-000	Rail Edge S (Right)	1	
10	011-16037-005	Stopper III; Scanner	1	
11	011-15272-000	Spacer; Magnet Catch	1	
12	011-11112-009	Bracket R; Suction	1	
13	011-11111-002	Bracket F; Suction	1	
14	011-13146-008	Set Plate R; P.-Rcv.T.	1	
15	011-13144-005	Set Plate F; P.-Rcv.T.	1	
16	011-17206-005	Bracket E; Keyboard	1	
17	011-17209-004	Set Plate; Front Right Cover	2	
18	011-17205-106	Bracket D; Keyboard	1	
19	011-17204-002	Bracket C; Keyboard	2	
20	011-17201-003	Upper Hinge	1	
21	011-17208-202	Bottom Plate (Right)	1	
22	011-17207-109	Bracket; Hinge	1	
23	660-01000-200	Rubber Foot K-45	4	
24	011-11113-102	Bottom Cover	1	
25	011-14120-002	Front Cover; M.-Rmv.	1	
26	011-17213-400	Bottom Plate (Left)	1	
27	011-15080-004	Bracket; Wire Harness	1	
28	011-17229-102	Mount; Connector; 200 V	1	
28	011-17230-003	Mount; Connector; 100 V	1	
29	011-17219-000	Blind Plate A; Connector	2	
30	011-17220-008	Blind Plate B; Connector	1	
31	011-16103-105	Upper Rear Frame	1	
33	011-16112-007	Bracket A; Micro-SW	1	
34	443-00120-501	Micro-SW; E21-51N	1	
35	011-60022-007	Switch A	1	

[illegible]

Fig. 2 MAIN BODY AREA (RC5800)

I-4




No.	Part No.	Part Name	Q'ty	Remark
1		Main Side Frame	1	
2	011-13122-001	Bracket; Magnet Catch; P.-Rcv.-T.	1	
3	660-05000-018	Magnet Catch SM50P	2	
4	011-15272-000	Spacer; Magnet Catch	2	
	012-96070-005	Rail (Left) Ass'y; 58		
5	012-16110-109	* Rail (Left); 58	1	
6-1	012-16121-003	* Rail Bracket (Left)	1	
	012-96065-001	Rail (Right) Ass'y; 58		
6-2	012-16120-309	* Rail Bracket (Right)	1	
7	012-16109-100	* Rail (Right); 58	1	
8	011-11112-009	Bracket R; Suction	1	
9	011-11111-002	Bracket F; Suction	1	
10	011-13146-008	Set Plate R; P.-Rcv.-T.	1	
11	011-13144-005	Set Plate F; P.-Rcv.-T.	1	
12	011-17206-005	Bracket E; Keyboard	1	
13	011-17209-004	Set Plate; Front Right Cover	2	
14	011-17205-106	Bracket D; Keyboard	1	
15	011-17204-002	Bracket C; Keyboard	2	
16	011-17201-003	Upper Hinge	1	
17	011-17208-202	Bottom Plate (Right)	1	
18	011-17207-109	Bracket; Hinge	1	
19	660-01000-200	Rubber Foot K-45	4	
20	012-16115-003	Support Cover	2	
21	011-11113-102	Bottom Cover	1	
22	665-02010-000	Clamp DKN-16	4	
23	011-14120-002	Front Cover; M.-Rmv.	1	
24	011-17213-400	Bottom Plate (Left)	1	
25	011-17220-008	Blind Plate B; Connector	3	
26	011-15080-004	Bracket; Wire Harness	1	
27	011-17229-102	Mount; Connector; 200V	1	
27	011-17230-003	Mount; Connector; 100V	1	
28	011-17219-000	Blind Plate A; Connector	2	
	012-96041-200	Upper Rear Frame Ass'y; 58		
29	012-16101-401	* Upper Rear Frame; 58	1	
30	443-00121-206	* Micro-SW; E21-51S	2	

[illegible]

Fig. 3 MAIN BODY AREA (RC6300)


9-I



No.	Part No.	Part Name	Q'ty	Remark
1		Main Side Frame	1	
	014-93110-000	Magnet Catch B Ass'y; P.Rcv.-T.		
2	014-13410-009	* Bracket B; Magnet Catch; P.-Rcv.-T.	1	
3	660-05000-018	* Magnet Catch SM50P	1	
	011-93110-009	Magnet Catch Ass'y; P.-Rcv.-T.		
4	011-13122-001	* Bracket; Magnet Catch; P.-Rcv.-T.	1	
5	660-05000-018	* Magnet Catch SM50P	1	
	014-96070-000	Rail (Left) Ass'y; A3		
6	012-16110-109	* Rail (Left); 58	1	
7	014-16006-004	* Rail Bracket (Left); A3	1	
8	012-16117-006	* Stopper B; 58	1	
	012-96065-001	Rail (Right) Ass'y; 58		
9	012-16120-309	* Rail Bracket (Right)	1	
10	012-16109-100	* Rail (Right); 58	1	
11	012-16117-006	* Stopper B; 58	1	
12	014-11112-000	Bracket R; Suction; A3	1	
13	014-11111-004	Bracket F; Suction; A3	1	
14	014-13403-100	Set Plate R; P.-Rcv.-T.; A3	1	
15	014-13401-107	Set Plate F; P.-Rcv.-T.; A3	1	
16	011-17206-005	Bracket E; Keyboard	1	
17	011-17209-004	Set Plate; Front Right Cover	2	
18	011-17205-106	Bracket D; Keyboard	1	
19	011-17204-002	Bracket C; Keyboard	2	
21	011-17201-003	Upper Hinge	1	
22	011-17208-202	Bottom Plate (Right)	1	
23	011-17207-109	Bracket; Hinge	1	
24	660-01000-200	Rubber Foot K-45	4	
25	012-16115-003	Support Cover	2	
26	665-02010-000	Clamp DKN-16	3	
27	014-11114-003	Bottom Cover; A3	1	
28	014-14119-103	Front Cover; M.-Rmv.; A3	1	
29	011-17213-400	Bottom Plate (Left)	1	
30	011-17220-008	Blind Plate B; Connector	3	
31	014-15161-103	Bracket; Wire Harness	1	
	011-97241-000	Mount Ass'y; Connector; 100 V		

[illegible]


Fig. 4 ELEVATOR-SCRAPER AREA



No.	Part No.	Part Name	Q'ty	Remark
	011-91810-003	Scraper Ass'y		
	014-91810-005	Scraper Ass'y; A3		
1	011-91814-009	* Shaft; Pickup Roller	1	
1	014-91814-000	* Shaft; Pickup Roller; A3	1	RC6300
2	011-11522-002	* Paper Guide Roller	6	
3	000-06123-007	* Stopper; Paper Guide Roller	6	
4	011-11816-103	* Collar; Shaft; Pickup Roller	1	
5	011-11805-004	* Holder Plate; Scraper	1	
6	607-16000-802	* Metal; F10 x 18/16 x 5; 22 x 1.5	4	
7	011-91812-006	* Shaft; Scraper	1	
8	620-31776-002	* Belt; 177-3M-6	1	
	011-11817-002	* Pickup Roller Ass'y	1	
9	006-11332-009	** Core; Pickup Roller	2	
10	011-11818-009	** Rubber Roller; Pickup	2	
	011-91820-009	Upper Limit Sensor Ass'y		
11	011-11806-000	* Bracket; Upper Limit Sensor	1	
12	011-60029-001	* Upper Limit Sensor	1	
	011-91850-005	Paper Det. Sensor (Receive) Ass'y		
13	011-11814-003	* Bracket; Paper Det. Sensor (Receive)	1	
14	011-60002-103	* Paper Det. Sensor (Receive)	1	
15	011-60001-204	Paper Det. Sensor (Send)	1	
	011-91830-004	P.-F. Pressure Adj. Lever Ass'y		
16	011-11807-007	* Bracket; P.-F. Pressure Adj. Lever	1	
17	011-11810-008	* P.-F. Pressure Adj. Lever	1	
18	011-11815-000	* Spring; P.-F. Pressure Adj. Lever	1	
19	011-11811-209	Spring; P.-F. Pressure	1	
20	011-91610-004	Shaft; Elevator	1	
20	014-11601-001	Shaft; Elevator; A3	1	RC6300
	011-91620-107	Unit/Elevator Motor		
21	011-65001-105	* Elevator Motor	1	
22	002-11715-006	* Bevel Gear; Elevator	1	
23	011-11606-001	* Bracket; Elevator Motor	1	
24	443-00120-706	* Micro-SW; E21-92N	1	
39	011-11610-009	* Bracket; Lower Limit SW	1	
25	607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	2	

[illegible]


Fig. 5 PAPER-FEED TRAY



No.	Part No.	Part Name	Q'ty	Remark
	011-91500-004	Unit/Paper-Feed Tray		
	011-91520-005	Unit/Paper-Feed Tray; 100US		U.S.A.
	014-91500-006	Unit/Paper-Feed Tray; A3		
	014-91520-007	Unit/Paper-Feed Tray; A3; US		U.S.A.
1	011-11510-004	* Side Guide L; P.-F.-T.	1	
2	011-11509-006	* Side Guide R; P.-F.-T.	1	
3	011-11515-006	* Slide Sheet; P.-F.-T.	4	
4	011-11504-101	* Paper Feed Tray	1	
4	014-11504-103	* Paper Feed Tray; A3	1	RC6300
4	014-41528-007	* Paper Feed Tray; A3; US	1	RC6300 U.S.A
5	011-11516-002	* L.O. Sheet	1	
6	011-11511-000	* Slide Rack; P.-F.-T.	2	
6	014-11511-002	* Slide Rack; P.-F.-T.; A3	2	RC6300
7	011-11517-009	* Spring; Slide Rack	2	
8	011-11513-003	* Collar; Slide Rack; P.-F.-T.	4	
9	011-11512-104	* Link Plate; Side Guide; P.-F.-T.	2	
10	011-11514-000	* Gear; Slide Rack; P.-F.-T.	1	
11	011-11524-005	* Adj. Dial	1	
12	011-11503-008	* Shaft B; P.-F.-T.	1	
12	014-11503-000	* Shaft B; P.-F.-T.; A3	1	RC6300
13	011-11501-102	* Bracket; P.-F.-T.	1	
13	014-11501-007	* Bracket; P.-F.-T.; A3	1	RC6300
14	600-50059-017	* Bearing; FLW 688ZZ	2	
15	011-11502-001	* Shaft A; P.-F.-T.	1	
15	014-11502-003	* Shaft A; P.-F.-T.; A3	1	RC6300
16	011-11523-106	* Adj. Nut; P.-F.-T.	1	
17	011-11527-004	* Support Plate L; Feed Board	1	
18	011-11526-008	* Support Plate R; Feed Board	1	
19	011-11529-007	* Feed Board Cover	1	
19	014-11529-009	* Feed Board Cover; A3	1	RC6300
20	011-11528-000	* Feed Board	1	
20	011-41528-005	* Feed Board; 100US	1	U.S.A.
20	014-11528-100	* Feed Board; A3	1	RC6300
21	011-11532-105	* Nut Holder	1	
22	014-11533-006	* Spring; Slide Rack; A3	1	

[illegible]

Fig. 6 DRIVE MECHANISM AREA



No.	Part No.	Part Name	Q'ty	Remark
	011-91200-108	Unit/Main Motor		
1	011-91203-000	* Main Motor Ass'y; SU	1	
	011-60027-106	** Photoelectron Disc.	1	
	011-60026-002	** Encoder Sensor	1	
2	002-11220-007	* Cam; Guide Roller	1	
3	011-11240-309	* Cam; Timing Roller	1	
	014-91220-003	Unit/Drive		All RC Model
4	011-11204-000	* Base Plate; P.-F. Clutch	1	
5	002-11242-000	* Idler	3	
6	002-11227-001	* Spacer; Slide Plate	3	
7	011-11201-001	* Unit/P.-F. Clutch	1	
8	011-11208-006	* Base Shaft Plate; Slide Plate	1	
9	002-11244-003	* Idler Pulley	4	
10	006-11222-009	* Slide Plate (Base)	1	
11	002-11225-009	* Support Block; Slide Plate	2	
12	006-11224-109	* Slide Plate (Front)	1	
13	011-11231-008	* Shaft Block; Slide Plate	1	
14	011-11230-001	* Shaft; Slide Plate	1	
15	638-90616-005	* Washer; 6.1 x 12 x 1.6	1	
16	607-13000-003	* Metal; F6 x 10/9 x 4; 12 x 1.5	2	
17	011-11220-006	* Shaft Base Block; Slide Plate	1	
18	011-11232-004	* Gear; Slide Plate	1	
19	011-11227-000	* Reinforce Plate; Slide Plate	1	
20	443-30000-500	Sensor; OS3701R-03	1	
21	014-11203-006	* Bracket; Pressure Det. Sensor; A3	1	RC6300
21	011-11239-009	* Bracket; Pressure Det. Sensor	1	
22	620-48309-009	* Belt; 830-5M-15	1	
23	002-11291-109	* Sector Gear	1	
24	011-11296-002	Spring; Sector Gear	1	
	014-91225-005	Main Shaft Ass'y; A3		RC6300
25	011-11212-003	* Main Pulley; Main Shaft	1	RC6300
26	011-11238-002	* Disc Plate; Main Shaft	1	RC6300
27	014-11207-001	* Cam; Pressure Roller II; A3	1	RC6300
	011-91225-100	Main Shaft Ass'y; B4		
25	011-11212-003	* Main Pulley; Main Shaft	1	


No.	Part No.	Part Name	Q'ty	Remark
26	011-11238-002	* Disc Plate; Main Shaft	1	
27	011-11258-003	* Cam; Pressure Roller; B4	1	
	011-91226-000	Main Shaft Ass'y; A4		
25	011-11212-003	* Main Pulley; Main Shaft	1	
26	011-11238-002	* Disc Plate; Main Shaft	1	
27	011-11257-007	* Cam; Pressure Roller; A4	1	
28	006-11216-009	Bearing House A; Main Shaft	1	
29	011-11249-209	Face Plate; Main Shaft	1	
	011-91250-008	Paper Feed Clutch Sensor Ass'y		
30	443-30000-403	* Sensor; OS3705-02	1	
31	011-11243-006	* Bracket; P Disc Sensor	1	
32	011-11235-003	P Disc	1	
33	011-91235-009	Face Plate; Pressure Shaft	1	
34	620-37506-007	Belt; 750-3M-6	1	
	014-91230-009	Pressure Link Ass'y		
35	002-11247-100	* Pressure Link; Top	1	
36	011-11241-100	* Pressure Link; Bottom	1	
37	204-03310-019	* Spacer; Paper Feed Clutch	2	
38	002-11250-100	* Stopper Shaft	1	
39	002-11251-204	* Spring Hanger Shaft	1	
40	014-11204-002	* Spring II; Pressure Link	1	
41	014-11205-009	* Pressure Adj. Screw II	1	
42	607-50800-109	* Washer; TW0815	1	
43	011-11245-009	* Gear; Pressure Adj. Screw	1	
44	002-11255-013	* Linking Plate; Drive Base	1	
45	600-50061-003	* Bearing; FL608ZZ	1	
46	002-11303-000	* Spring B; Pressure Link	1	
47	011-11276-206	* Hook Lever	1	
48	011-11270-003	* Shaft; Hook Lever	1	
49	002-11304-006	* Spring; Hook Lever	1	
50	011-11289-006	* Bracket; Hook Lever Spring	1	
51	011-11280-009	* Pressure Hook	1	
52	002-11259-108	* Connecting Shaft; Link	1	
	011-91208-109	Pressure Det. Ass'y		
53	011-11248-105	* Bracket; Pressure Control	1	

[illegible][illegible]

M E M O

1-15


Fig. 7 ROLLER SYSTEM AREA (RC4000, RC4500, RC5600/D, RC5800)



No.	Part No.	Part Name	Q'ty	Remark
1	011-91420-000	Pressure Roller Ass'y; B4	1	
1	011-91421-007	Pressure Roller Ass'y; A4	1	
	011-91410-102	Pressure Shaft Ass'y; B4		
	011-91411-001	Pressure Shaft Ass'y; A4		
2	011-91412-008	* Pressure Shaft	1	
3	002-11405-007	* Center Shaft; Pressure	1	
4	011-11403-208	* Pressure Roller Support	1	
5	006-11312-008	* Support Collar; R3	2	
6	002-11402-008	* Adjuster; Press.-Roll. Support	2	
7	002-11404-108	* Roller Holder; Pressure	4	
8	011-11409-001	* Guide Cover; Pressure; B4	1	
8	011-41409-006	* Guide Cover; Pressure; A4	1	
9	011-11404-000	* De-electricity Brush; B4	1	
9	011-41404-004	* De-electricity Brush; A4	1	
	011-91320-006	Guide Roller Ass'y		
10	011-11301-006	* Guide Roller	1	
11	006-11306-008	* Gear A; Guide Roller	1	
12	002-11412-003	* Shaft Catch; Guide Roller	1	
13	002-11210-109	* Load Spring; Guide Roller	1	
14	006-11304-005	* Guide Shaft	1	
15	006-11305-109	* One-Way Spring	1	
16	006-11303-009	* Gear; Guide Roller	1	
17	600-50059-017	Bearing; FLW688ZZ	1	
	011-91310-000	Timing Roller Ass'y		
18	006-11301-006	* Timing Roller	1	
19	607-05000-207	* Metal; S6 x 12 x 10M	2	
20	006-11307-004	* Gear B; Timing Roller	1	
21	011-11302-002	* Shaft; Timing Roller	1	
22	000-01326-007	* Timing Roller Supporter	2	
23	002-11428-007	* Roller Stopper A; Timing	1	
24	002-11429-003	* Roller Stopper B; Timing	1	
25	607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	2	
27	000-01327-003	Adj. Plate; Guide Roller	1	
28	000-01328-000	Adj. Eccentric; Guide Roller	1	
	011-91700-208	Unit/Guide Plate		

[illegible]


Fig. 8 ROLLER SYSTEM AREA (RC6300)



No.	Part No.	Part Name	Q'ty	Remark
1	014-91420-002	Pressure Roller Ass'y; A3	1	
	014-91410-104	Pressure Shaft Ass'y; A3		
2	014-91412-000	* Pressure Shaft; A3	1	
3	002-11405-007	* Center Shaft; Pressure	1	
4	014-11406-101	* Pressure Roller Support; A3	1	
5	014-11410-001	* Support Collar; A3	2	
6	002-11402-008	* Adjuster; Press.-Roll. Support	2	
7	002-11404-108	* Roller Holder; Pressure	4	
8	014-11404-001	* Guide Cover; Pressure; A3	1	
9	014-11405-008	* De-electricity Brush; A3	1	
	014-91320-008	Guide Roller Ass'y; A3		
10	014-11301-105	* Guide Roller; A3	1	
11	006-11306-008	* Gear A; Guide Roller	1	
12	002-11412-003	* Shaft Catch; Guide Roller	1	
13	002-11210-109	* Load Spring; Guide Roller	2	
14	006-11304-005	* Guide Shaft	1	
15	006-11305-109	* One-Way Spring	1	
16	006-11303-009	* Gear; Guide Roller	1	
17	600-50059-017	Bearing; FLW688ZZ	1	
	014-91310-002	Timing Roller Ass'y; A3		
18	014-11303-000	* Timing Roller; A3	1	
19	607-05000-207	* Metal; S6 x 12 x 10 M	2	
20	006-11307-004	* Gear B; Timing Roller	1	
21	014-11302-101	* Shaft; Timing Roller; A3	1	
22	000-01326-007	* Timing Roller Supporter	2	
23	002-11428-007	* Roller Stopper A; Timing	1	
24	002-11429-003	* Roller Stopper B; Timing	1	
25	607-15000-000	Metal; F8 x 13/12 x 5; 16 x 2	2	
26	000-01327-003	Adj. Plate; Guide Roller	1	
27	000-01328-000	Adj. Eccentric; Guide Roller	1	
	014-91700-005	Unit/Guide Plate; A3		
28	014-11701-006	* Guide Plate (Lower); A3	1	
29	014-11714-000	* Guide Plate (Upper); A3	1	
30	011-11718-101	* Sheet; Guide Plate	1	
31	011-11717-105	* Bracket; Paper Buckle Det. Sensor	1	

[illegible]

Fig. 9 SQUEEGEE-INK PUMP UNIT AREA



No.	Part No.	Part Name	Q'ty	Remark
		Unit/Squeegee		
1	011-12204-101	* Squeegee Stay	1	
1	014-12201-007	* Squeegee Stay; A3	1	RC6300
2	000-02254-506	* Ink Blocking Plate (Front)	1	
3	002-12219-002	* Adj. Boss; Ink Blocking	2	
4	002-12208-000	* Adj. Plate (Front); Squeegee	1	
5	002-12217-000	* Reverse Rotation Stopper A	1	
6	640-60080-001	* O Ring; P8-1.9	2	
7	607-16000-918	* Metal; F10 x 16 x 6; 19 x 2; 14.5 x 8	2	
7	607-16000-900	* Metal; F10 x 16 x 6; 19 x 2; 14.5 x 1	2	RC6300
8	000-02211-009	* Spring; Squeegee Gap	2	
9	002-12234-001	* Spring; Adj. Plate (Front)	2	
10	002-12213-101	* Sector Adjustor; Squeegee	1	
11	002-12240-001	* Shaft Catch; Drive; Squeegee	1	
12	002-12209-007	* Adj. Collar A; Squeegee	1	
13	011-12211-205	* Side Frame; Squeegee	1	
14	640-60140-012	* O Ring; P14-2.4	2	
15	002-12201-219	* Squeegee Roller	1	
15	014-12221-008	* Squeegee Roller; A3	1	RC6300
16	002-12205-001	* Doctor Roller	1	
16	014-12224-007	* Doctor Roller; A3	1	RC6300
17	002-12239-305	* Drive Shaft; Squeegee	1	
17	014-12252-000	* Drive Shaft; Squeegee; A3	1	RC6300
18	002-12216-100	* Adj. Shaft; Squeegee	1	
18	014-12251-004	* Adj. Shaft; Squeegee; A3	1	RC6300
19	002-12237-000	* Adj. Plate (Back); Squeegee	1	
20	000-02255-502	* Ink Blocking Plate (Back)	1	
21	002-12218-006	* Reverse Rotation Stopper B	1	
22	638-90000-020	* Washer; 18 x 10.2 x 0.2	1	
23	002-12222-003	* Pulley; Squeegee Roller	1	
24	640-70030-100	* V Ring; VRY2.7 x 3.5 x 4.1	1	
25	002-12238-104	* Axis; Drive Shaft; Squeegee	1	
26	607-10000-010	* Metal; F3 x 5 x 3; 8x 1.4	1	
27	002-12229-105	* Tensioner; Squeegee	1	
28	002-12233-005	* Spring; Tensioner; Squeegee	1	

No.	Part No.	Part Name	Q'ty	Remark
29	011-12221-006	* Fulcrum; Tensioner; Squeegee	1	
30	011-12241-007	* Shaft Support II; Squeegee	1	
	011-12206-007	* Ass'y; Shaft Joint	1	
31	002-12223-107	** Pulley; Main Shaft	1	
32	011-12207-100	** Shaft Joint	1	
33	002-12227-005	** Bearing Holder A; Squeegee	1	
34	601-10007-003	** Bearing; 6202ZZ	1	
35	002-12210-005	* Adj. Collar B; Squeegee	1	
36	620-21309-104	* Squeegee Belt; B130/65M x L9.5	1	
37	011-12209-103	* PCB Cover; Drum	1	
38	011-12222-002	* Bracket R; Drum Cover F	1	
39	011-12223-009	* Bracket L; Drum Cover F	1	
40	011-12213-100	* Drum Cover F (Upper)	1	
	011-92300-009	Unit/Drum Frame		
	014-92300-000	Unit/Drum Frame II		RC6300
41	000-01169-106	* Support Roller; Drum	3	
42	002-12410-004	* Adj. Plate; Support Roller	1	
43	002-12409-006	* Support Shaft; Support Roller	2	
44	011-12301-000	* Frame; Drum	1	
44	014-12281-000	* Frame II; Drum	1	RC6300
45	002-12414-000	* Shaft; Locking Plate; Drum	1	
46	011-12305-005	* Spring; Locking Plate; Drum	1	
47	002-12413-003	* Locking Plate; Drum	1	
48	011-12321-000	* Drum Lever	1	
49	002-12407-003	* Boss A; Drum Lever	2	
50	002-12418-005	* Spacer; Drum Lever	2	
51	011-12320-209	Adj. Plate; Magnet A Det. Sensor	1	
52	011-12319-006	Bracket; Magnet A Det. Sensor	1	
53	011-60025-006	Magnet A Det. Sensor	1	
54	011-60024-000	Magnet C Det. Sensor	1	
55	011-12315-000	Bracket; Magnet C Det. Sensor	1	
56	011-12313-008	Bracket B; Connector; Drum	1	
57	011-55009-205	Wire Harness; Drum	1	
57	014-55001-001	Wire Harness; Drum; A3	1	RC6300
58	011-12220-107	Drum Cover F (Lower)	1	


No.	Part No.	Part Name	Q'ty	Remark
	011-42212-001	Bottle Guide	1	
	014-12216-101	Bottle Guide II Ass'y	1	RC6300
59	011-12208-000	* Bottle Guide (Over)	1	RC6300
60	014-12217-000	* Bottle Guide II (Base)	1	RC6300
61	011-60019-200	Bottle Set SW	1	
62	011-12218-005	Boss; Bottle Set SW	1	
63	011-12217-009	Adj. Plate; Bottle SW	1	
64	011-12216-002	Bracket; Bottle SW	1	
65	011-12219-001	Spring; Bottle SW	1	
	011-92220-005	Unit/Ink Pump		
	014-92220-015	Unit/Ink Pump; A3		RC6300
66	002-12303-305	* Bracket; Inking Motor	1	
67	002-12304-107	* Piston; Inking Pump	1	
68	640-60140-012	* O Ring; P14-2.4	1	
69	640-60220-024	* O Ring; P22-2.4	1	
70	000-07119-100	* Coil Spring; Inking Pump	1	
71	011-12151-008	* Valve; Inking Pump	2	
72	011-12201-200	* Inking Pump Body	1	
72	014-12211-002	* Inking Pump Body; A3	1	RC6300
73	011-12147-108	* Coil Spring; Inking Pump; RC	1	
74	640-60100-118	* O Ring; P10A-2.4	1	
75	011-12153-000	* Ink Distributor II	1	
75	014-12213-005	* Ink Distributor; A3	1	RC6300
76	011-51009-200	* Drum PCB	1	
77	011-65007-103	* Inking Motor	1	
78	002-12307-203	* Linking Disc; Inking Pump	1	
79	002-12308-013	* Linking Plate; Inking Pump	1	
80	002-12309-001	* Collar; Inking Pump	2	
81	002-12310-107	* Collar Holder; Inking Pump	1	
82	550-20077-106	Seal; Ink (Black)	1	
82	550-20215-100	Seal; Ink (Black); Pic.	1	
82	550-20091-109	Seal; Ink (Blue)	1	
82	550-20092-105	Seal; Ink (Red)	1	
82	550-20093-101	Seal; Ink (Yellow)	1	
82	550-20094-108	Seal; Ink (Brown)	1	

[illegible]

M E M O

1-23


I-24



No.	Part No.	Part Name	Q'ty	Remark
	014-92100-001	Unit/Drum Screen; A3		RC6300
	011-92100-000	Unit/Drum Screen; B4		
	011-92101-006	Unit/Drum Screen; 100US		U.S.A.
	011-92102-002	Unit/Drum Screen; A4		
1	014-12101-002	* Drum Body; A3	1	RC6300
1	011-12101-205	* Drum Body; B4	1	
1	011-42101-200	* Drum Body; 100US	1	
1	011-42102-206	* Drum Body; A4	1	
2	011-12123-705	* Drum Body Support (Left)	1	
2	014-12103-005	* Drum Body Support (Left); A3	1	RC6300
3	011-12133-204	* Drum Body Support (Right)	1	
4	011-12118-000	* Magnet C	3	
5	011-12120-102	* Clamp Plate Base	1	
5	014-12106-004	* Clamp Plate Base; A3	1	RC6300
6	011-12130-000	* Clamp Magnet B	1	
7	014-12120-104	* Clamp Magnet A; A3	1	RC6300
7	002-12110-108	* Clamp Magnet A; B4	1	
7	011-12143-005	* Clamp Magnet A; A4	1	
8	011-12132-305	* Sheet; Clamp Plate	1	
8	014-12121-208	* Sheet; Clamp Plate; A3	1	RC6300
10	002-12134-104	* Sticker Sheet; Drum	1	
10	014-12118-100	* Sticker Sheet; Drum; A3	1	RC6300
11	011-12110-301	* Clamp Plate Ass'y	1	
11	014-12104-001	* Clamp Plate Ass'y; A3	1	RC6300
12	011-12129-100	* Clamp Sub-Plate	1	
12	014-12115-003	* Clamp Sub-Plate; A3	1	RC6300
13	011-12134-006	* Sheet; Drum; B4	2	
13-1	014-12126-005	* Sheet (Left); Drum; A3	1	RC6300
13-2	014-12125-009	* Sheet (Right); Drum; A3	1	RC6300
14	011-12114-005	* Shaft; Clamp Plate	1	
15	011-12124-108	* Compensator	1	
16	011-12141-100	* Screw; Spring Hanger	2	
	011-92106-008	* Ass'y; Angular Magnet Plate		
17	011-12154-007	** Plate II; Angular Magnet	1	
18	660-05500-100	** Magnet TDK REC 18 D5 x 2	1	


[illegible]

Fig. 11 LOCK LEVER AREA (RC4000, RC4500, RC5600/D, RC5800)




[illegible][illegible]

Fig. 12 LOCK LEVER AREA (RC6300)



[illegible][illegible]


Fig. 13 CLAMP-PRESSURE CONTROL AREA



No.	Part No.	Part Name	Q'ty	Remark
1	011-95041-004	Unit/Write Pulse Motor	1	
2	011-15018-007	* Pulley; Write Pulse Motor	1	
3	620-21559-003	Belt; B115 M x L-9.5	1	
	011-95050-208	Unit/Loading Pulse Motor	1	
4	011-65013-006	* Loading Pulse Motor	1	
5	009-35214-009	* Pulley PM (16); Exit Roller	1	
6	011-15037-001	* Bracket; Loading Pulse Motor	1	
	014-95050-005	Unit/Loading Pulse Motor; A3		RC6300
4	014-65013-008	* Loading Pulse Motor; A3	1	RC6300
5	009-35214-009	* Pulley PM (16); Exit Roller	1	RC6300
6	011-15037-001	* Bracket; Loading Pulse Motor	1	RC6300
32	014-15155-006	* Mount; Loading Pulse Motor; A3	1	RC6300
7	620-20714-005	Belt; B71 M x L-4.8	1	
8	011-91230-007	Unit/Drive Gear; Transfer Belt	1	
8	014-91235-009	Unit/Drive Gear; Transfer Belt; A3	1	RC6300
	011-91265-005	Pressure Control Motor Ass'y		
9	011-65009-009	* Pressure Control Motor	1	
10	011-11244-002	* Gear; Pressure Control Motor	1	
11	011-11293-003	* Bracket; Pressure Control Motor	1	
	011-91240-002	Unit/Print Positioning Motor		
12	011-11294-107	* Print Positioning Motor	1	
13	011-11229-003	* Bracket; Print Positioning Motor	1	
	006-91440-001	Unit; Adj. Plate; Timing Lever	1	
14	002-11421-002	* Adj. Plate; Timing Lever	1	
15	006-11308-000	* Timing Lever	1	
16	006-11311-109	Spring; Timing Lever; R3	1	
	011-93220-009	Angular Sensor Ass'y		
17	011-12415-005	* Bracket; Angular Sensors	1	
18	011-60004-106	* Angular Sensor	1	
19	002-12537-209	Protection Sheet	1	
	011-92400-003	Unit/Clamp		
	014-92400-005	Unit/Clamp; A3		RC6300
20	011-12403-309	* Base Plate; Clamp Solenoid	1	
20	014-12401-006	* Base Plate; Clamp Solenoid; A3	1	RC6300
21	011-12405-107	* Bracket; Compensator Plate	1	


[illegible]

Fig. 14 SEPARATOR AREA



[illegible][illegible]


Fig. 15 SUCTION UNIT (RC4000, RC4500, RC5600/D, RC5800)



No.	Part No.	Part Name	Q'ty	Remark
	011-93206-006	Suction Unit		
1	011-13203-206	* Face Cover; Suction	1	
2	011-13220-003	* Transfer Belt	3	
3	011-13201-106	* Suction Cover (Upper)	1	
4	011-13219-102	* Bracket; P.-Rcv. Sensor 1 (Send)	1	
5	011-60035-109	* Paper Receiving Sensor (Send)	1	
6	011-13232-109	* Suction Cover (Lower)	1	
7	011-13215-107	* Suction Fan	1	
8	011-13206-108	* Suction Fan Cover	1	
9	011-13207-007	* Seal	1	
10	011-65006-301	* Suction Motor	1	
11	600-50059-017	* Bearing; FLW688ZZ	4	
12	011-13209-107	* Transfer Shaft B; Suction	1	
13	011-13208-100	* Transfer Shaft A; Suction	1	
14	011-13212-000	* Fulcrum Plate; Gear Pulley; Suction	1	
15	002-13252-003	* Gear Pulley B; Suction	1	
16	620-22364-001	* Belt; B236 M x L-4.8	1	
17	011-13204-008	* Pulley; Suction Motor	1	
18	011-13231-005	* De-electricity Brush; P.-Rcv.	1	
19	011-13205-004	* Cover Plate; Suction	1	
20	011-13134-000	* Damper; Cover Plate; Suction	1	
21	011-13233-008	* Dust-proof Cover 1; Rcv.	1	
22	011-13237-003	* Dust-proof Tape 1; Rcv.	1	
23	011-13235-000	* Dust-proof Sponge 1; Rcv.	1	
24	011-13234-004	* Dust-proof Cover 2; Rcv.	1	
25	011-13238-000	* Dust-proof Tape 2; Rcv.	1	
26	011-13236-007	* Dust-proof Sponge 2; Rcv.	1	
	011-93230-004	De-electricity Brush Ass'y		
27	011-13224-106	* Bracket; De-electricity Brush; Suction	1	
28	011-13225-102	* De-electricity Brush	1	
29	011-55064-001	Wire Harness; P.-Rcv. Sensor (Send)	1	

[illegible]


Fig. 16 SUCTION UNIT (RC6300)



No.	Part No.	Part Name	Q'ty	Remark
	014-93200-000	Suction Unit III		
1	014-13210-000	* Face Cover II; Suction	1	
2	011-60035-109	* Paper Receiving Sensor (Send)	1	
3	011-13219-102	* Bracket; P.-Rcv. Sensor 1 (Send)	1	
4	011-13235-000	* Dust-proof Sponge 1; Rcv.	1	
5	011-13233-008	* Dust-proof Cover 1; Rcv.	1	
6	011-13237-003	* Dust-proof Tape 1; Rcv.	1	
7	011-13238-000	* Dust-proof Tape 2; Rcv.	1	
8	011-13236-007	* Dust-proof Sponge 2; Rcv.	1	
9	011-13234-004	* Dust-proof Cover 2; Rcv.	1	
10	011-13201-106	* Suction Cover (Upper)	1	
11	011-13220-003	* Transfer Belt	3	
12	011-13208-100	* Transfer Shaft A; Suction	1	
13	014-13203-003	* Suction Cover R	1	
14	600-50059-017	* Bearing; FLW688ZZ	4	
15	011-13204-008	* Pulley; Suction Motor	1	
16	620-22364-001	* Belt; B236 M x L-4.8	1	
17	002-13252-003	* Gear Pulley B; Suction	1	
18	011-13212-000	* Fulcrum Plate; Gear Pulley; Suction	1	
19	014-13202-007	* Suction Cover F	1	
20	011-13215-107	* Suction Fan	1	
21	011-13206-108	* Suction Fan Cover	1	
22	011-13207-007	* Seal	1	
23	011-13209-107	* Transfer Shaft B; Suction	1	
24	011-13232-109	* Suction Cover (Lower)	1	
25	011-65006-301	* Suction Motor	1	
26	011-13231-005	De-electricity Brush; P.-Rcv.	1	
27	014-13201-108	Cover Plate; Suction; A3	1	
28	011-13134-000	Damper; Cover Plate; Suction	1	
29	011-13225-102	De-electricity Brush	1	
30	011-13224-106	Bracket; De-electricity Brush; Suction	1	
31	011-55064-001	Wire Harness; P.-Rcv. Sensor (Send)	1	
32	550-20584-008	Seal; P.-Rcv.-T. Pos.	1	

[illegible]


Fig. 17 PAPER RECEIVING TRAY



No.	Part No.	Part Name	Q'ty	Remark
	011-93100-402	Unit/Paper Receiving Tray II		
	011-93105-102	Unit/Paper Receiving Tray; 100US		U.S.A.
	014-93100-005	Unit/Paper Receiving Tray; A3	1	RC6300
	014-93105-007	Unit/Paper Receiving Tray; A3; 100US	1	RC6300 U.S.A.
1	011-13115-102	* Receiving Tray Plate II	1	
1	011-43102-102	* Receiving Tray Plate II; 100US	1	U.S.A.
2	011-13102-108	* Frame A; Paper Receiving Tray	1	
2	014-13101-006	* Frame A; Paper Receiving Tray; A3	1	RC6300
3	011-13106-006	* Frame B; Paper Receiving Tray	1	
4	011-13112-103	* Shaft; Paper Receiving Tray	1	
5	011-13108-106	* Slide Rail A; P.-Rcv.-T.	1	
6	011-13109-102	* Slide Rail B; P.-Rcv.-T.	1	
7	011-13107-002	* Catch Plate; P.-Rcv.-T.	1	
8	000-04123-000	* Slide Frame; Paper Guide; Rcv.	3	
8	014-13113-004	* Slide Frame; Paper Guide; Rcv. ; A3	3	RC6300
9	007-13101-001	* Slide Guide; Paper Guide; Rcv.	3	
9	014-13110-005	* Slide Guide; Paper Guide; Rcv. ; A3	3	RC6300
10	007-13124-109	* Base Block; Paper Guide; Rcv.	3	
11	011-13110-208	* Paper Guide; P.-Rcv.-T.	2	
12	011-13111-000	* Back Stop; P.-Rcv.-T.	1	
13	011-13133-100	* Damper; Back Stop; P.-Rcv.-T.	1	
14	011-13141-006	* Spring; Paper Guide; P.-Rcv.-T.	2	
15	011-13142-002	* Paper Guiding Arm F; P.-Rcv.-T.	1	
16	011-13143-009	* Paper Guiding Arm R; P.-Rcv.-T.	1	
17	011-13135-006	* Pin; Paper Guide	2	
18	006-11714-203	* Back Stop A; P.-Rcv.-T.; 100US	1	U.S.A.
19	006-11715-102	* Back Stop B; P.-Rcv.-T.; 100US	1	U.S.A.
20	006-11719-000	* Vibration Stopper; Back Stop; 100US	1	U.S.A.
21	006-11717-008	* Spring; Back Stop; Rcv.; 100US	1	U.S.A.
22	006-11716-109	* Hinge; Back Stop; Rcv.; 100US	1	U.S.A.
23	550-20087-004	Seal; Guide; P.-Rcv.-T.	1	


[illegible]

Fig. 18 SCANNER AREA (1) (RC4000)



[illegible][illegible]

Fig. 19 SCANNER AREA (2) (RC4000)



No.	Part No.	Part Name	Q'ty	Remark
1	011-70053-202	Image Scanner; 40	1	
2	011-55127-208	Wire Harness; Image Scanner; 40	1	
	011-96046-000	Unit/ADF II		
3	011-96102-007	* Original Guide 4 Ass'y	1	
4	011-96104-000	* De-electricity Brush Ass'y	1	
5	011-16345-001	* Exit Roller (Upper); Scanner	1	
6	011-16360-000	* Original Guide 5; Scanner	1	
7	011-96115-001	* Exit Roller (Lower); Scanner	1	
8	011-16379-003	* Side Frame R; Scanner	1	
9	011-16333-003	* Belt; 246-3M-4	1	
10	011-16328-000	* Belt; B 87M x L3.2	1	
11	011-96107-106	* Read Pulse Motor	1	
	011-96113-009	* Original Guide 1	1	
12	011-16356-003	** Sensor Stay	1	
13	011-16359-002	** Original Guide 1; Scanner	1	
14	011-16358-006	** Sheet; Original Guide 1; Scanner	2	
15	011-16357-000	** Original Sensor A	1	
16	011-96101-205	* Wire Harness; Original Regist./Det. Sensor	1	
17	011-96116-008	* Shaft; Original Feed	1	
17-1	011-16365-002	** Upper Original Pickup Roller	1	
17-2	011-16366-009	** Original Feed Roller	1	
18	011-16346-008	* Transfer Roller; Scanner	1	
	011-96117-004	* Original Guide 3 Ass'y	1	
19	011-16373-005	** Original Guide 3	1	
20	011-16372-009	** Sheet; Original Guide 3; Scanner	1	
21	011-16371-002	** Original Sensor B	1	
22	011-96101-205	* Wire Harness; Original Regist./Det. Sensor	1	
	011-96118-000	* Original Guide 2 Ass'y	1	
23	011-16377-000	** Original Guide 2	1	
24	011-16374-001	** Sheet; Original Guide 2; Scanner	1	
25	011-96111-006	* Transfer Roller (Lower)	1	
26	011-96100-209	* Original IN Sensor	1	
27	011-16378-007	* Side Frame L; Scanner	1	
28	011-16315-005	* Lever	3	
29	011-96105-103	* Original Feed Solenoid	1	

[illegible]

Fig. 20 SCANNER AREA (1) (RC4500, RC5600/D)





Fig. 21 SCANNER AREA (2) (RC4500, RC5600/D)




[illegible][illegible]

No.	Part No.	Part Name	Q'ty	Remark
1	011-70001-300	Image Scanner	1	
2	011-70058-000	* Glass Plate; Image Scanner	1	
	011-96046-000	Unit/ADF II		
3	011-96102-007	* Original Guide 4 Ass'y	1	
4	011-96104-000	* De-electricity Brush Ass'y	1	
5	011-16345-001	* Exit Roller (Upper); Scanner	1	
6	011-16360-000	* Original Guide 5; Scanner	1	
7	011-96115-001	* Exit Roller (Lower); Scanner	1	
8	011-16378-007	* Side Frame L; Scanner	1	
9	011-16333-003	* Belt; 246-3M-4	1	
10	011-16328-000	* Belt; B 87M x L3.2	1	
11	011-96107-106	* Read Pulse Motor	1	
	011-96113-009	* Original Guide 1	1	
12	011-16356-003	** Sensor Stay	1	
13	011-16359-002	** Original Guide 1; Scanner	1	
14	011-16358-006	** Sheet; Original Guide1; Scanner	2	
15	011-16357-000	** Original Sensor A	1	
16	011-96101-205	* Wire Harness; Original Regist./Det. Sensor	1	
17	011-96116-008	* Shaft; Original Feed	1	
17-1	011-16365-002	** Upper Original Pickup Roller	1	
17-2	011-16366-009	** Original Feed Roller	1	
18	011-16346-008	* Transfer Roller; Scanner	1	
	011-96117-004	* Original Guide 3 Ass'y	1	
19	011-16373-005	** Original Guide 3	1	
20	011-16372-009	** Sheet; Original Guide 3; Scanner	1	
21	011-16371-002	** Original Sensor B	1	
22	011-96101-205	* Wire Harness; Original Regist./Det. Sensor	1	
	011-96118-000	* Original Guide 2 Ass'y	1	
23	011-16377-000	** Original Guide 2	1	
24	011-16374-001	** Sheet; Original Guide 2; Scanner	1	
25	011-96111-006	* Transfer Roller (Lower)	1	
26	011-96100-209	* Original IN Sensor	1	
27	011-16379-003	* Side Frame R; Scanner	1	
28	011-16315-005	* Lever	3	
29	011-96105-103	* Original Feed Solenoid	1	


[illegible]

Fig. 22 SCANNER AREA (3) (RC4500, RC5600/D)



[illegible][illegible]

Fig. 23 SCANNER AREA (1) (RC5800, RC6300)



No.	Part No.	Part Name	Q'ty	Remark
	012-96111-100	Unit/Scanner; 58		RC5800
	012-96110-104	Unit/Scanner; 58US		RC5800 U.S.A.
	014-96111-105	Unit/Scanner; 63		RC6300
	014-96110-109	Unit/Scanner; 63US		RC6300 U.S.A.
		* Scanner Area (1)		
		* Scanner Area (2)		
1	012-16210-006	Shading Cover	1	
2	012-16288-005	Stage Glass	1	
2	012-16279-103	Stage Glass; US	1	U.S.A.
3	012-16257-002	Spacer Holder	2	
4	012-16258-009	Flat-Head Screw M4 x 6	6	
5	012-16295-001	Stopper Ass'y	1	
5	012-16294-005	Stopper Ass'y; US	1	U.S.A.
6	012-16203-000	Solenoid Cover	1	
7	012-16292-002	Stopper Crank	1	
8	012-16205-002	Solenoid Holder	1	
9	012-65001-005	Stopper Solenoid	1	
10	012-16206-009	Solenoid Pin	1	
11	012-16281-000	Scanner Cover	1	
12	012-16209-008	Shading Plate	1	
13	012-16208-001	Shading Mylar	1	
14	012-16260-003	CCD Fixing Plate	1	
15	012-16261-000	CCD Fixing Screw	2	
16	012-16263-002	Lifting Spring	2	
17	012-16259-005	Sub-Frame	1	
18	012-16262-006	Lifting Pin	2	
	012-96215-208	Unit/CCD		
19	012-70001-501	* CCD; CIPS305MS5A-1	1	
20	012-16275-108	* CCD Cover (Left)	1	
21	012-16274-101	* CCD Cover (Right)	1	
22	012-16268-004	* Roller; CCD	4	
23	012-16266-001	* Roller Tension Plate (Right)	1	
24	012-16267-008	* Roller Tension Plate (Left)	1	
25	012-16273-008	* AJ Pin	2	
26	012-16271-005	* CCD Holder (Front)	1	


No.	Part No.	Part Name	Q'ty	Remark
27	012-16272-001	* CCD Holder (Rear)	1	
28	012-16270-009	* Roller Spring (Left)	1	
29	012-16269-000	* Roller Spring (Right)	1	
30	012-16287-106	* CCD Cover	1	
31	012-16276-007	Blind Plate A	1	
32	012-16277-003	Blind Plate B	1	
33	012-16251-004	Blind Plate C	1	
34	012-16278-000	Guide Cover	1	
35	012-16256-103	Upper Back Frame	1	
36	012-16237-001	Grip Holder	1	
37	012-16236-005	Grip	1	
38	012-16238-008	Grip Pin	2	
39	012-16235-009	Grip Arm	1	
40	012-16229-009	Crank Pin	1	
	012-96205-008	Unit/Back Frame		
41	012-16228-002	* Crank Arm	1	
42	012-16229-009	* Crank Pin	1	
43	012-16226-000	* Hook	1	
44	012-16227-006	* Hook Holder	1	
45	443-30000-500	* Sensor; OS3701R-03	2	
46	012-16230-007	* Spring; Hook Holder	1	
47	012-16225-003	* Back Frame	1	
	012-96210-001	* Unit/Read Pulse Motor	1	
48	012-16233-006	** Pulley Shaft	1	
49	620-50716-002	** Belt; 142P2M6	1	
50	620-50806-001	** Belt; 160P2M6	1	
51	012-16232-000	** Pulley; P2M-42/24	1	
52	012-16231-003	** Pulley; P2M-20-M	1	
54	012-16234-002	** Bracket; Pulley	1	
56	012-65002-001	* Read Pulse Motor	1	
57	012-16222-101	Side Frame (Right)	1	
58	012-16220-001	Pulley; P2N-20-D	1	
59	600-08125-000	Bearing; MF128ZZS NSK	2	
60	012-16223-000	Drive Shaft	1	
61	012-16224-007	Pulley; P2M-20/36	1	

[illegible][illegible]

M E M O

1-53

Fig. 24 SCANNER AREA (2) (RC5800)




No.	Part No.	Part Name	Q'ty	Remark
1	012-16211-304	Scanner Bottom Plate	1	
2	012-16213-005	Sub-Base Frame	1	
3	012-16201-007	Blind Cover	1	
4	012-16252-000	Edge Fitting; Scanner Bottom Plate	1	
5	012-51007-000	Image Processing PCB (GA); RC5800	1	
6	012-16215-008	Sheet; Image Processing PCB; 58	1	
7	012-51016-204	A.C.C. PCB	1	
8	012-16216-004	Sheet; A.C.C. PCB	1	
9	012-51009-003	Trimming PCB	1	
10	012-16214-001	Sheet; Trimming PCB	1	
11	012-51017-103	Original Det. Sensor PCB II	1	
12	012-60018-201	Original Det. Sensor	1	
13	012-96218-002	Wire Harness; CCD Ass'y	1	
14	012-55029-203	Wire Harness; Original Det. Sensor	1	
15	012-55033-103	Wire Harness; A.C.C.	1	
16	014-55005-104	Wire Harness; Trimming PCB	1	
17	012-55031-305	Wire Harness; ADF	1	
18	012-55011-002	Wire Harness; Digitizer	1	
19	012-55056-103	Junction Wire; Stopper Solenoid	1	
20	012-55032-204	Wire Harness; Home-Pos. Sensor	1	
21	012-16217-000	Bracket; Connector	1	
22	012-16296-008	Bracket C; Core Set	1	
23	435-00015-005	Core Set; 2643-164501	1	
24	012-16298-000	Bracket B; Core Set	1	
25	012-16212-009	Spacer; L4.8	12	
26	505-00050-109	Spacer; KGLS-5RTVOL	8	
27	505-00050-206	Spacer; KGPS-5RT	3	
28	665-02021-207	Nylon Clip; NK-13N	1	
29	665-02021-100	Nylon Clip; NK-10N	2	
30	665-02021-002	Nylon Clip; NK-8N	4	
31	665-02020-901	Nylon Clip; NK-6N	3	
32	665-02020-804	Nylon Clip; NK-2N	5	
33	012-16253-007	Edge Fitting 1		
	012-16254-003	Edge Fitting 2		
	012-16255-000	Edge Fitting 3		

[illegible]

Fig. 25 SCANNER AREA (2) (RC6300)


1-56



No.	Part No.	Part Name	Q'ty	Remark
1	012-16211-304	Scanner Bottom Plate	1	
2	012-16298-000	Bracket B; Core Set	1	
3	435-00015-005	Core Set; 2643-164501	1	
4	012-16201-007	Blind Cover	1	
5	012-16212-009	Spacer; L4.8	12	
6	012-16252-000	Edge Fitting; Scanner Bottom Plate	1	
7	012-16213-005	Sub-Base Frame	1	
8	505-00050-109	Spacer; KGLS-5RTVOL	8	
9	665-02020-901	Nylon Clip; NK-6N	3	
10	665-02021-207	Nylon Clip; NK-13N	1	
11	012-16253-007	Edge Fitting 1	1	
12	665-02021-002	Nylon Clip; NK-8N	4	
13	665-02021-100	Nylon Clip; NK-10N	2	
14	012-16217-000	Bracket; Connector	1	
15	665-02020-804	Nylon Clip; NK-2N	5	
16	505-00050-206	Spacer; KGPS-5RT	8	
17	012-16296-008	Bracket C; Core Set	1	
18	012-96218-002	Wire Harness; CCD Ass'y	1	
19	014-50000-104	Image Processing PCB; A3	1	
20	012-16215-008	Sheet; Image Processing PCB; 58	1	
21	012-55011-002	Wire Harness; Digitizer	1	
22	012-55031-305	Wire Harness; ADF	1	
23	014-55002-105	Wire Harness; Image-MTF	1	
24	012-55032-204	Wire Harness; Home-Pos. Sensor	1	
25	012-55056-103	Junction Wire; Stopper Solenoid	1	
26	012-55029-203	Wire Harness; Original Det. Sensor	1	
27	014-50001-003	MTF2 PCB	1	
28	012-55057-207	Wire Harness; Image Processing; 58	1	
29	014-55005-104	Wire Harness; Trimming PCB	1	
30	012-60018-201	Original Det. Sensor	1	
31	012-51017-103	Original Det. Sensor PCB II	1	
32	012-51009-003	Trimming PCB	1	
33	012-16214-001	Sheet; Trimming PCB	1	

[illegible]


Fig. 26 ADF AREA (1) (RC5800, RC6300)



No.	Part No.	Part Name	Q'ty	Remark
1	012-16401-103	ADF Rear Frame	1	
2	012-16402-002	Tension Plate (Rear)	1	
3	600-08162-002	Bearing; L816ZZ	4	
4	012-16403-009	Or.-Trans Belt Pulley	1	
5	640-63320-003	O Ring; S32 - 1.8	2	
6	012-16404-005	Holder Plate; O.T.B. Pulley	2	
7	012-16405-001	Spring; Belt Tension (Back)	1	
8	607-13000-801	Metal; 6S	1	
9	012-16406-008	ADF Ejection Pulley	1	
10	012-16407-004	Belt Gear	1	
11	012-16408-000	Gear; 28	1	
12	012-16409-007	Damper	1	
	012-96201-002	Unit/Side-shift Prevention Collar (Rear)		
13	012-16410-005	* Adj. Plate (Rear); Side-shift Prevention	1	
14	012-16411-001	* Collar; Side-shift Prevention	2	
15	012-51901-100	ADF Control PCB	1	
16	012-55901-008	Wire Harness; Ori.-Exit Sensor	1	
17	012-55907-006	Wire Harness; ADF Control	1	
18	012-55903-000	Wire Harness; Open/Close SW	1	
19	012-55904-007	Wire Harness; ADF Motor	1	
20	012-55905-003	Wire Harness; Original Feed	1	
21	012-16412-008	DF Spacer	4	
22	012-16413-004	Or.-Trans Belt Roller (Right)	1	
24	012-16414-000	ADF Stay (Right)	1	
25	012-16415-007	ADF Mid Stay (Right)	1	
26	012-16416-003	ADF Mid Stay (Left)	1	
27	012-16417-000	ADF Stay (Left)	1	
28	012-16418-006	Spring; Holding Roller	16	
29	012-16419-002	Arm; Holding Roller	16	
30	012-16420-000	Holding Roller	16	
	012-96202-009	Unit/Side-shift Prevention Collar (Front)		
31	012-16421-007	* Adj. Plate (Front); Side-shift Prevention	1	
33	012-16422-003	ADF Front Frame; 58	1	
34	012-16423-000	Bracket; ADF Magnet Catch	1	
35	660-05000-700	Magnet Catch	1	

[illegible]

Fig. 27 ADF AREA (2) (RC5800, RC6300)



No.	Part No.	Part Name	Q'ty	Remark
1	012-16442-004	ADF Hinge (Left)	1	
2	012-16443-000	Actuator Plate; ADF SW	1	
3	443-01000-704	Micro-SW; V62-1A4	1	
4	012-16444-007	ADF Hinge (Right)	1	
5	012-16445-003	ADF Hinge Spacer	2	
6	012-16446-000	Registration Roller	1	
	012-96213-000	Unit/Original Feed (Upper)		
8	012-16447-006	* Upper Guide Plate; ADF	1	
9	012-16448-002	* Mylar Sheet; Original Feed	2	
10	011-16449-009	* Mylar Sheet; Original Feed (Up)	1	
11	012-16450-007	* Bracket; ADF Original Det. Sensor	1	
12	012-16451-003	* Actuator; ADF Original Det. Sensor	1	
13	443-30000-608	* Sensor; TLP1217(C2)	1	
14	012-16452-000	* Stopper; Original Feed Roller	1	
15	012-60901-008	ADF Registration Sensor (Receive)	1	
16	011-16339-001	Metal; 6 mm	3	
	012-96206-004	Unit/Original Feed (Lower)		
17	012-16453-006	* Lower Guide Plate; ADF	1	
18	012-16454-002	* Mylar Sheet; Registration	3	
19	012-16455-009	* Mylar Sheet; Separator	1	
20	012-16456-005	* Mylar Sheet; Original Feed (Low)	1	
21	012-60902-004	* ADF Registration Sensor (Send)	1	
	012-96207-000	Unit/Original Stripper		
22	012-16457-001	* Arbor	2	
23	012-16458-008	* Spring; Original Feed (Front)	1	
24	012-16459-004	* Link Plate; Original Feed Roller	2	
25	012-16460-002	* Joint; Original Feed	1	
26	012-16461-009	* Original Pickup Roller (Upper)	1	
27	012-16462-005	* Original Feed Roller	1	
29	012-16463-001	* Pulley 18	2	
30	620-50504-005	* Belt; B4OS2M100	1	
31	012-16464-008	* Spring; Original Feed (Back)	1	
32	012-16465-004	* Shaft; Original Pickup Roller	1	
34	011-16339-001	* Metal; 6 mm	1	
35	012-16466-000	* Pulley; Original Pickup	1	


No.	Part No.	Part Name	Q'ty	Remark
36	012-16467-007	* Gear; Original Pickup	1	
37	012-16468-003	* Arbor Clutch	1	
38	012-16469-000	* Release Spring Clutch	1	
39	012-16470-008	* Stopper Release Plate 2	1	
40	639-00605-007	* Washer; 6 x 10 x 0.5	1	
41	012-16471-004	Stopper Shaft; Original Feed	1	
42	012-16472-000	Stopper; Original Feed	2	
43	012-16473-007	Bracket; Original Separation Roller	1	
44	012-16474-003	Side Holder (Rear)	1	
45	012-16475-000	Ground Plate	1	
46	012-16476-006	Center Holder	1	
47	012-16477-002	Shaft; Original Separation Roller	1	
50	012-16478-009	Joint B; Original Sepa. Roller	1	
51	012-16479-005	Spring; Original Sepa. Roller	1	
52	012-16480-003	Spring Cover; Original Sepa. Roller	1	
53	012-16481-000	Joint; Original Sepa. Roller	1	
54	012-16482-006	Original Separation Roller	1	
55	012-16483-002	Side Holder (Front)	1	
56	012-16484-009	Pulley; Original Sepa. Roller	1	
58	012-16485-005	ADF Idler Pulley	1	
59	012-16486-001	Set Plate; Original Tray	2	
60	012-16487-008	Release Lever Ass'y	1	
61	638-90610-007	Washer; 6.5 x 13 x 1	2	
62	012-16488-004	Release Plate (Front); Registration Collar	1	
63	012-16489-000	Release Spring; Registration Collar	2	
64	012-16490-009	Set Plate; Registration Collar	1	
65	012-16491-005	Side Frame; Registration Collar	1	
66	012-16492-001	Spring; Side Holder	2	
67	012-16493-008	Joint Plate	1	
68	011-16344-005	Metal; 8 mm	2	
	012-96208-007	Unit/Original Registration Collar		
69	012-16494-004	* Shaft; Registration Collar	1	
70	012-16495-000	* Release Plate (Rear); Registration Collar	1	
71	012-16496-007	* Registration Collar M	1	
72	012-16497-003	* Registration Collar L	2	

[illegible][illegible]

M E M O

1-63


Fig. 28 MASTER-MAKING AREA (1) (RC4000, RC4500, RC5600/D, RC5800)



No.	Part No.	Part Name	Q'ty	Remark
	011-95207-107	Unit/Master Roll Holder D; B4		B4
1	011-15250-201	* Master Roll Holder	1	B4
2	011-15254-002	* Holder; Master Roll	1	B4
3	011-15263-001	* Cushion; Master Roll Holder	1	B4
4	011-15294-004	* Tension Plate; Master Roll Holder	1	B4
5	011-95208-103	* Unit/Damper; Master Roll Holder; B4	1	B4
	011-95212-100	Unit/Master Roll Holder D; A4		A4, Legal
1	011-15250-201	* Master Roll Holder	1	A4, Legal
2	011-15254-002	* Holder; Master Roll	1	A4, Legal
3	011-15263-001	* Cushion; Master Roll Holder	1	A4, Legal
4	011-15294-004	* Tension Plate; Master Roll Holder	1	A4, Legal
5	011-95211-104	* Unit/Damper; Master Roll Holder; A4	1	A4, Legal
	011-95095-007	Stocker Ass'y		
6	011-15023-000	* Frame A; Stocker	1	
7	011-15017-000	* Plate B; Stocker	1	
8	011-65025-004	* Loading Fan	1	
9	011-65012-107	* Storage Fan	1	
	011-95070-101	Set Guide Plate Ass'y	1	
10	011-15153-109	* Set Guide Plate; M.-M.	1	
11	011-15061-107	* Set Guide Sheet; M.-M.	1	
12	011-11404-000	*De-electricity Brush; B4	1	
13	011-60012-109	* Master End Sensor	1	
14	011-15143-006	* Bracket II; Master End Sensor	1	
	011-95360-002	Master Loading Unit SW Ass'y		
15	443-00120-501	* Micro-SW; E21-51N	1	
17	011-15113-000	* Bracket; Micro-SW; M.-M.	1	
18	011-55037-101	* Wire Harness; Master Loading Unit	1	
21	011-15162-000	Sheet; Master Guide Plate; M.-M.	1	
22	000-01138-006	L Plate; Guide Plate	4	
23	550-20078-102	Seal; Setting Master	1	
	011-95085-001	De-electricity Brush Ass'y	1	
24	011-15042-005	* Bracket; De-electricity Brush; M.-M.	1	
25	011-15041-009	* De-electricity Brush	1	
26	011-95077-009	Write Roller; 40	1	RC4000
26	011-95076-002	Write Roller	1	

[illegible]


Fig. 29 MASTER-MAKING AREA (2) (RC4000)



No.	Part No.	Part Name	Q'ty	Remark
1	011-15703-001	Frame A; M.-M.; 40	1	
2	011-15003-107	Shaft; Torsion	2	
3	011-15004-006	Fulcrum; TPH	2	
4	011-15129-208	Actuator; Micro-SW; M.-M.	1	
	011-95016-000	Frame B Ass'y; M.-M.		
5	011-15014-001	* Frame B; M.-M.	1	
6	011-15007-005	* Catch Roller (Upper); M.-M.	1	
7	011-15008-001	* Load Roller (Upper); M.-M.	1	
8	607-11000-200	* Metal; F4 x 7 x 6; 10 x 1.5	4	
9	011-15056-006	Spring (Right); M.-M.	1	
10	011-15055-000	Spring (Left); M.-M.	1	
11	011-15158-003	Bracket; De-electricity Brush	1	
12	011-15041-009	De-electricity Brush	1	
13	011-15721-107	Wire Harness Guide	1	
14	011-55137-106	Wire Harness; Thermal Pressure Motor	1	
15	443-00120-609	Micro-SW; E21-91N	2	
16	011-15710-008	Bracket; Micro-SW	1	
17	011-15707-201	Thermal Pressure Motor II Ass'y	1	
18	011-15078-003	Switch Cam	1	
19	011-15117-005	Cam; Thermal Pressure Motor	1	
20	011-15704-008	Bracket; TPH; 40	1	
21	011-15716-006	Pressure Assist Plate	2	
22	011-15717-002	Bracket; Pressure Assist Plate; K-TPH	2	Euro/Asia
22	011-15751-006	Bracket; Pressure Assist Plate; T-TPH	2	U.S.A.
	011-95037-007	K-TPH Ass'y; 40		Euro/Asia
23		* K-TPH	1	Euro/Asia
24	011-15733-008	* De-electricity Brush; K-TPH	1	Euro/Asia
25	011-15734-004	* Bracket; De-electricity Brush; K-TPH	1	Euro/Asia
26		* Protection Sheet A; K-TPH	1	Euro/Asia
	011-95038-003	T-TPH Ass'y; 40		U.S.A.
23		* T-TPH	1	U.S.A.
24	011-15036-005	* De-electricity Brush; TPH	1	U.S.A.
25	011-15034-002	* Bracket; De-electricity Brush; T-TPH	1	U.S.A.
26		* Protection Sheet A; T-TPH	1	U.S.A.
27	011-15711-101	Copy Guide Plate (Lower)	1	

[illegible]

Fig. 30 MASTER-MAKING AREA (2) (RC4500, RC5600/D, RC5800)




No.	Part No.	Part Name	Q'ty	Remark
1	011-14506-105	Master Guide C; M.-Rmv.	1	
2	011-15157-007	Stopper	1	
3	011-15293-008	Support Sheet; M.-Rmv.	1	
	011-95111-002	Cutter Cover A Ass'y		
4	011-15047-104	* Cutter Cover A Ass'y	1	
5	011-15049-000	* Set Sheet B	2	
6	011-15048-003	* Set Sheet A	2	
	011-95100-000	Master Sensor Ass'y	1	
7	011-15139-009	* Bracket; Master Sensor II	1	
8	011-60005-307	* Master Sensor	1	
	011-95121-105	Unit/Cutter II; B4		
	011-95122-101	Unit/Cutter II; A4		
9	011-15102-202	* Cutter Body	1	
10	011-15093-009	* Cutter Sheet B	1	
11	011-15175-005	* Cutter Cover D	1	
12	011-15176-001	* Cutter Guide IV	1	
13	011-15177-008	* Master Guide III	2	
14	011-15043-001	* Cutter Guide Sheet (Right)	1	
15	011-15169-005	* Cutter Guide Sheet III	1	
16	011-15044-008	* Cutter Guide Sheet (Left)	1	
17	011-15142-000	* Bracket; Master Positioning Sensor	1	
18	011-15059-102	* Sheet; Master Positioning Sensor	1	
19	011-60006-109	* Master Positioning Sensor	1	
20	011-15107-000	* Cutter Joint B	1	
21	002-11509-104	* Joint A	1	
	011-95045-107	Unit/Cutter Motor		
22	011-65014-002	* Cutter Motor	1	
23	011-15038-008	* Bracket; Cutter Motor	1	
24	011-15039-004	* Bracket; Cutter SW	1	
25	011-95046-006	* Cutter Joint A	1	
26	443-00120-900	* Micro-SW; E23-91	1	

[illegible]

Fig. 31 MASTER-MAKING AREA (1) (RC6300)

FLANGE SET
011-95218-001


I-70



No.	Part No.	Part Name	Q'ty	Remark
	014-95207-109	Unit/Master Roll Holder; A3		
1	014-15204-309	* Master Roll Holder; A3	1	
2	011-15254-002	* Holder; Master Roll	1	
3	014-15255-000	* Tension Spring	1	
4	014-15253-008	* Tension Stay; Master Roll Holder	1	
5	014-15250-009	* Tension Arm; Master Roll Holder	1	
6	014-15256-007	* Tension Sheet; Master Roll Holder	1	
	014-95208-008	* Unit/Damper; Master Roll Holder; A3		
7	015-18252-000	** Master Holder II	1	
8	011-15268-100	** Holder Spring	1	
9	011-15306-100	** Shaft; Master Holder	1	
10	610-00001-006	** Damper 50F; Master Holder	1	
11	600-50057-006	** Bearing; FLAW678ZZA	2	
12	011-15307-106	** Damper Gear	1	
13	011-15303-003	** Bracket; Damper	1	
14	550-20079-109	Seal; Setting Procedure	1	
14	550-20222-009	Seal; Setting Procedure; Pic.	1	
15	014-15210-104	Cover; Master Roll Holder	1	
16	014-15106-005	De-electricity Brush; A3	1	
	014-95095-009	Stocker Ass'y; A3		
17	665-02010-000	* Clamp DKN-16	2	
18	014-15152-104	* Plate B; Stocker; A3	1	
19	011-65012-107	* Storage Fan	1	
20	014-15151-000	* Frame A; Stocker; A3	1	
21	014-15178-103	Set Guide Shaft	1	
22	014-15175-007	Stay L; Set Guide Plate	1	
23	550-20078-102	Seal; Setting Master	1	
23	550-20221-100	Seal; Setting Master; Pic.	1	
	014-95070-006	Set Guide Plate Ass'y; A3		
24	014-15173-101	* Set Guide Plate; A3	1	
25	014-60003-209	* Master End Sensor; A3	1	
26	014-15174-000	Stay R; Set Guide Plate	1	
27	600-50059-017	Bearing; FLW688ZZ	2	
28	014-95076-004	Write Roller; A3	1	
29	014-15131-107	Master Guide Plate; A3	1	

[illegible]


Fig. 32 MASTER-MAKING AREA (2) (RC6300)



No.	Part No.	Part Name	Q'ty	Remark
1	011-15056-006	Spring (Right); M.-M.	1	
2	011-15055-000	Spring (Left); M.-M.	1	
	014-95010-003	Unit/Master Marking; A3		
3	011-15722-006	* Fulcrum II; M.-M.	2	
4	011-55137-106	* Wire Harness; Thermal Pressure Motor	1	
5	443-00120-609	* Micro-SW; E21-91N	2	
6	011-15708-100	* Switch Cam	2	
7	011-15710-008	* Bracket; Micro-SW	1	
8	011-15707-201	* Thermal Pressure Motor II Ass'y	1	
9	011-15117-005	* Cam; Thermal Pressure Motor	1	
10	607-13000-607	* Metal; F6 x 9 x 7; 11 x 1	2	
11	014-15003-109	* Frame A; M.-M.; A3	1	
12	011-15003-107	* Shaft; Torsion	2	
13	607-11000-200	* Metal; F4 x 7 x 6; 10 x 1.5	2	
14	011-15004-006	* Fulcrum; TPH	2	
15	014-15012-000	* Shaft; Load Roller	1	
16	014-15007-007	* Load Roller	1	
17	014-15018-009	* Catch Roller (Upper); A3	1	
18	014-15004-008	* Bracket; TPH; A3	1	
19	011-15716-006	* Pressure Assist Plate	2	
20	011-15751-006	* Bracket; Pressure Assist Plate; T-TPH	2	
21	011-15718-106	* Spring; TPH Pressure	2	
22	011-15129-208	* Actuator; Micro-SW; M.-M.	1	
	011-95011-008	* Capacitor PCB II Ass'y	1	
23	011-51031-001	** Capacitor PCB	1	
24	011-15164-003	** Sheet; Capacitor PCB	1	
25	011-15713-007	** Bracket; Capacitor PCB	1	
26	011-15098-000	* Hook Spring	2	
27	011-15013-005	* Open/Close Hook	2	
28	014-15008-003	* Shaft; Open/Close Hook; A3	1	
29	014-60002-105	Master End Sensor (Send); A3	1	
30	014-15014-100	Lower Cover; M.-M.; A3	1	
31	550-20118-007	Seal; TPH	1	
31	550-20228-007	Seal; TPH; Pic.	1	
32	014-15013-007	Sheet; Light Absorber; M.-M.	1	

[illegible]


Fig. 33 CUTTER UNIT (RC4000, RC4500, RC5600/D, RC5800)



No.	Part No.	Part Name	Q'ty	Remark
1	011-14506-105	Master Guide C; M.-Rmv.	1	
2	011-15157-007	Stopper	1	
3	011-15293-008	Support Sheet; M.-Rmv.	1	
	011-95111-002	Cutter Cover A Ass'y		
4	011-15047-104	* Cutter Cover A Ass'y	1	
5	011-15049-000	* Set Sheet B	2	
6	011-15048-003	* Set Sheet A	2	
	011-95100-000	Master Sensor Ass'y	1	
7	011-15139-009	* Bracket; Master Sensor II	1	
8	011-60005-307	* Master Sensor	1	
	011-95121-105	Unit/Cutter II; B4		
	011-95122-101	Unit/Cutter II; A4		
9	011-15102-202	* Cutter Body	1	
10	011-15093-009	* Cutter Sheet B	1	
11	011-15175-005	* Cutter Cover D	1	
12	011-15176-001	* Cutter Guide IV	1	
13	011-15177-008	* Master Guide III	2	
14	011-15043-001	* Cutter Guide Sheet (Right)	1	
15	011-15169-005	* Cutter Guide Sheet III	1	
16	011-15044-008	* Cutter Guide Sheet (Left)	1	
17	011-15142-000	* Bracket; Master Positioning Sensor	1	
18	011-15059-102	* Sheet; Master Positioning Sensor	1	
19	011-60006-109	* Master Positioning Sensor	1	
20	011-15107-000	* Cutter Joint B	1	
21	002-11509-104	* Joint A	1	
	011-95045-107	Unit/Cutter Motor		
22	011-65014-002	* Cutter Motor	1	
23	011-15038-008	* Bracket; Cutter Motor	1	
24	011-15039-004	* Bracket; Cutter SW	1	
25	011-95046-006	* Cutter Joint A	1	
26	443-00120-900	* Micro-SW; E23-91	1	


[illegible]

Fig. 34 CUTTER UNIT (RC6300)



[illegible][illegible]


I-78



No.	Part No.	Part Name	Q'ty	Remark
	011-94410-308	Unit/Master Removal III; B4		
	011-94412-203	Unit/Master Removal III; A4		
1	011-14401-001	* Right-Side Frame; M.-Rmv.	1	
2	011-14402-008	* Left-Side Frame; M.-Rmv.	1	
3	011-14405-007	* Base Plate; M-Rmv.	1	
3	011-14433-000	* Base Plate II; M.-Rmv.	1	A4
4	011-14404-108	* Stay B; M.-Rmv.	1	
5	011-14403-004	* Stay A; M.-Rmv.	1	
6	011-14406-100	* Guide Plate; M.-Rmv.; B4	1	
6	011-14434-007	* Guide Plate II; M.-Rmv.	1	A4
7	011-14407-107	* Vertical Transport Roller (Up); B4	1	
7	011-14435-003	* Vertical Transport Roller II (Up); A4	1	A4
8	008-24108-005	* Vertical Transport Roller S (Down)	1	
8	011-14436-000	* Vertical Transport Roller II (Down); A4	1	A4
9	011-14430-109	* Shaft; M.-Rmv.Hook	1	
10	011-14170-000	* Master Removal Hook; A4	2	A4
10	011-14169-001	* Master Removal Hook (R); B4	1	B4
10	011-14168-005	* Master Removal Hook (L); B4	1	B4
11	000-10148-030	* Spring B	1	
12	011-14115-009	* Linking Plate; M.-Rmv. Hook	1	
13	011-65018-300	* Master Removal Solenoid	1	
14	000-10142-016	* Bracket; M.-Rmv. Solenoid	1	
15	011-14408-006	* Bracket; Disposal Box SW	1	
16	443-00121-109	* Micro-SW; 21-52N	1	
17	011-55056-203	* Wire Harness; M.-Rmv.	1	
18	612-03101-006	* Gear; Vertical Transport	2	
19	607-13000-402	* Metal; F6 x 10/9 x 4; 12 x 1.5	2	
20	011-65016-307	* M.-Rmv. Vertical Transport Motor	1	
21	002-14517-000	* Pulley Duct	1	
22	011-14121-009	* Pulley B; M.-Rmv.	1	
23	620-03066-105	* Belt; 264-3M-6	1	
24	011-60022-007	* Switch A	1	
25	011-14446-005	* Bracket II; Master Removal Sensor (Receive)	1	
26	011-60034-307	* Master Removal Sensor (Receive)	1	
	011-94422-004	* Holder Ass'y II; V.-Transport Roller	1	

[illegible]


Fig. 36 MASTER REMOVAL UNIT (RC6300)



No.	Part No.	Part Name	Q'ty	Remark
	014-94400-002	Unit/Master Removal; A3		
1	014-14402-107	* Right-Side Frame; M.-Rmv.;A3	1	
2	014-14404-100	* Left-Side Frame; M.-Rmv.; A3	1	
3	014-14407-001	* Base Plate; M.-Rmv.; A3	1	
4	014-14406-102	* Back Plate; M.-Rmv.; A3	1	
5	014-14405-009	* Stay A; M.-Rmv.; A3	1	
6	014-14411-009	* Guide Plate; M.-Rmv.; A3	1	
7	014-14408-105	* Upper Plate; M.-Rmv.; A3	1	
8	014-14111-102	* Vertical Transport Roller (Down); A3	1	
9	014-14431-000	* Shaft; M.-Rmv. Hook; A3	1	
10	002-14143-011	* Master Removal Hook	2	
11	000-10148-030	* Spring B	1	
12	011-14115-009	* Linking Plate; M.Rmv. Hook	1	
13	011-65018-300	* Master Removal Solenoid	1	
14	000-10142-016	* Bracket; M.-Rmv. Solenoid	1	
15	011-14408-006	* Bracket; Disposal Box SW	1	
16	443-00121-109	* Micro-SW; 21-52N	1	
17	011-55056-203	* Wire Harness; M.-Rmv.	1	
18	002-14130-009	* Gear; Vertical Transport	2	
19	607-13000-402	* Metal; F6 x 10/9 x 6; 12 x 1.5	4	
20	011-65016-307	* M.-Rmv. Vertical Transport Motor	1	
21	002-14517-000	* Pulley; Duct	1	
22	011-14121-009	* Pulley B; M.-Rmv.	1	
23	620-32916-002	* Belt; 291-3M-6	1	
24	011-60022-007	* Switch A	1	
25	011-14446-005	* Bracket II; Master Removal Sensor (Receive)	1	
26	011-60034-307	* Master Removal Sensor (Receive)	1	
27	014-14432-006	* Feed Guide Plate; M.-Rmv.; A3	1	
28	011-60033-300	* Master Removal Sensor (Send)	1	
29	014-14110-009	* Vertical Transport Roller (Up); A3	1	
	014-94410-108	Holder Ass'y; V.-Transport Roller; A3		
30	007-14113-100	* Spring; Vertical Transport	3	
31	635-00409-004	* Plastic Head Screw; M4 x 9	2	
32	014-14428-203	* Upper Holder; V.-Transport Roller; A3	1	
33	638-92000-001	* Plastic Washer; Plastic Head Screw	2	

[illegible]


Fig. 37 MASTER DISPOSAL BOX



No.	Part No.	Part Name	Q'ty	Remark
	014-94435-000	Unit/Master Disposal Box; A3		RC6300
	014-94436-007	Unit/Master Disposal Box; A3; Pic.		RC6300
	011-94431-003	Unit/Master Disposal Box		B4
	011-94432-000	Unit/Master Disposal Box; Pic.		B4
	011-94433-006	Unit/Master Disposal Box II		A4
	011-94434-002	Unit/Master Disposal Box II; Pic.		A4
1	011-44415-007	* Disposal Box	1	
1	014-14451-000	* Disposal Box; A3	1	RC6300
1	011-44417-000	* Disposal Box; Pic.	1	
2	011-14421-100	* Guide Cam; Disposal Box	2	
3	011-14423-200	* Guide Shaft; Disposal Box	1	
3	014-14463-106	* Guide Shaft; Disposal Box; A3	1	RC6300
4	011-14420-103	* Guide Plate; Disposal Box	1	B4
4	014-14461-006	* Guide Plate; Disposal Box; A3	1	RC6300
4	011-14440-007	* Guide Plate II; Disposal Box	1	A4
5	011-14422-106	* Guide Spring; Disposal Box	1	
6	011-44416-003	* Disposal Box Cover	1	
6	011-44418-006	* Disposal Box Cover; Pic.	1	
6	014-44451-102	* Disposal Box Cover; A3	1	RC6300
6	014-44452-109	* Disposal Box Cover; A3; Pic.	1	RC6300
7	011-14425-008	* Shaft; Disposal Box Cover	1	
7	014-14469-007	* Shaft; Disposal Box Cover; A3	1	RC6300
8	011-14427-000	* Lock Shaft; Disposal Box	1	
8	014-14465-001	* Lock Shaft; Disposal Box; A3	1	RC6300
9	011-14428-007	* Lock Spring (Right)	1	
10	011-14429-003	* Lock Spring (Left)	1	
11	014-44453-105	* Disposal Box Cover B; A3	1	RC6300
11	014-44454-101	* Disposal Box Cover B; A3; Pic.	1	RC6300
12	011-14418-001	* H.-Lever (Right); Disposal Box	1	
12	014-14455-200	* H.-Lever (Right); Disposal Box; A3	1	RC6300
13	011-14419-008	* H.-Lever (Left); Disposal Box	1	
13	014-14458-200	* H.-Lever (Left); Disposal Box; A3	1	RC6300
14	011-14417-005	* Handle; Disposal Box	1	
14	014-14454-000	* Handle; Disposal Box; A3	1	RC6300
15	014-14460-107	* Frame; Disposal Handle	1	RC6300

[illegible]


Fig. 38 ELECTRICAL COMPONENT AREA (1) (RC4000)



No.	Part No.	Part Name	Q'ty	Remark
	011-97551-204	Unit/Operation Panel; 40US		U.S.A.
	011-97552-200	Unit/Operation Panel; 40B4		Asia
	011-97553-207	Unit/Operation Panel; 40Pic		Europe
1	011-97555-005	* Key Board Cover Ass'y; 40US	1	
1	011-97556-001	* Key Board Cover Ass'y; 40B4	1	
1	011-97557-008	* Key Board Cover Ass'y; 40Pic	1	
2		** Key Switch		
	011-97540-008	* Pocket Cover Ass'y	1	
3	011-47554-105	** Pocket Cover	1	
4	011-17039-001	** Knob; Pocket Cover	1	
5	011-17040-000	** Plate Spring; Knob; Pocket Cover	1	
6	011-17041-006	* Shaft; Pocket Cover; Panel	1	
7	011-17037-009	* Door; Sub-Panel	1	
8	011-17046-105	* Reinforce Plate; Panel	1	
9	011-17047-004	* Bracket A; Panel	1	
10	011-17048-108	* Bracket B; Keyboard	1	
11	011-51505-003	* Panel Display PCB	1	
12	011-70508-005	* LCD; Panel	1	
13	011-51503-000	* Panel SW PCB	1	
14	011-51511-208	* Panel Main PCB	1	
15		* Sheet; Sub-Panel	1	
16	011-51518-008	* P. VR PCB	1	
17		* Sub-Panel Base	1	
	011-98200-200	Unit/Power Supply III-S; 100V		
	011-98205-105	Unit/Power Supply III-S; 200V		
18		* Power Supply PCB	1	
19		* Bracket; Power Supply PCB	1	
20	011-55116-001	Inlet Terminal; 100V	1	
20	011-55115-102	Inlet Terminal; 200V	1	
21	011-55070-206	Wire Harness; TPH-Power	1	
22	011-55004-203	Wire Harness; Image-Power	1	
23	011-55011-102	Wire Harness; Panel-Power	1	
	011-97235-000	Unit/Counter		
24	011-47210-104	* Bracket; Counter	1	
25	011-65022-200	* Counter	1	

[illegible]


Fig. 39 ELECTRICAL COMPONENT AREA (1) (RC4500, RC5600/D)



No.	Part No.	Part Name	Q'ty	Remark
	011-97530-509	Unit/Operation Panel; 56/D 100US		U.S.A.
	011-97531-505	Unit/Operation Panel; 56/D A4		
	011-97532-404	Unit/Operation Panel; 56/D B4		
	011-97533-303	Unit/Operation Panel; 56/D Pic.		
	011-97542-507	Unit/Operation Panel; 45 B4		
	011-97550-500	Unit/Operation Panel; 45 100US		U.S.A.
	011-97541-500	Unit/Operation Panel; 45 A4		
	011-97543-309	Unit/Operation Panel; 45Pic.		
1	011-97565-009	* Key Board Cover Ass'y; 56/D US	1	
1	011-97575-006	* Key Board Cover Ass'y; 56/D A4	1	
1	011-97585-001	* Key Board Cover Ass'y; 56/D B4	1	
1	011-97576-002	* Key Board Cover Ass'y; 56/D Pic.	1	
1	011-97580-000	* Key Board Cover Ass'y; 45 B4	1	
1	011-97560-009	* Key Board Cover Ass'y; 45 US	1	
1	011-97570-004	* Key Board Cover Ass'y; 45 A4	1	
1	011-97571-000	* Key Board Cover Ass'y; 45 Pic.	1	
2		** Key Switch		
	011-97540-008	* Pocket Cover Ass'y	1	
3	011-47554-105	** Pocket Cover	1	
4	011-17039-001	** Knob; Pocket Cover	1	
5	011-17040-000	** Plate Spring; Knob; Pocket Cover	1	
6	011-17041-006	* Shaft; Pocket Cover; Panel	1	
7	011-17037-009	* Door; Sub-Panel	1	
8	011-17046-105	* Reinforce Plate; Panel	1	
9	011-17047-004	* Bracket A; Panel	1	
10	011-17048-108	* Bracket B; Keyboard	1	
11	011-51505-003	* Panel Display PCB	1	
12	011-70508-005	* LCD; Panel	1	
13	011-51503-000	* Panel SW PCB	1	
14	011-51511-208	* Panel Main PCB	1	
15		* Sheet; Sub-Panel	1	
16	011-51517-001	* P. VR PCB; 56	1	
16	011-51518-008	* P.VR PCB	1	
17		* Sub-Panel Base	1	
	011-90000-504	Unit/ Power Supply; 100V		

[illegible]


Fig. 40 ELECTRICAL COMPONENT AREA (1) (RC5800)



No.	Part No.	Part Name	Q'ty	Remark
	012-97104-205	Unit/Operation Panel; 58B		
	012-97102-202	Unit/Operation Panel; 58US		
	012-97105-201	Unit/Operation Panel; 58Pic.		
	012-96012-005	* Key Board Cover Ass'y; 58B		
	012-96011-009	* Key Board Cover Ass'y; 58US		
	012-96013-001	* Key Board Cover Ass'y; 58Pic.		
1		** Key Board Cover	1	
2		** Key Switch		
	012-96031-000	* Pocket Cover Ass'y; 58	1	
	011-97525-009	* Pocket Cover Ass'y; Pic.	1	
3	012-17032-101	** Pocket Cover; Pic.	1	
3	011-47560-008	** Pocket Cover	1	
4	011-17039-001	** Knob; Pocket Cover	1	
5	011-17040-000	** Plate Spring; Knob; Pocket Cover	1	
6	011-17041-006	* Shaft; Pocket Cover; Panel	1	
7	011-17037-009	* Door; Sub-Panel	1	
8	011-17046-105	* Reinforce Plate; Panel	1	
9	011-17047-004	* Bracket A; Panel	1	
10	011-17048-108	* Bracket B; Keyboard	1	
11	011-51505-003	*Panel Display PCB	1	
12	011-70508-005	* LCD; Panel	1	
13	011-51503-000	* Panel SW PCB	1	
14	012-51605-005	* P.Main PCB; 58	1	
15	012-17052-005	* SW Sheet; 58	1	
15	012-17053-001	* SW Sheet; 58Pic.	1	
16	011-17050-005	* Sub-Panel Base	1	
17	012-51606-001	* P.Sub SW PCB	1	
18	012-17012-003	Pocket Manual; 58	1	
18	012-17014-006	Pocket Manual; 58Pic.	1	
	011-90000-504	Unit/Power Supply; 100V		
	011-90050-307	Unit/Power Supply; 200V	1	
19		* Power Supply PCB	1	
20	485-00002-401	** Fuse 10A 125V 5.2ULTSC	1	
21	485-00001-804	** Fuse 8A 125V 5.2ULTSC	1	
22	485-00002-509	** Fuse 5A 125V 5.2ULTSC	2	

[illegible]


Fig. 41 ELECTRICAL COMPONENT AREA (1) (RC6300)



No.	Part No.	Part Name	Q'ty	Remark
	014-97110-005	Unit/Operation Panel; 63 US		
	014-97111-001	Unit/Operation Panel; 63 Pic.		
	014-97112-008	Unit/Operation Panel; 63		
	014-97210-000	* Key Board Cover Ass'y; 63 US		
	014-97211-006	* Key Board Cover Ass'y; 63 Pic.		
	014-97212-002	* Key Board Cover Ass'y; 63		
1	014-17015-007	** Key Board Cover; 63		
1	014-17016-003	** Key Board Cover; 63 Pic.		
2		** Key Switch		
	011-97525-009	* Pocket Cover Ass'y; Pic.	1	
	012-96031-000	* Pocket Cover Ass'y; 58	1	
3	012-17032-101	** Pocket Cover; Pic.	1	
3	011-47560-008	** Pocket Cover	1	
4	011-17039-001	** Knob; Pocket Cover	1	
5	011-17040-000	** Plate Spring; Knob; Pocket Cover	1	
6	011-17041-006	* Shaft; Pocket Cover; Panel	1	
7	011-17037-009	* Door; Sub-Panel	1	
8	011-17046-105	* Reinforce Plate; Panel	1	
9	011-17047-004	* Bracket A; Panel	1	
10	011-17048-108	* Bracket B; Keyboard	1	
11	011-51505-003	* Panel Display PCB	1	
12	011-70500-004	* LCD; DMF5005N	1	
13	011-51503-000	* Panel SW PCB	1	
14	011-51502-209	* Panel Main PCB	1	
15	014-17012-008	* Sheet; Sub-Panel; 63 US	1	
15	014-17013-004	* Sheet; Sub-Panel; 63 Pic.	1	
16	011-17050-005	* Sheet; Sub-Panel Base	1	
17	012-51606-001	* P.Sub SW PCB	1	
18	014-17052-000	Pocket Manual; 63	1	
18	014-17053-006	Pocket Manual; 63Pic.		
19	011-17049-007	Sponge; Pocket Manual	2	
20	011-90100-304	Power Supply PCB III H100	1	
20	011-90105-004	Power Supply PCB III H200	1	
21	485-00002-401	* Fuse 10A 125V 5.2 ULTSC	1	
22	485-00001-804	* Fuse 8A 125V 5.2 ULTSC	1	

[illegible]


Fig. 42 ELECTRICAL COMPONENT AREA (2) (RC4000, RC4500, RC5600/D)



No.	Part No.	Part Name	Q'ty	Remark
1	011-16023-004	Wire Harness Stay (Upper); Scanner	1	
2	011-16024-000	Wire Harness Stay (Lower); Scanner	1	
	011-96055-009	Wire Harness Ass'y; Image; 40		RC4000
	011-96050-104	Wire Harness Ass'y; Image		
3	011-55004-203	* Wire Harness; Image-Power	1	
4	011-55138-005	* Wire Harness; Image-TPH; 40	1	RC4000
4	011-55005-404	* Wire Harness; TPH	1	
5	011-55134-107	* Wire Harness; CN2; Image Processing; 40	1	RC4000
5	011-55002-308	* Wire Harness; CN2; Image Processing	1	
6	011-55041-109	Ground Wire; Image	1	
7	011-70010-201	Protection Net; Wire Harness	1	
8	011-16107-003	Bracket; Wire Harness	1	
9	011-55116-001	Inlet Terminal; 100V	1	
9	011-55115-102	Inlet Terminal; 200V	1	
10	488-00013-103	Power Cord; 100V	1	
10	488-00014-100	Power Cord; US	1	
10	488-00015-106	Power Cord; 200V	1	
11	011-18102-009	Bracket (Right); System PCB	1	
12	011-18103-005	Bracket (Left); System PCB	1	
13	011-18104-001	Sheet; System PCB	1	
	011-98120-509	Unit/System PCB II	1	
14	011-51500-702	* System Main PCB II	1	
15	014-51501-000	* System Drive PCB III	1	
15	011-51501-709	System Drive PCB II	1	*
16	011-55087-109	Wire Harness; CN1 & CN8	1	
17	011-55134-107	Wire Harness; CN2; Image Processing; 40	1	RC4000
17	011-55002-308	Wire Harness; CN2; Image Processing	1	
18	011-55003-100	Wire Harness; CN3; Panel	1	
19	011-55090-100	Wire Harness; CN4, CN5, CN9 & CN10	1	
19	011-55090-100	Wire Harness; CN4, CN5, CN9 & CN10; 45	1	
19	011-55095-101	Wire Harness; CN4, CN5, CN9 & CN10; Pressure Det.	1	
20	011-55016-309	Wire Harness; CN6	1	
21	011-55017-100	Wire Harness; CN7	1	
22	011-55021-302	Wire Harness; CN11	1	
23	011-55001-204	Wire Harness; CN12; Power	1	

[illegible]

Fig. 43 ELECTRICAL COMPONENT AREA (2) (RC5800, RC6300)




No.	Part No.	Part Name	Q'ty	Remark
1	488-00013-103	Power Cord; 100V	1	
1	488-00014-100	Power Cord; US	1	
1	488-00015-106	Power Cord; 200V	1	
2	665-04036-007	Free Bushing; KG-024K	1	
3	665-04012-000	Snap Bushing; SB-1500-21	1	
4	665-04014-003	Snap Bushing; SB-2000-26	2	
5	011-55116-001	Inlet Terminal; 100V	1	
5	011-55115-102	Inlet Terminal; 200V	1	
5	014-55009-002	Inlet Terminal; 200V; A3	1	RC6300
5	014-55008-006	Inlet Terminal; 100V; A3	1	RC6300
6	550-20119-003	Seal; Ground	1	
7	505-00600-001	Board Spacer; SPS-20	2	
8	011-18102-009	Bracket (Right); System PCB	1	
9	011-18103-005	Bracket (Left); System PCB	1	
10	505-00310-003	Support Post (R); SP-3-3-01	6	
11	011-18104-001	Sheet; System PCB	1	
12	011-55095-101	Wire Harness; CN4,CN5,CN9 & CN10; Pressure Det.	1	
13	011-55021-302	Wire Harness; CN11	1	
14	011-55001-204	Wire Harness; CN12; Power	1	
15	011-55003-100	Wire Harness; CN3; Panel	1	
16	011-55016-309	Wire Harness; CN6	1	
17	011-55087-109	Wire Harness; CN1 & CN8	1	
17	014-55007-000	Wire Harness; CN1 & CN8; A3	1	RC6300
	011-98120-509	Unit/System PCB II		
18	011-51500-702	* System Main PCB II	1	
19	488-90004-108	* Ground Wire	2	
20	014-51501-000	* System Drive PCB III	1	
20	011-51501-709	System Drive PCB II	1	*
21	012-55057-207	Wire Harness; Image Processing; 58	1	
22	012-16240-002	Bracket; Wire Harness	1	
23	012-16241-009	Holder A; Wire Harness	1	
24	012-16242-005	Holder B; Wire Harness	1	
25	012-55049-107	Junction Wire; CN2; Image	1	
26	435-00004-003	Core Set; ESD OR-25	1	
27	014-55004-000	Wire Harness; TPH Signal	1	

[illegible]

Fig. 44 EXTERIOR COVER AREA (RC4000, RC4500, RC5600/D)


96-1



No.	Part No.	Part Name	Q'ty	Remark
	011-96070-008	Unit/ADF Cover; 56D		
	011-96075-000	* Unit/Clip; 56D		
1	011-17502-100	** Clip B	1	
2	011-17504-006	** Rubber; Clip	2	
3	011-17503-000	** Plate Spring; Clip	1	
4	011-17501-007	** Clip A; 56D	1	
5	011-17508-109	** Scroll Magnet; 56D	1	
6	011-17505-002	** Scroll Arm; 56D	1	
7	011-17506-009	** Fulcrum; 56D	2	
	011-96080-003	* Unit/ADF Cover; 45, 56		
8	011-17106-000	** ADF Cover	1	
9	011-17108-003	** Original Side Guide (Left)	1	
10	011-17107-007	** Original Side Guide (Right)	1	
11	009-35406-005	** Slide Rack; Original Holder (A3)	2	
12	005-24114-003	** Shaft Gear; Original Holder	1	
13	011-17109-000	** Set Plate; Original Holder	1	
14	011-16003-100	** Catch Plate; ADF Cover	1	
15	011-16001-108	** Set Plate; ADF Cover	1	
16	011-17113-007	Original Tray	1	
17	011-17105-004	Front Left Cover	1	
18	002-11131-004	Lower Hinge; Front	1	
19	002-17006-007	Shaft Catch; Front Cover	2	
20	011-17101-009	Front Cover	1	
21	002-12542-300	Cushion; Ink Bottle	1	
22	011-17102-005	Magnet Catch Plate; Front	1	
23	002-17016-002	Cover Catch A; Front	1	
24	011-14503-106	Inner Cover B	1	
25	002-17017-203	Cover Catch B; Front	1	
26	011-47103-103	Front Right Cover	1	
27	550-20362-005	Emblem; 4000	1	
27	550-20208-006	Emblem; 4500	1	
27	550-20209-002	Emblem; 5600	1	
27	550-20210-000	Emblem; 5600D	1	
	011-97210-008	Inner Cover A Ass'y		
28	011-17212-102	* Inner Cover A	1	


[illegible]

Fig. 45 EXTERIOR COVER AREA (RC5800, RC6300)




[illegible][illegible]

Fig. 46 EXTERIOR COVER AREA (ADF): (RC5800, RC6300)



[illegible][illegible]

Fig. 47 DIGITIZER (RC5800, RC6300)



No.	Part No.	Part Name	Q'ty	Remark
1	011-96520-003	Stylus Pen	1	
	012-96601-000	Unit/Digitizer; 58US		
	012-96602-007	Unit/Digitizer; 58Eu		
	012-96603-003	Unit/Digitizer; 58Pic.		
	012-96611-006	* Digitizer Ass'y; 58US	1	
	012-96612-002	* Digitizer Ass'y; 58Eu	1	
	012-96613-009	* Digitizer Ass'y; 58Pic.	1	
2	011-45513-002	** Digitizer Sheet	1	
2	011-45514-009	** Digitizer Sheet; Pic.	1	
3	012-16624-102	** Digitizer Cover (Upper); 58US	1	
3	012-16625-001	** Digitizer Cover (Upper); 58Eu	1	
3	012-16626-008	** Digitizer Cover (Upper); 58Pic.	1	
4	011-17517-108	** Tablet	1	
5	012-16611-000	* Protection Sheet; Tablet	1	
6	012-16605-108	* Holding Plate; Tablet	1	
7	011-51011-302	* Digitizer PCB	1	
8	012-55009-008	* Wire Harness; Digitizer (Inner)	1	
9	012-55008-001	Wire Harness; Digitizer (Outer)	1	
10	012-16607-003	Hinge; Digitizer	1	
11	012-16616-002	Hinge Sponge	1	
12	012-16606-007	Frame; Digitizer; 58	1	
13	011-17502-100	Clip B	1	
14	011-17504-006	Rubber; Clip	2	
15	011-17503-000	Plate Spring; Clip	1	
16	012-16603-008	Lower Clip; 58	1	
17	012-16604-209	Original Slide Plate; Digitizer 58	1	
18	012-16608-000	Digitizer Rail; 58	1	
19	012-16610-004	Bracket; Scroll SW	1	
20	660-05000-603	Magnet Catch; TL-98S-AL-F	2	
21	012-60001-007	Scroll SW A	1	
22	012-60002-003	Scroll SW B	1	
23	012-16602-001	Digitizer Cover (Lower)	1	

[illegible]

II. INDEX

[NOTICE]

- ★ When you order spare parts, please never fail to order the parts listed in this Index after making sure of what is the spare parts you want.
- ★ For modified or added parts, please refer to the technical information issued by our technical department.
- ★ What the part No. means;

Ex.)

0 0 0 - 0 8 9 4 0 - 0 0 1

- For classification of parts
- Main number in part No.
- Surfix No.
(In case of modification
this number is changed.)

- When you order spare parts, please never fail to inform us all of this part No. (the number of eleven figures).