


M41A Static counter DIP switches



Hardcoded to display 00 when there is no magazine inserted.

The Display comes pre-set at 95 when the microswitch is pressed in by the magazine.

Carefully slide the DIP switch to the ON (1) position with a small flat screwdriver to match the table below to set the number you wish to display.

Decimal	DIP Switch position
0	11111100
1	01100000
2	11011010
3	11110010
4	01100110
5	10110110
6	00111110
7	11100000
8	11111110
9	11100110