


INSTRUCTIONS

To change the time:


- Press down on the RGB Encoder and Push Button for more than half a second.
- The RGB Encoder will light up RED and only the hours will be shown on the Display Ring as a RED LED.
- Rotate the RGB Encoder to change the hour
- Press again for minutes. The RGB Encoder will be GREEN and the minutes will be shown on the Display Ring as a GREEN LED.
- Repeat for seconds. The encoder will be BLUE and seconds are shown on the Display Ring as a BLUE LED

To change brightness and display mode:

- Press down on the RGB Encoder and Push Button for less than half a second.
- The RGB Encoder will light up PINK. Rotate the encoder to set the brightness (four levels).
- Press again, the RGB Encoder will light up CYAN. Rotate the encoder to select different time display modes.



Display Ring



Controller

