

- Modes Navigation Sec – switch between various surface modes

Modifier Sec – modify buttons behaviour

Channels Sec – actions related to channels (or anything assigned to channels)

Navigation Sec – navigate between channels or apply group action to all of them

Master Channel Sec - actions related to master fader
- Display Sec – affect display information

Functions Sec – various function mode dependent

Automation Sec – channel/global automation

Transport Sec – transport actions
- Save Sec – save/undo/redo

Marker Sec – modify markers

Zoom Sec – move or zoom

DispU1	DispU2	DispU3	DispU4	DispU5	DispU6	DispU7	DispU8
DispL1	DispL2	DispL3	DispL4	DispL5	DispL6	DispL7	DispL8

Enc1

Enc2

Enc3

Enc4

Enc5

Enc6

Enc7

Enc8

Rec 1

Rec 2

Rec 3

Rec 4

Rec 5

Rec 6

Rec 7

Rec 8

Solo 1

Solo 2

Solo 3

Solo 4

Solo 5

Solo 6

Solo 7

Solo 8

Mute 1

Mute 2

Mute 3

Mute 4

Mute 5

Mute 6

Mute 7

Mute 8

Sel 1

Sel 2

Sel 3

Sel 4

Sel 5

Sel 6

Sel 7

Sel 8

F1

F2

F3

F4

F5

F6

F7

F8

Lock

Options

<

>

<<

>>

M

F

Change Display Sec

Home

SMPTE

Undo

Redo

Save

Layer 2

F1

F2

F3

F4

F5

F6

F7

F8

Layer Navigation Sec

Pan

Sends

Receives

Inserts

Automation

Aut. FX

Map

Trim/Read

Write/Latch

Touch/LatPrev

Project

Mixer

Help

Control

Alt

Shift

Rewind

Loop

FForward

Left Marker

Marker

Right Marker

Rec

Stop

Play

Zoom Sec

Up

Left

Zoom

Right

Down

Shift

Jog Wheel

Jog Wheel Sec