




Logic Level Converter Fix

NixieClock



- Do not solder U10
- Connect the converter board according to following pages





Only one GND connection is needed

Take 3.3V and GND from connector socket on the right (with SCL and SDA