



CONNECTORS

J1: Power supply

- 1: +5V
- 2: GND

J2: TTL serial port

- 1: TXD
- 1: RXD
- 1: GND

J3: RS232C serial port

- 1: TXD
- 2: RXD
- 3: GND

JUMPERS

JP1: reset

JP2-3: operation modes

Op. mode JP3 JP2

Mode #0 OFF OFF

Mode #1 OFF ON

Mode #2 ON OFF

Mode #3 ON ON