



//This decoder works by setting the value of enable bitshifted by the number of places equal to the address to out  
 //If enable is 1, enable will be shifted over the number of places dictated by address to cause the out[address] to be one  
 //If enable is zero, all bits will be zero (a bitshifted zero is always zero)