

Thank you for your review.




When and how should I clean or replace the air filter?

See below.

Cleaning the Air Filter and Vents

Clean the projector's air filter or vents if they get dusty, or if you see a message telling you to clean them.

1. Turn off the projector and unplug the power cord.
2. Gently remove the dust using a small vacuum designed for computers or a very soft brush (such as a paintbrush).



Note: You can remove the air filter so you can clean both sides of it. Do not rinse the air filter in water, or use any detergent or solvent to clean it.

Caution:

Do not use canned air. The gases may leave a flammable residue or push dust and debris into the projector's optics or other sensitive areas.

3. If dust is difficult to remove or the air filter is damaged, replace the air filter.

Replacing the Air Filter


You need to replace the air filter in the following situations:

- After cleaning the air filter, you see a message telling you to clean or replace it
- The air filter is torn or damaged


You can replace the air filter while the projector is mounted to the ceiling or placed on a table.

1. Turn off the projector and unplug the power cord.

2. Carefully open the air filter cover.




3. Pull the air filter out of the projector.



Note: Air filters contain ABS resin and polyurethane foam. Dispose of used air filters according to local regulations.

4. Place the new air filter in the projector as shown and push gently until it clicks into place.



5. Close the air filter cover.

Related references

Optional Equipment and Replacement Parts

(https://files.support.epson.com/docid/cpd4/cpd42907/source/product_info/reference/ex3240_pl1224_vs240_s31/opti)

Published: Sep 1, 2015

Was this helpful?

- ☐ Yes
- ☐ No

Stay Connected

Follow Us

with Epson

Enter Your Email Address 

You are providing your consent to Epson America, Inc., doing business as Epson, so that we may send you promotional emails. You may withdraw your consent or view our privacy policy (/privacy-policy) at any time. To contact Epson America, you may write to 3840 Kilroy Airport Way, Long Beach, CA 90806 or call 1-800-463-7766.

Copyright © 2000-2017 Epson America, Inc
[Terms of Use \(/terms-of-use\)](#) | [California Privacy Rights \(/privacy-rights-california\)](#)
| [Privacy Policy \(/privacy-policy\)](#)

