

Connect XTAG
USB to host PC

Connect xCORE board
power cable to power
on the system

Connect Ethernet
sliceCARD to Router
or host PC with
Ethernet cable

