



**PARTIALS (2-6)** 



## **STAGES** — Common Configurations

**AD** envelope

**AR Envelope** 

**ADR** envelope

**ADSR** envelope

ADSR with pre-delay & start level

ADSR with non-zero rest level

AHDSR with hold level & time

**ADSAR** 

**ADAR** 

ADRcy with settable sustain

**ADARcy** 

**3** notes with variable glide

**Trapezoid LFO** 

Envelope with random-level step

Envelope with random-level hold


AD with specific start value

Cycle on gate

Maths-style envelope


Triangle LFO with reset to zero

Step Sequence or CV 'Switch"



STEP (n)

**CONTROL (1st)** 



Document version v1.2.0a; created by Philip Belesky. Stages firmware by Émilie Gillet (Mutable Instruments) and modified firmware by Bryan Head (Qiemem). Latest download at: https://github.com/qiemem/eurorack