

Time Circuits Display

DR. E. BROWN ENTERPRISES
24 HR. SCIENTIFIC SERVICES



Destination time programming	
Set date and time	mmddyyyyhhMM↵
Set date / time only	mmddyyyy↵ / hhMM↵

Disable / Enable beep sound	000↵ / 001↵
Enable beep sound (30/60 seconds)	002↵ / 003↵
Toggle Room Condition mode	111↵
Toggle World Clock mode	112↵
Toggle both WC and RC mode	113↵
Show weekday of <i>present time</i> date	33↵
Select volume level / Enable knob	300 - 319↵ / 399↵
Disable / Enable line-out audio	350↵ / 351↵
Alarm : Show / Set to hh:MM	11↵ / 11hhMM↵
Timer : Show remaining time	44↵
Timer : Set timer to MM minutes	44MM↵
Timer : Delete timer	440↵
Reminder : Display reminder	77↵ / 777↵
Reminder : Program reminder	77mmdd↵
Reminder : Program reminder	77mmddhhMM↵
Reminder : Delete reminder	770↵
Music Player : Display curr. played	55↵
Music Player : Shuffle off / on	222↵ / 555↵
Music Player : Go to song 000 / xxx	888↵ / 888xxx↵
Disable / Enable Car Mode	990↵ / 991↵
Forbid / Allow Remote Control	992↵ / 993↵
Forbid / Allow Keypad Rem. Control	994↵ / 995↵
Release HA Fake-Power Control	996↵
Restore stored dest./last dep. times	998↵
Toggle Exhibition Mode	999↵
Program Time for Exhibition Mode	99mmddyyyyhhMM↵
Restart the Time Circuits	64738↵

Time Circuits Display



Holding keys for 2 seconds		
<div>1</div> <div>Toggle Alarm on/off</div>	<div>2</div> <div>Music Player : Previous song</div>	<div>3</div> <div>Play "key3.mp3"</div>
<div>4</div> <div>Toggle Night mode</div>	<div>5</div> <div>Music Player : Play/Stop</div>	<div>6</div> <div>Play "key6.mp3"</div>
<div>7</div> <div>Re-enable WiFi</div>	<div>8</div> <div>Music Player : Next song</div>	<div>9</div> <div>Return from Time Travel</div>
	<div>0</div> <div>Time Travel</div>	