


Armachat Screens

Screen Name	320x240 Pixels	280x240 Pixels	240x240 Pixels	160x80 Pixels	Keypad																																																		
Font	neep-24.pcf Monospaced 12x24px	neep-24.pcf Monospaced 12x24px	neep-24.pcf Monospaced 12x24px	pavlova-16.pcf Monospaced 8x16px	Special Keys on all screens but editor <ul style="list-style-type: none">Q - Keyboard Backlight ToggleA - Display Backlight ToggleZ - Display DimX - Display Bright																																																		
Characters & Lines	26 chars x 10 lines	23 chars x 10 lines	20 chars x 10 lines	20 chars x 5 lines																																																			
Armachat Models	Max Compact	Max Compact	Max Compact	Watch																																																			
Notes				Scrolling of the screen is done with: <ul style="list-style-type: none">[O] - Up[L] - Down																																																			
Main	<pre>ARMACHAT 915.00MHz RO >(12-36-124-2)DemoUser [N] New message [D] To:(12-36-124-255)All [M] Messages = ALL: 1 New:0 Undelivered:0 [] [I] HW Info [] [P] Ping [T] Terminal [S] Setup Ready ...</pre>			<pre>915.00MHz RO >(12-36-124-2)DemoUs [N] New message [D] To:Broadcast [M] Messages-A:1 New:0 Undeliv:0 [] [I] HW Inf [] [P] Ping [T] Term [S] Setup Ready ...</pre>	<table><tr><td>Q</td><td>W</td><td>E</td><td>R</td><td>T</td><td>Y</td><td>U</td><td>I</td><td>O</td><td>P</td></tr><tr><td>A</td><td>S</td><td>D</td><td>F</td><td>G</td><td>H</td><td>J</td><td>K</td><td>L</td><td>DEL</td></tr><tr><td>ALT</td><td>Z</td><td>X</td><td>C</td><td>V</td><td>B</td><td>N</td><td>M</td><td>SPC</td><td>ENT</td></tr><tr><td colspan="10">Key</td></tr><tr><td colspan="2">Special</td><td colspan="3">Menu</td><td colspan="5">Navigation</td></tr></table>	Q	W	E	R	T	Y	U	I	O	P	A	S	D	F	G	H	J	K	L	DEL	ALT	Z	X	C	V	B	N	M	SPC	ENT	Key										Special		Menu			Navigation				
Q	W	E	R	T	Y	U	I	O	P																																														
A	S	D	F	G	H	J	K	L	DEL																																														
ALT	Z	X	C	V	B	N	M	SPC	ENT																																														
Key																																																							
Special		Menu			Navigation																																																		
[M] Messages Splash Screen	<pre>Messages Scroll [L]down [O]up Pg [ENT]next [DEL]previous [SPC] details [ESC] to exit ALT-Ex Ent> Del< SPC-Detail</pre>			<pre>Messages Scroll [L]dwn [O]up Pg [ENT]nxt [DEL]pre [SPC] details [ESC] to exit Ent> Del< SPC-Detail</pre>	<table><tr><td>Q</td><td>W</td><td>E</td><td>R</td><td>T</td><td>Y</td><td>U</td><td>I</td><td>O</td><td>P</td></tr><tr><td>A</td><td>S</td><td>D</td><td>F</td><td>G</td><td>H</td><td>J</td><td>K</td><td>L</td><td>DEL</td></tr><tr><td>ALT</td><td>Z</td><td>X</td><td>C</td><td>V</td><td>B</td><td>N</td><td>M</td><td>SPC</td><td>ENT</td></tr><tr><td colspan="10">Key</td></tr><tr><td colspan="2">Special</td><td colspan="3">Menu</td><td colspan="5">Navigation</td></tr></table>	Q	W	E	R	T	Y	U	I	O	P	A	S	D	F	G	H	J	K	L	DEL	ALT	Z	X	C	V	B	N	M	SPC	ENT	Key										Special		Menu			Navigation				
Q	W	E	R	T	Y	U	I	O	P																																														
A	S	D	F	G	H	J	K	L	DEL																																														
ALT	Z	X	C	V	B	N	M	SPC	ENT																																														
Key																																																							
Special		Menu			Navigation																																																		
[M] Messages View Message	<pre>ARMACHAT 915.00MHz RO Message: 0 a1 a2 a3 a4 a5 a6 a7 ALT-Ex Ent> Del< SPC-Detail</pre>			<pre>915MHz RO Message: 0 a1 a2 a3 a4 a5 a6 a7 Ent> Del< SPC-Detail</pre>																																																			
[M] Messages View Message Detail	<pre>ARMACHAT 915.00MHz RO Message: 0 Status:5 To:1 From:2 MsgId:3 Hop:4 RSSI:6 SNR:7 Time:8 [ALT] Exit [SPC] Message</pre>			<pre>915MHz RO Message: 0 Detail Status:5 To:1 From:2 MsgId:3 Hop:4 RSSI:6 SNR:7 Time:8 [ALT] Exit [SPC] Msg</pre>																																																			
[I] HW Info	<pre>ARMACHAT 915.00MHz RO System info: VSYs power = 4.53 V USB power connected Disk size 1004.0 KB Free space 91.0 KB CPU Temp: 29.95 degrees C - - [ALT] Exit</pre>			<pre>915MHz RO System info: VSYs power = 4.53 V USB power connected Disk size 1004.0 KB Free space 91.0 KB CPU Temp: 29.95 C [ALT] Exit</pre>	<table><tr><td>Q</td><td>W</td><td>E</td><td>R</td><td>T</td><td>Y</td><td>U</td><td>I</td><td>O</td><td>P</td></tr><tr><td>A</td><td>S</td><td>D</td><td>F</td><td>G</td><td>H</td><td>J</td><td>K</td><td>L</td><td>DEL</td></tr><tr><td>ALT</td><td>Z</td><td>X</td><td>C</td><td>V</td><td>B</td><td>N</td><td>M</td><td>SPC</td><td>ENT</td></tr><tr><td colspan="10">Key</td></tr><tr><td colspan="2">Special</td><td colspan="3">Menu</td><td colspan="5">Navigation</td></tr></table>	Q	W	E	R	T	Y	U	I	O	P	A	S	D	F	G	H	J	K	L	DEL	ALT	Z	X	C	V	B	N	M	SPC	ENT	Key										Special		Menu			Navigation				
Q	W	E	R	T	Y	U	I	O	P																																														
A	S	D	F	G	H	J	K	L	DEL																																														
ALT	Z	X	C	V	B	N	M	SPC	ENT																																														
Key																																																							
Special		Menu			Navigation																																																		
[S] Setup Splash Screen	<pre>Setup Scroll [L]down [O]up Pg [ENT]next [DEL]previous [ALT] to exit</pre>			<pre>Setup Scroll [L]dwn [O]up Pg [ENT]nxt [DEL]pre [ALT] to exit</pre>	<table><tr><td>Q</td><td>W</td><td>E</td><td>R</td><td>T</td><td>Y</td><td>U</td><td>I</td><td>O</td><td>P</td></tr><tr><td>A</td><td>S</td><td>D</td><td>F</td><td>G</td><td>H</td><td>J</td><td>K</td><td>L</td><td>DEL</td></tr><tr><td>ALT</td><td>Z</td><td>X</td><td>C</td><td>V</td><td>B</td><td>N</td><td>M</td><td>SPC</td><td>ENT</td></tr><tr><td colspan="10">Key</td></tr><tr><td colspan="2">Special</td><td colspan="3">Menu</td><td colspan="5">Navigation</td></tr></table>	Q	W	E	R	T	Y	U	I	O	P	A	S	D	F	G	H	J	K	L	DEL	ALT	Z	X	C	V	B	N	M	SPC	ENT	Key										Special		Menu			Navigation				
Q	W	E	R	T	Y	U	I	O	P																																														
A	S	D	F	G	H	J	K	L	DEL																																														
ALT	Z	X	C	V	B	N	M	SPC	ENT																																														
Key																																																							
Special		Menu			Navigation																																																		

	[ALT] Exit [Ent] > [Del] <			ALT-Ex ENT>RT DEL<Lt																																		
[S] Setup Radio	ARMACHAT 915.00MHz RO 0 Radio: [F] Frequency: 915.00MHz [P] Power 23 [S] Profile 1 Bw500Cr45Sf128 Short/Fast [ALT] Exit [Ent] > [Del] <			915.00MHz RO 0 Radio: [F] Freq: 915.00MHz [P] Power 23 [S] Profile 1 Bw500Cr45Sf128 Short/Fast [ALT-Ex ENT>RT DEL<Lt	<table><tr><td>Q</td><td>W</td><td>E</td><td>R</td><td>T</td><td>Y</td><td>U</td><td>I</td><td>O</td><td>P</td></tr><tr><td>A</td><td>S</td><td>D</td><td>F</td><td>G</td><td>H</td><td>J</td><td>K</td><td>L</td><td>DEL</td></tr><tr><td>ALT</td><td>Z</td><td>X</td><td>C</td><td>V</td><td>B</td><td>N</td><td>M</td><td>SPC</td><td>ENT</td></tr></table> <div>Key</div> <table><tr><td>Special</td><td>Menu</td><td>Navigation</td></tr></table>	Q	W	E	R	T	Y	U	I	O	P	A	S	D	F	G	H	J	K	L	DEL	ALT	Z	X	C	V	B	N	M	SPC	ENT	Special	Menu	Navigation
Q	W	E	R	T	Y	U	I	O	P																													
A	S	D	F	G	H	J	K	L	DEL																													
ALT	Z	X	C	V	B	N	M	SPC	ENT																													
Special	Menu	Navigation																																				
[S] Setup Identity	ARMACHAT 915.00MHz RO 1 Identity: [N] Name: DemoUser ----- [E] Encryption {} [G] Group 3:3 [G] Group 2:2 [G] Group 1:1 [I] ID: 1 [ALT] Exit [Ent] > [Del] <			915.00MHz RO 1 Identity: [N] Name: DemoUser ----- [E] Encryption {} [G] Group 3:3 [G] Group 2:2 [G] Group 1:1 [I] ID: 1 [ALT-Ex ENT>RT DEL<Lt	<table><tr><td>Q</td><td>W</td><td>E</td><td>R</td><td>T</td><td>Y</td><td>U</td><td>I</td><td>O</td><td>P</td></tr><tr><td>A</td><td>S</td><td>D</td><td>F</td><td>G</td><td>H</td><td>J</td><td>K</td><td>L</td><td>DEL</td></tr><tr><td>ALT</td><td>Z</td><td>X</td><td>C</td><td>V</td><td>B</td><td>N</td><td>M</td><td>SPC</td><td>ENT</td></tr></table> <div>Key</div> <table><tr><td>Special</td><td>Menu</td><td>Navigation</td></tr></table>	Q	W	E	R	T	Y	U	I	O	P	A	S	D	F	G	H	J	K	L	DEL	ALT	Z	X	C	V	B	N	M	SPC	ENT	Special	Menu	Navigation
Q	W	E	R	T	Y	U	I	O	P																													
A	S	D	F	G	H	J	K	L	DEL																													
ALT	Z	X	C	V	B	N	M	SPC	ENT																													
Special	Menu	Navigation																																				
[S] Setup Display	ARMACHAT 915.00MHz RO 2 Display: [B] Bright 1 [I] Sleep 0 [F] Font 2 [T] Theme 1 [ALT] Exit [Ent] > [Del] <			915.00MHz RO 2 Display: [B] Bright 1 [I] Sleep 0 [F] Font 2 [T] Theme 1 [ALT-Ex ENT>RT DEL<Lt	<table><tr><td>Q</td><td>W</td><td>E</td><td>R</td><td>T</td><td>Y</td><td>U</td><td>I</td><td>O</td><td>P</td></tr><tr><td>A</td><td>S</td><td>D</td><td>F</td><td>G</td><td>H</td><td>J</td><td>K</td><td>L</td><td>DEL</td></tr><tr><td>ALT</td><td>Z</td><td>X</td><td>C</td><td>V</td><td>B</td><td>N</td><td>M</td><td>SPC</td><td>ENT</td></tr></table> <div>Key</div> <table><tr><td>Special</td><td>Menu</td><td>Navigation</td></tr></table>	Q	W	E	R	T	Y	U	I	O	P	A	S	D	F	G	H	J	K	L	DEL	ALT	Z	X	C	V	B	N	M	SPC	ENT	Special	Menu	Navigation
Q	W	E	R	T	Y	U	I	O	P																													
A	S	D	F	G	H	J	K	L	DEL																													
ALT	Z	X	C	V	B	N	M	SPC	ENT																													
Special	Menu	Navigation																																				
[S] Setup Sound	ARMACHAT 915.00MHz RO 3 Sound: [V] Volume 6 [T] Tone [M] Melody [ALT] Exit [Ent] > [Del] <			915.00MHz RO 3 Sound: [V] Volume 6 [T] Tone [M] Melody [ESC-Ex ENT>RT DEL<Lt	<table><tr><td>Q</td><td>W</td><td>E</td><td>R</td><td>T</td><td>Y</td><td>U</td><td>I</td><td>O</td><td>P</td></tr><tr><td>A</td><td>S</td><td>D</td><td>F</td><td>G</td><td>H</td><td>J</td><td>K</td><td>L</td><td>DEL</td></tr><tr><td>ALT</td><td>Z</td><td>X</td><td>C</td><td>V</td><td>B</td><td>N</td><td>M</td><td>SPC</td><td>ENT</td></tr></table> <div>Key</div> <table><tr><td>Special</td><td>Menu</td><td>Navigation</td></tr></table>	Q	W	E	R	T	Y	U	I	O	P	A	S	D	F	G	H	J	K	L	DEL	ALT	Z	X	C	V	B	N	M	SPC	ENT	Special	Menu	Navigation
Q	W	E	R	T	Y	U	I	O	P																													
A	S	D	F	G	H	J	K	L	DEL																													
ALT	Z	X	C	V	B	N	M	SPC	ENT																													
Special	Menu	Navigation																																				
Editor [N] New message [S] Setup - [N] Name [S] Setup - [E] Encryption [S] Setup - [G] Group [S] Setup - [I] Id	Armachat EDITOR U [abc] 0:0/0 [Ent] Send [Del] Delete			Armachat EDITOR U [abc] 0:0/0 [Ent] Send [Del] Del	<table><tr><td>Q</td><td>W</td><td>E</td><td>R</td><td>T</td><td>Y</td><td>U</td><td>I</td><td>O</td><td>P</td></tr><tr><td>A</td><td>S</td><td>D</td><td>F</td><td>G</td><td>H</td><td>J</td><td>K</td><td>L</td><td>DEL</td></tr><tr><td>ALT</td><td>Z</td><td>X</td><td>C</td><td>V</td><td>B</td><td>N</td><td>M</td><td>SPC</td><td>ENT</td></tr></table> <div>Key</div> <table><tr><td>Special</td><td>Menu</td><td>Navigation</td></tr></table> <div>Notes regarding ALT key:</div> <ul style="list-style-type: none">• Short press changes layout from [abc] to [ABC] to [123]• Long press locks the current layout• Short press when layout is locked changes layout and locks the new layout• Second long press unlocks the layout	Q	W	E	R	T	Y	U	I	O	P	A	S	D	F	G	H	J	K	L	DEL	ALT	Z	X	C	V	B	N	M	SPC	ENT	Special	Menu	Navigation
Q	W	E	R	T	Y	U	I	O	P																													
A	S	D	F	G	H	J	K	L	DEL																													
ALT	Z	X	C	V	B	N	M	SPC	ENT																													
Special	Menu	Navigation																																				
Editor [S] Setup - [N] Name [S] Setup - [E] Encryption [S] Setup - [G] Group [S] Setup - [I] Id [ALT] Pressed (Short)	Armachat EDITOR U [ABC] 0:0/0 [Ent] > Right [Del] < Left			Armachat EDITOR U [ABC] 0:0/0 [Ent] >Rt [Del] <Lt																																		
Editor [S] Setup - [N] Name [S] Setup - [E] Encryption [S] Setup -	Armachat EDITOR U [123] 0:0/0 [Ent] Down [Del] Up			Armachat EDITOR U [123] 0:0/0 [Ent] Down [Del] Up																																		

[G] Group [S] Setup - [I] Id [ALT] Pressed (Short)					
Editor [S] Setup - [N] Name [S] Setup - [E] Encryption [S] Setup - [G] Group [S] Setup - [I] Id [ALT] Pressed (Long)	