



Connection for stepper motor driver carrier 1



Connection for stepper motor driver carrier 2



Connection for RC receiver

FUTABA RC receiver
R6208SB

86Duino

