

User Guide

October 2016

Version 1.001

RollingDice Technologies Pvt. Ltd.

Registered Office:

Unit 4 & 5, D Building, Panchratna Apartment,

Off Pune - Solapur Highway, Wanowrie, Fatima Nagar,

Pune – 411013, Maharashtra, INDIA.

Copyright Disclaimer

Copyright© RollingDice Technologies Pvt. Ltd. (All rights reserved)

DEFT is protected by copyright law and international treaties. The Product and software is licensed (not sold), and its use is subject to a License Agreement. Unauthorized use, copying or distribution of the program or any of its components may result in severe criminal or civil penalties, and will be prosecuted to the maximum extent under the law.


All trademarks and registered trademarks used in this documentation are property of their owners.

Table of Contents

1. Home	1
2. On Devices.....	2
3. Energy.....	3
4. Rooms	4
4.1 List of Appliances.....	5
5. Appliances	6
5.1 Lights	7
5.2 Fan	8
5.3 Socket	9
5.4 Curtain	10
5.5 Water Sprinkler	11
6. Moods.....	12
7. Sensor	13
8. Lock.....	14
9. Shortcuts.....	15
10. Moods Setup.....	16
11. Add Lock.....	18
12. Notifications.....	19
13. Scheduler.....	20
14. Help.....	23
15. Settings	26

1. Home

Screen 1



This is your Home screen for your Master Tablet. Go through this manual to know every function of this application.

List of Setup options:

A. Shortcuts



E. Notifications



B. Mood Setup



F. Scheduler



C. Lock Setup



G. Help



D. Settings



2. On Devices


Screen 2



On This Screen You will be able to see all switched On appliances in your entire house. You can switch off all these appliances listed on this screen.

3. Energy

Screen 3




In this screen you will be able to see Real time energy consumption appliancewise and roomwise.

In next window you will be able to see the past consumption of energy roomwise, appliancewise and datewise.

4. Room


Screen 4



Click on Rooms and you will be directed to **Screen 5 List of Appliances** For particular Rooms.

4.1 List of Appliances

Screen 5



This is the list of all the appliances in the room. You can Control and switch between these appliances as per your requirement. When Button has a green mark it means the appliance is switched on. You can also switch between different levels for dimmable appliances and curtains.

5. Appliances

Screen 6




When You tap on Appliances button You will see Screen 6 on your tab. Please go through below mentioned chapters to know more about all these icons.

- 5.1 Lights
- 5.2 Fan
- 5.3 Socket
- 5.4 Curtain
- 5.5 Water Sprinkler

5.1 Lights


Screen 7



You can access all the Lights in your house that are integrated with DEFT from this list. You can even switch between different levels of light intensity.

5.2 Fan


Screen 8



You can access all The fans in your house from this menu. Also you can switch between different speed levels.

5.3 Sockets


Screen 9



In this menu you will be able to see all sockets in your house which are integrated with DEFT.

5.4 Curtains


Screen 10



In this menu You will be able to see all the curtains that are integrated with DEFT and you can also access the curtains form this menu.

5.5 Water Sprinkler


Screen 11



In this menu you can access all the sprinklers that are integrated with Deft.

6. Moods

Screen 12




In this menu you will be able to access the moods that are already set with help of Moods Setup.

You can set up new moods from Home screen. By using Lower setup panel.

7. Sensors


Screen 13



In this menu You will be able to control and access all the sensors that are available in your home.

8. Locks


Screen 14



In this menu you will be able to access locks that are integrated with DEFT. You can either open or close from this menu.

9. ShortCut


Screen 15



From this menu you will be able to access shortcuts that are created by you so that you can get a faster access to your important appliances.


10. Moods Setup

Screen 16



Enter The mood name And then Click on Next to select Room. Now you will be directed to Screen 17.

Screen 17



Select The room and then click Ok. Now you will be directed to Screen 18.

Screen 18



Select Appliances That you want to add in Mood and Click on OK. And you will be directed to [Screen 1: Home](#)

11. Add Lock

Screen 19

The screenshot shows the 'DEFT MASTER' app interface. On the left, a sidebar lists three room categories: 'Demo Living Room', 'Office Dining Room', and 'Pune Child Bed Room', each preceded by a plus icon. The main content area is a white modal titled 'DEFT MASTER'. Inside this modal, there are two input fields: 'Lock Id' with the value '0' and 'LOCK_NAME' with the value 'Main Door'. At the bottom of the modal are two buttons: 'CANCEL' and 'SAVE'. The background of the app is dark grey, and at the bottom, there is a navigation bar with a back arrow, a home icon, and a plus icon in the bottom right corner.

Give name to your lock and click on Save.

12. Notifications


Screen 20



In this menu you will be able to see all the activities in your house like accessing different appliances with date and time details.


13. Scheduler

Screen 21




Click on Create New Scene. You will be directed to Screen 22.

Screen 22




Give name for the new scenario. You will be directed to Screen 23.

Screen 23




Set the start time for the schedule. And click on next You will be directed to screen 24.

Screen 24




Set the end time for the schedule. Then click on to next button. You will be redirected to Screen 25.

Screen 25



Select the days on which you want this schedule to be followed. Then click on OK. You will be directed to Screen 26.


Screen 26



Select between different appliances and curtains that you require to be scheduled. Then tap on Finish to complete the mood settings. Then you will be directed to Screen 1: Home.


14. Help

Screen 27




This button is used in case of any failure in the system so that we can resolve the issues for you. Click on Launch Complaint to File the failure/error. Then You will be directed to screen 28.

Screen 28



Please go through the basic trouble shooting before launching Complaint. If you have already checked for the possible issues. Tick the check box and tap Ok button. Then You will be directed to screen 29.

Screen 29



After clicking Ok you will be able to see this screen on this screen you will be able to check the status of previous complaints. Click on Launch new Complaint to file the issue.

15. Settings

Screen 30

