



*pd: Input FIFO size: 1024 samples*  
*pd: Input channel list FIFO size: 256 entries*  
*pd: Output FIFO size: 2048 samples*  
*pd: Manufacture date: 01-AUG-2004*  
*pd:*

*pd:*





Figure 2.5

You can change the parameters for each block by double-clicking on it and changing the values in the dialog box.

The Analog Input block's parameters are:

-

Figure 2.6

The Analog Input block's paramet



Figure 5.1

Sel