



REG1:

- Adjust super capacitor charging current
- Adjust maximum super capacitor voltage

- REG2:
 - Adjust maximum sensor voltage

- Supercapacitor voltage must be lower than battery voltage

RTEK1000
 Sheet: /
 File: SEPIC_Nobreak.kicad_sch
Title: SEPIC UPS supercapacitor
 Size: A4 | Date: 2024-06-01
 KiCad E.D.A. | kicad 7.0.9-7.0.9-ubuntu22.04.1 | Rev: 1.0
 Id: 1/1