

Raspberry Pi Connection Instructions

1. Locate the GPIO header pins 39 (Ground) and 40 (GPIO 21). They are the last two pins closest to the USB and Ethernet ports.
2. Identify the female +5V and GND pins on the trigger, and orient the trigger so that the GND pin lines up with GPIO pin 39 (Ground), and +5V pin lines up with GPIO pin 40 (GPIO 21). The trigger module should be components side down.
3. Push the trigger module onto the GPIO header pins
4. Connect a 3.5mm audio cable to the trigger module and interface it with your camera using appropriate cables/adapters.

