

POT

LDR

NTC

NTC

A0

A1


A2

A3

A4

A5

RESET



GND

3V3

GND

A4

3V3

SDA
SCL

SCK
MISO
MOSI
G LED
R LED
B LED

PD7
PD6
PD5
PD4
PD3
PD2
PD1
PD0

TX
RX

RELAY

PB 1

PB 2

PB 3

PB 4

IR

BUZZER