




USB TYPE C




POWER & BATT CHARGING




5V TO 3.3V





USB TO UART



PWR LED



BOOT AND RESET BUTTON



EnkFi 5.83"				Cannot open file C:\Users\DEEPAK\Download\SB logo.png. File does not	
Size: A4	Revision: V1.0	Sheet: 1/2	SB Component Ltd.		
Date: 12-11-2024	Time: 12:15:28	DrawnBy:	Kemp House, 152-160, London EC1V 2NX.		


1

2








3

4

A



B

**SD CARD****BUZZER****RTC****USB TYPE C****5.83\_Inch E-Paper****BUTTONS****EnkPi 5.83"**

Size: A4	Revision: V1.0	Sheet: 2/2	SB Component Ltd. Kemp House, 152-160, London EC1V 2NX.	Cannot open file C:\Users\DEEPAK\Downloa ds\SB logo.png. File does not
Date: 12-11-2024	Time: 12:15:29	DrawnBy:		

1

2

3

4

C

D