

İÇİ AÇIYORSA VE KİMLİĞİ BİLİNİYORSA



F1




UR1


U-PWR



CP1



220VAC



RL1



SERIAL

X1

X1C1

RES1

X1C2

I / O



DP1

CP2

CP3

D5

RESET

CP1

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E

D2

R4

D

R2

E


D2

R4

D

R2


E



EXTERNAL I/O -1

EXTERNAL I/O -2

AD 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100



NO NC COM OUT GND DOOR SNR +5VDC

3E