



PWM Controller




I2C Address


Note default address is 001000





Power input




Qwiic Bus



Haptic Drivers



Motor connectors



LRA/ERM select

