


## Steps to change Wireless Network/ Router name & Password:


1. Open any Web Browser and enter 192.168.1.1 in the address bar as in the image.




2. Enter the below details of your router as shown in the image

Default Account: **useradmin**


Default Password: **admin**



2. Upon login, below page will open



3. Click the 'Network' tab to open the wireless settings. Once the wireless settings are open, you will see 'SSID' which is the Wireless Network/ Router name & 'WPA Key' which is the router password.



5. Set your new Wireless Network/ Router name in SSID.

6. Set your new password in WPA key.

7. Click on apply to save changes.

8. Now connect your device with the new wireless network name with new password.