

Set Default Barcode Options

Scan the appropriate bar code below to reset the scanner to its default settings.

Restore Defaults: Resets all default parameters as follows:

- If no custom default values were configured, the factory default values are set for all parameters each time the Restore Defaults bar code below is scanned.
 - For a list of factory default values, see the “Standard Default Parameters Table” of your scanner’s Product Reference Guide (PRG) available from www.zebra.com/ScannerSoftware
- If custom default values were configured, the custom default values are set for all parameters each time the Restore Defaults bar code below is scanned.



Restore Defaults

Set Factory Defaults: Scan this bar code to restore the factory default values. This deletes any custom defaults set.

- For a list of factory default values, see the “Standard Default Parameters Table” of your scanner’s Product Reference Guide (PRG) available from www.zebra.com/ScannerSoftware



Set Factory Defaults

Write to Custom Defaults: Custom default parameters can be configured to set unique default values for all parameters. After changing all parameters to the desired default values, scan the Write to Custom Defaults bar code below to configure custom defaults.

- Once set, you can recover custom default settings by scanning the Restore Defaults barcode, above.



Write to Custom Defaults