

MDY Torah Tablet User Guide

Welcome to the MDY Shiurim Tablet App! This app brings the latest Shiurim right to your exclusive MDY Kosher tablet. Download your favorites, watch them live, or explore our huge library. Let's get started!

Getting Started

Charging and Turning On Your Tablet

- **Charge the device fully**, as the tablets are shipped with 0% battery. Plug the charger into the tablet's charging port and an electrical outlet.
- **Press and hold the power button** located on the side of the tablet until the screen lights up.

Initial Setup

Connecting to Wi-Fi

1. **Sign in as a guest**.
2. **Tap the settings icon** (gear) at the top right corner.
3. **Select 'Wi-Fi Settings'**.
4. **Choose your network** and enter the password.
5. **If a loading popup appears**, tap the background to dismiss it, then click the settings icon again to connect.

Navigating the Home Page

Bottom Navbar

- **Latest Shiurim**: See the newest uploaded classes.
- **Downloaded**: Access all your downloaded Shiurim here. When clicking on a downloaded video for the first time, it might prompt you to "Open with" - select Google Photos.
- **Live Shiurim**: Join the live Zoom class by tapping this tab.
- **Categories**: Explore our Shiur library. Pick a category (like Bava Kama), then choose the specific daf you want.
- **Bookmarks**: Save a Shiur for later by tapping the bookmark icon (requires an account, not available for guest login).

Top Navbar

- **Notifications Bell**: Get a reminder when new Shiurim are uploaded (coming soon!).
- **Settings Gear**: Change Wi-Fi, Bluetooth, refresh the app, or sign out of your account.
- **Back Arrow**: Go back to the previous screen.

Watching a Shiur

Video Player Controls

- **Play, pause, skip forward/backward**, and control playback speed.
- **PDF Icon**: Show or hide the PDF of the Shiur.
- **Download Icon**: Download the video.
- **Bookmark Icon**: Save it (requires an account).
- **Skip Intro**: (Coming soon!)

Landscape Mode (Horizontal)

- The video plays on the left, with the PDF on the right.

Features

Downloading Shiurim

- **Tap the download icon**. Allow the app to access your photos and videos the first time you do this.

Saving Shiurim

- Use the **Bookmarks** feature to save your favorite Shiurim.

Live Shiurim

- Join live Zoom classes by tapping on the "Live Shiurim" tab.

Troubleshooting

Wi-Fi Connection Issues

- Ensure your Wi-Fi is on and you are connected to the right network.
- Retry entering your password to ensure it's correct.

Account Issues (e.g., 'Hi null' Error)

- Make sure the tablet is connected to Wi-Fi.
- Sign out and sign back in to refresh your account data.
- Contact support if the problem continues.

Bluetooth Connectivity

- Go to settings, select Bluetooth, and ensure it is turned on. Follow on-screen instructions to pair with devices like headphones.

Battery Management

- Charge regularly and don't let the battery fully drain often, as this may affect its lifespan.

Getting Further Help

- Email: tablet@mdydaf.com
- WhatsApp: +1 845 445-7495