

# NuvlaBox

## Confined Network




Routed


source NAT

source NAT


LAN





WAN




Company router







## NuvlaBox



br0

Routed

Routed  
source NAT

source NAT

wlan0



### VMs on dedicated network:

The NuvlaBox eth0 is connected to the company's network.

VMs are reachable from WiFi network and from company's network via a routing rule. Internet is provided by NAT on company's network.


eth0

Company network

Company router



## NuvlaBox



br0


Routed

wlan0



IPv6  
source NAT  
source NAT

eth0




Company router  
Port forwarding  
(UPnP)



### IPv6:

The NuvlaBox is directly connected to Internet or through a company's network considered as untrusted.

VMs are reachable through WiFi network.



# NuvlaBox

Direct IPv6 connection:

...

