



(L) SD_MODE HIGH, CUT TO SWITCH TO MONO (R_LARGE ~634K)
LEFT CHANNEL



(R) SD_MODE HIGH (R_SMALL ~210K)
CUT TO SWITCH TO MONO (R_LARGE ~634K)
RIGHT CHANNEL



DIGITAL POWER

