


LONGER_LK4_Pro_Screen_Project instructions


1. How to open development software?

- (1) You should go into **Screen_software_guide** folder and unzip the **DGUS_V7381.zip**.
- (2) Go into DGUS_V7381 folder and double click **DGUS Tool V7.381.exe**.




2. How to open LK4_Pro_Screen_Project?

Click the Open file and select **DWprj.hmi** in **LK4_Pro_Screen_Project** folder. After clicking open button, you can see this page.



3. How to compile and build project?

- (1) Click File.
- (2) Click Generate compile build project.



4. Where is the generated file?

You can see a **DWIN_SET** folder in **LK4_Pro_Screen_Project** folder. **DWIN_SET** is screen UI firmware.

5. How to download firmware to the screen?

Copy **DWIN_SET** folder to the SD card. **SD card must be 4KB sectors, FAT32 format**. Then insert the SD card into the screen card slot and it will automatically download the firmware. After the download is successful, Unplug the SD card and restart your printer.

6. Where can I get help when I have trouble?

- (1) Read the development document carefully.
- (2) You can click <http://www.dwin.com.cn/home/English/service> to get help.

Note:

If you want to build a new project yourself, you can use the pictures in our **DWIN_SET** folder or draw 272*480 resolution pictures with Photoshop by yourself. Refer to the above steps for operation.