

## FEATURES & SPECIFICATION

### INTENDED USE

Support bracket for pendant mounting the Indura® small housing. Not available for large housing units.

### CONSTRUCTION

16 ga. galvanized sheet steel.

3.8" x 4" x 1.45"

Includes one pendant mount bracket and two 1/2" slotted hex head screws.

Conduit and canopy are not provided.

Actual performance may differ as a result of end-user environment and application.

Note: Specifications subject to change without notice.

Catalog  
Number


Notes

Type

Unit Accessories

# ELA IND PM

Pendant Mount Kit



Example: ELA IND PM

### ORDERING INFORMATION

ELA IND PM

#### Series

**ELA IND PM** Pendant mount kit for Indura small housing: IND618, IND654, IND1236, IND1254, IND6100, IND12100 (XTRA and SEL options), IND24100 (XTRA and SEL options)

## FEATURES & SPECIFICATIONS

### INTENDED USE

Battery support brackets for use when ceiling mounting the Indura® small housing unit. Not available for large housing units.

### CONSTRUCTION

20 ga. galvanized sheet steel

Includes one ceiling-mount bracket and one Phillips head screw.

Note: Must be used for ceiling-mount applications.


Actual performance may differ as a result of end-user environment and application.

Note: Specifications subject to change without notice.

Unit Accessories

# ELA IND CM

Ceiling Mount Kit



Example: ELA IND CM1

### ORDERING INFORMATION

Lead times will vary depending on options selected. Consult with your sales representative.

#### Series

##### UL Listed products

**ELA IND CM1** Ceiling mount kit for IND618

**ELA IND CM2** Ceiling mount kit for IND654, IND1236, IND1254

**ELA IND CM3** Ceiling mount kit for IND6100

**ELA INDX CM1** Ceiling mount kit for INDX618 (for use with standard, XTRA, or SEL only)

**ELA INDX CM2** Ceiling mount kit for INDX654/1236/1254 (for use with standard, XTRA, or SEL only)

ELA IND PM CM RHB R3 Unit Accessories

FEATURES & SPECIFICATION

INTENDED USE

Bracket for surface mounted single-gang j-boxes with 3-9/32" hole spacings for Indura remote heads.

CONSTRUCTION

Seals opening between surface mount box and and Indura mounting plate.


Dimensions fit footprint of remote Indura head mounting plate (see spec sheet [ELA-IND](#)).

Actual performance may differ as a result of end-user environment and application.

Note: Specifications subject to change without notice.

Catalog Number
Notes
Type

Unit Accessories



ELA IND RHB

Indura® Remote Head Bracket

ORDERING INFORMATION

Example: ELA IND RHB

ELA IND RHB

Series

ELA IND RHB Remote head brackets to use with surface-mounted j-boxes.

FEATURES & SPECIFICATIONS

INTENDED USE

Prepack provides template and hardware to field install third head on Indura® unit equipment.

INSTALLATION

Includes template and instructions to help with the drilling of holes for the third lamp on the small or large Indura® housing.


CONSTRUCTION

Includes necessary hardware to field install third head. (Third head not included.)

Tools needed: 9/64" (.140") dull bit; 1/2" (.500") dull bit Phillips screwdriver.

Actual performance may differ as a result of end-user environment and application.

Note: Specifications subject to change without notice.



Unit Accessories

ELA IND R3

Indura® Third Head Mounting Kit

ORDERING INFORMATION

Example: ELA IND R3

ELA IND R3

Series

ELA IND R3 Prepack kit to field install third head on Indura unit