

FMT IO Protocol Command

Command Definition. The package format is shown below:

head	cmd	len	content	alloc	checksum	end
uint8[2]	uint16	uint16	uint8*	uint8	uint16	uint8

PROTO_CMD_SYNC

command for synchronization. server send this command to client

- **cmd**: 1
- **content**: *NULL*

PROTO_ACK_SYNC

ack for synchronize command. client send this ack to server after it receives **PROTO_CMD_SYNC** from server

- **cmd**: 2
- **content**: *NULL*

PROTO_CMD_REBOOT

server send this command to request client to reboot

- **cmd**: 3
- **content**: *NULL*

PROTO_ACK_REBOOT

client send this ack after it receives **PROTO_CMD_REBOOT** before it reboot

- **cmd**: 4
- **content**: *NULL*

PROTO_DBG_TEXT

client send this package to server, in which contains debug information, similar to printf()

- **cmd**: 5
- **len**: data length in content, it should not larger than **(MAX_PACKAGE_SIZE-10)**, where 10 is size of **PackageStruct** except **content**. It is recommended len is not larger than 100.
- **content**: content include debug information