


DIGITAL PEN


Rechargeable Pen

1. It will 'auto sleep' if it is not used 30 minutes.
2. Click pen tip to wake pen up.


Notice: if the reading height become lower and the line is unstable, it means you have to charge.




Digital Pen



1. Unscrew the pen
2. Put an AAA battery in, + pole towards to pen tip end.
3. Press down Power on/off button, then pen works.
4. Second pressing to power off for saving power if you don't use it any more.



Charge Pen Tip



1. Ready Pen Clip
2. Clamping pen tip
3. Pull the tip out
4. Clamp a new tip and put it in gently