

## Initialization Guide

### Step 1: Connect to WiseRise WiFi

Ensure your device is connected to the WiseRise WiFi network.  
Password: '123456789'.

### Step 2: Access Configuration

Open a web browser and enter '192.168.4.1' in the address bar.

### Step 3: Select Your Network

Click on 'Configure WiFi' and choose the desired WiFi network for your clock.

### Step 4: Enter Network Credentials

Input your WiFi password in the designated field and click 'Save' to apply the settings.

### Step 5: All Done

Your WiseRise device is now successfully connected and ready for use.