

[illegible]




1	0800318368	CRISTAL ANTIVANDALICO PUBLICIDAD
1	0800385534	MONITOR PUBLICIDAD KORTEK KT-LA15CX
1	0800446121	MONITOR PUBLICIDAD KORTEK (450CD)
1	0800487345	MONITOR PUBLICIDAD KF
2	0800385525	MONITOR CLIENTE KORTEK
2	0800446130	MONITOR CLIENTE KORTEK
2	0800475660	PANTALLA TACTIL (SUSTITUIR CONJUNTO POR MONITOR KF 0800487354)
2	0800487354	MONITOR CLIENTE KFE301
3	0800436445	CAMARA USB
3	0800443561	METACRILATO USB
3	0800498351	CAMARA RF ECON 130
3	0800498397	SOPORTE INTERIOR DE PLASTICO CAMARA RF ECON 130
3	0800498388	CARATULA (SOLO SOPORTE) CAMARA RF ECON 130
3	0800498404	CRISTAL PROTECTOR CAMARA RF ECON 130
4	0800489227	SHUTTER G510 (PG FJ)
4	0800442189	SHUTTER BILLETES (PG NCR)
5	0800489218	SHUTTER GBXX (PG FJ)
5	0800442170	SHUTTER GBXX (PG NCR)
6	0800491063	BLOQUEO ENTRADA TARJETAS PG FJ
7	0800318171	BLOQUEO ENTRADA TARJETAS PG NCR




1	0800318288	TECLADO CURSORES
2	0800318279	TECLADO ALFABETICO
3	0800318260	TECLADO NUMERICO 1.0 (CAIXA) ZYT588-D12-F16
3	0800453201	TECLADO NUMERICO 3.0 (CAIXA) ZYT588-D300-F20
3	0800495933	TECLADO NUMERICO 5.0 (CAIXA) ZYT588-D400-F50
3	0800470898	KIT MECANICO PARA CAMBIAR TECLADO PCI 1.0 POR PCI 3.0
	0800470460	CABLE CURSORES – ALFABETICO
	0800470335	CABLE NUMERICO – ALFABETICO
4	0800395943	CONTACTLESS ANTENA+CABLE+ANTENA KIOSK II
4	0800395952	CONTACTLESS CONTROLADOR KIOSK II
4	0800474386	CONTACTLESS ANTENA+CABLE+ETIQUETA KIOSK III
4	0800474377	CONTACTLESS CONTROLADOR KIOSK III
4	0800474386	CONTACTLESS ANTENA+CABLE+ETIQUETA KIOSK II EMV CO V.2.6
4	0800487951	CONTACTLESS CONTROLADOR KIOSK II EMV CO V.2.6
5	0800446096	BAR CODE READER (PG FJ)
5	0800503210	BCR JDK-10216 (PG FJ)
5	0800489566	BCR JDK2111_REVB (PG FJ)
5	0800318821	SCANNER 2D READER (PG NCR)
5	0800499412	KIT MECANICO TOBERA ESCANER + SOPORTE CRISTAL (SIN CRISTAL)
6	0800318313	CRISTAL ESCANER



1	0800374500	ARO DE LUZ
2	0800318901	EMBOCADURA LIBRETAS
3	0800318885	EMBOCADURA TARJETAS
4	0800318894	EMBOCADURA RECIBOS
5	0800318929	EMBOCADURA INGRESOS
6	0800318910	EMBOCADURA BILLETES
2-6	0800455101	CONJUNTO TODAS LAS EMBOCADURAS
7	0800469980	FLICKER + DIFUSOR LARGO (PG FJ)
7	0800421709	LARGE MEEI LENS (PG NCR)
7	0800421727	LARGE MEEI BACK LIGHT (PG NCR)
7	0800318386	LARGE MEEI (THREE MODULES) (PG NCR)
8	0800469971	FLICKER + DIFUSOR CORTO (PG FJ)
8	0800421692	SHORT MEEI LENS (PG NCR)
8	0800421718	SHORT MEEI BACK LIGHT (PG NCR)
8	0800318377	SHORT MEEI (TWO MODULES) (PG NCR)
9	0800318395	FASCIA LIGHT POWER LEDS. BARRA DE LED VIEJA
9	0800318402	FASCIA LIGHT PSU. FUENTE LEDS LUZ FRONTAL (ANTIGUA VER PROC144)
9	0800318938	FASCIA - METACRILATO ILUMINACION
9	0800479274	FASCIA LIGHT SELF-REGULATED. KIT CONVERSION LUMINARIA VIEJA-NUEVA
9	0800479498	FASCIA LIGHT SELF-REGULATED. BARRA DE LEDS NUEVA

[illegible]

CABLES



1	0800453210	CONJUNTO CABLES USB+ALIMENTACION T-RPR & CRW PG NCR (USB MINI)
2	0800486701	CONJUNTO CABLES USB+ALIMENTACION T-RPR & CRW PG FJ (USB B)
	0800470460	CABLE TECLADO CURSORES A ALFABETICO
	0800470335	CABLE TECLADO NUMERICO A ALFABETICO
	0800491027	CABLE USB 2.0 A-MACHO / A-MACHO (PANTALLA TACTIL MONITOR CLIENTE KF)
	0800340743	CABLE USB A – MINI B (NFC / ESCANER PG NCR)
	0800475866	CABLE USB A – MINI B DOBLE (GOP PG FJ A CPU)
	0800476801	CABLE USB A-A 5 METROS (GBNA / TECLADO A CPU)
	0800258752	CABLE USB A-B (RECIBOS / COIN DISPENSER / GOP PG NCR)
	0800351008	CABLE USB A-B (TARJETAS / RECIBOS)
	0800453210	CABLE USB A-B (TARJETAS / RECIBOS)
	0800453238	CABLE USB A-B 1 METRO
	0800312710	CABLE USB A-B 3 METROS
	0800386917	CABLE USB DOBLE PARA TECLADO EPP D2X VER. 6 O SUPERIOR
	0800258093	CABLE VGA MONITORES
	0800351366	CABLE VIDEO DVI-D / GOP PG NCR
	0800453299	PROLONGADOR USB 2.0 ACTIVO
	0800316501	PROLONGADOR USB M-H 2 METROS
	0800035565	PROLONGADOR VGA M-H 2 METROS

[illegible]