



1	0800435909	PBPR PPRX200GL
1	0800248390	PBPR PPR2100
2	0800398110	MS-READER PPRX200GL
2	0800303695	MS-READER PPR2100
3	0800435918	IMS UNIT PPRX200GL
3	0800435963	CUBIERTA TRANSPARENTE DEL IMS PPRX200GL
4	0800435927	PRINT HEAD PPRX200GL
5	0800435972	PRINT HEAD MASK PPRX200GL
6	0800435936	FUENTE DE ALIMENTACION PPRX20GL
7	0800395453	CHAPA METALICA BOCA DE ENTRADA PPRX200GL
7	0800309500	CHAPA METALICA BOCA DE ENTRADA PPR2100
8	0800435981	BOCA DE ENTRADA DE PLASTICO PPRX200GL
9	0800435945	PLACA PRX10CB PPRX200GL
10	0800436686	MANDO/POMO VERDE PPRX200GL
11	0800436061	ACTUADOR S (ACTUADOR SENSOR DE ENTRADA DE LIBRETA)
11	0800436052	ACTUADOR (ACTUADOR SENSOR DE ENTRADA DE LIBRETA)
12	0800435954	GOMAS DE CAMBIO DE PAGINA