



monkkee

Tue, 10 Jul. 2018 10:17 AM

Install the right driver for SEGGER J-Link debug probe


install windows driver for J-Link debug probe (this driver is installed with one of the SEGGER software products)

Driver for SEGGER Software

Sometime, because a previous wrong installation, software can't see the J-Link debug probe. In this case use this procedure.


Open device manager

and search where is J-Link driver could be one of following.




then use following steps


select J-Link and click right.



chose Update driver



then click to select "Browse my computer for driver software"



Then chose "Let me pick from a list of available drivers on my computer"

← Update Drivers – J-Link

Browse for drivers on your computer

Search for drivers in this location:

D:\Portable\Tools\CP2102-Usb2Serial-Drivers-master

Browse...


☒ Include subfolders

→ Let me pick from a list of available drivers on my computer
This list will show available drivers compatible with the device, and all drivers in the same category as the device.


Next

Cancel

and finally select J-Link driver an then press Next button.



At the end you have to have **J-Link driver** under the **Universal Serial Bus controllers**



Driver for openocd

Open device manager

as the previous point update the driver

← Update Drivers – J-Link

Browse for drivers on your computer

Search for drivers in this location:

D:\Portable\Tools\CP2102-Usb2Serial-Drivers-master

Browse...

☒ Include subfolders

→ Let me pick from a list of available drivers on my computer
This list will show available drivers compatible with the device, and all drivers in the same category as the device.

Next

Cancel

Select J-Link xxx (libwdi)

☒ Show compatible hardware

Model

J-Link (Interface 2) (libusbK)

J-Link (Interface 2) (libusbK)

J-Link (Interface 2) (libwdi)

J-Link driver

At the end you have to have **J-Link** under the **Universal Serial Bus devices**

USB Root Hub (USB 3.0)
Universal Serial Bus devices
J-Link
WSD Print Provider